## Samsung DG94-00889B

# Samsung DG94-00889B Cook Top Assembly Frame Instruction Manual

Model: DG94-00889B

## 1. Introduction

This manual provides essential information for the installation, operation, and maintenance of your Samsung DG94-00889B Cook Top Assembly Frame. This genuine OEM part is manufactured to exact specifications, ensuring compatibility and reliable performance for your Samsung oven.

### Compatible Models

This assembly frame is compatible with the following Samsung oven models:

- NE58F9500SS/AA
- NE58K9500SG/AA
- NE58K9430SS/AA
- NE58F9500SS/AC
- NE58K9500SG/AC
- NE58K9430/AA
- NE58R9430SG/AC
- NE58R9431ST/AA
- NE58R9431SG/AA
- NE58R9431SS/AA

## 2. Safety Information

Always prioritize safety when handling and installing appliance parts. Read all instructions carefully before proceeding.

- **Disconnect Power:** Always ensure the appliance is disconnected from its power source before attempting any installation or maintenance.
- **Wear Protective Gear:** Use appropriate personal protective equipment, such as gloves and safety glasses, to prevent injury.
- **Professional Installation Recommended:** If you are unsure about any step, it is recommended to seek assistance from a qualified technician.

- **Handle with Care:** The cook top assembly frame contains tempered glass, which can break if mishandled.

### Proposition 65 Warning

**WARNING:** This product can expose you to chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

## 3. Product Overview

### Specifications

| Feature | Detail |
|---|---|
| Brand | Samsung |
| Model Number | DG94-00889B |
| Material | Tempered Glass |
| Color | Black |
| Product Dimensions (D x W x H) | 28" x 34" x 6" |
| Estimated Weight | 18 lbs |
| Installation Type | Drop-In |
| Burner Type | Induction |
| Number of Heating Elements | 1 |
| Control Type | Glide Touch |
| Special Features | Adjustable Temperature, Automatic Ignition |

### What's in the Box

- 1 x Samsung DG94-00889B Cook Top Assembly Frame

### Product Image




Image: Samsung DG94-00889B Cook Top Assembly Frame, featuring a sleek black tempered glass surface with five distinct circular burner outlines.

## 4. Setup and Installation

The Samsung DG94-00889B Cook Top Assembly Frame is designed for drop-in installation. This section provides general guidance; always refer to your specific oven model's service manual for detailed, step-by-step instructions.

### Tools Required (Typical)

- Philips head screwdriver
- Flathead screwdriver (optional, for prying)
- Gloves

### General Installation Steps

1. **Prepare the Area:** Clear the work area around the oven. Ensure adequate lighting.
2. **Disconnect Power:** Turn off the circuit breaker supplying power to the oven. Verify power is off before proceeding.
3. **Remove Old Cook Top:** Carefully remove any screws or clips securing the old cook top assembly frame. Lift the old frame out of its position.
4. **Transfer Components:** Depending on your oven model, you may need to transfer certain components (e.g., heating elements, wiring harnesses, control knobs) from the old frame to the new DG94-00889B assembly frame. Follow your oven's service manual for precise instructions on component transfer.
5. **Install New Cook Top:** Carefully lower the new DG94-00889B assembly frame into position. Ensure it sits flush and is properly aligned.
6. **Secure the Frame:** Reinstall any screws or clips to secure the new cook top assembly frame. Do not overtighten.

7. **Reconnect Power:** Restore power to the oven by turning on the circuit breaker.
8. **Test Functionality:** Test all heating elements and controls to ensure proper operation.

## 5. Operating Instructions

As the DG94-00889B is an assembly frame, its operation is integrated with your Samsung oven. Refer to your oven's primary user manual for detailed operating instructions, including:

- Turning on/off heating elements.
- Adjusting temperature settings.
- Using special features like automatic ignition or specific burner types (e.g., induction).
- Utilizing the Glide Touch control panel.

## 6. Maintenance

Proper care and maintenance will extend the life of your cook top assembly frame.

### Cleaning the Tempered Glass Surface

- **Daily Cleaning:** For light spills and everyday cleaning, wipe the surface with a soft cloth and a mild glass cleaner or a ceramic cooktop cleaner.
- **Stubborn Stains:** For burnt-on food or stubborn stains, allow the cooktop to cool completely. Apply a ceramic cooktop cleaner and gently scrape with a plastic or specialized cooktop scraper. Avoid abrasive cleaners or scouring pads, as these can scratch the glass.
- **Avoid Impact:** Do not drop heavy or sharp objects on the glass surface, as this can cause cracks or breakage.
- **Check for Damage:** Regularly inspect the glass surface for any signs of cracks or damage. If damage is found, discontinue use and consider replacement to prevent further issues.

## 7. Troubleshooting

If you encounter issues after installing the DG94-00889B Cook Top Assembly Frame, consider the following:

- **No Power to Cooktop:** Ensure the circuit breaker is on and the oven is properly connected to power. Check all wiring connections made during installation.
- **Burners Not Heating:** Verify that all components transferred from the old frame are correctly installed and connected. Consult your oven's service manual for specific wiring diagrams.
- **Controls Not Responding:** Check the connection of the control panel to the cook top assembly. Ensure no wires are pinched or loose.
- **Visible Damage:** If the glass surface is cracked or damaged, it requires replacement. Do not attempt to use a damaged cooktop.

For complex issues or if troubleshooting steps do not resolve the problem, contact Samsung customer support or a certified appliance technician.

## 8. Warranty and Support

This genuine Samsung part is manufactured by Samsung. For warranty information and customer support, please refer to the documentation provided with your original Samsung oven or visit the official Samsung website.

You can also visit the Samsung Store on Amazon for additional product information and support resources.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question