HABA HA1377

HABA Chocolate Ice Cream Cone Toy - Model HA1377 User Manual

Instructions for Use and Care

1. Product Overview

The HABA Chocolate Ice Cream Cone is a durable wooden toy designed for imaginative play. It features a naturally colored cone and a red cherry-colored ice cream scoop, crafted to resemble a classic dessert. This item is intended to enhance play kitchen or play food collections, encouraging creative role-playing scenarios.



Figure 1: HABA Chocolate Ice Cream Cone. This image displays the wooden toy, featuring a light brown cone and a red spherical ice cream scoop.

2. Safety Information

This product is designed for children aged 3 months and older. Please observe the following safety guidelines:

- **Material Safety:** The toy is constructed from hard wood and finished with completely non-toxic materials, ensuring it is safe for children.
- **Supervision:** Adult supervision is recommended during play, especially for younger children.
- **Inspection:** Regularly inspect the toy for any signs of damage, such as splinters or loose parts. Discontinue use if damage is observed.
- **Choking Hazard:** While designed for safety, ensure the toy is used appropriately and not placed in the mouth by children who may attempt to swallow it.

3. Setup

The HABA Chocolate Ice Cream Cone requires no assembly. It is ready for use directly out of its packaging.

1. Remove the toy from its packaging.
2. Inspect the toy for any manufacturing defects or shipping damage.
3. The toy is now ready for imaginative play.

4. Operating Instructions

This toy operates manually through imaginative engagement. There are no electronic components or complex mechanisms.

- Encourage children to incorporate the ice cream cone into pretend play scenarios, such as serving in a play kitchen or operating an imaginary ice cream stand.
- The toy is designed to stimulate creativity and social interaction during play.

5. Maintenance and Cleaning

Proper care will ensure the longevity of your HABA Chocolate Ice Cream Cone.

- **Cleaning:** Wipe the toy clean with a slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the wood or its non-toxic finish.
- **Drying:** After cleaning, allow the toy to air dry completely before storing.
- **Storage:** Store the toy in a dry environment, away from direct sunlight or extreme temperatures, to prevent warping or fading of the wood.

6. Troubleshooting

This simple wooden toy has minimal components, reducing the likelihood of issues. However, if you encounter any concerns:

- **Minor Scratches/Dents:** As a wooden toy, minor cosmetic wear may occur with regular use. This is generally considered normal and does not affect functionality.
- **Damage:** If the toy becomes significantly damaged (e.g., large cracks, splinters, broken pieces), discontinue use immediately to prevent injury.
- **Fading:** Prolonged exposure to direct sunlight can cause colors to fade. Store the toy appropriately to minimize this.

7. Specifications

Model Number:	HA1377
Brand:	HABA
Material:	Wood
Dimensions (L x W x H):	3 x 2 x 0.5 inches (approximately)
Weight:	0.05 Pounds (approximately)
Recommended Age:	3 months and up
Educational Objective:	Imagination

Assembly Required:	No

8. Warranty and Support

Specific warranty information for the HABA Chocolate Ice Cream Cone (Model HA1377) is not provided within this document. For details regarding warranty coverage, product support, or to report any issues, please contact HABA customer service directly or visit their official website.
You can often find contact information on the product packaging or by searching for "HABA customer support" online.

© 2023 HABA. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question