Outsunny 100110-088W

Outsunny Gazebo Canopy Party Tent - Instruction Manual

Model: 100110-088W

Product Overview

The Outsunny 10' x 30' Gazebo Canopy Party Tent is designed for temporary outdoor events, providing a covered space for gatherings. It features a durable water-resistant polyethylene cover and removable sidewalls with windows, offering flexibility for various occasions. The structure is supported by a steel frame and includes ropes and stakes for enhanced stability.



Figure 1: The Outsunny 10' x 30' Gazebo Canopy Party Tent fully assembled with all five windowed sidewalls in place, providing a large enclosed space.

Setup and Assembly

Assembling the Outsunny Gazebo Canopy Party Tent requires careful attention to detail and sufficient manpower for safety and ease. It is recommended to have at least **6 people** to assist with the assembly process.

Components Checklist:

- 10' x 30' Steel Frame (various poles and connectors)
- 1 Top Cover (polyethylene canopy)
- 5 Window Style Sidewalls
- Connectors (for frame assembly)
- Ropes and Stakes (for stability)

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out. Refer to the included parts diagram

(if available in physical manual) to identify each piece.

2. **Assemble the Frame:** Begin by connecting the steel poles using the provided connectors. Ensure all connections are secure. The frame consists of horizontal and vertical sections.



Figure 2: A close-up view of a white plastic connector used to join multiple steel poles of the gazebo frame, showing the secure pin mechanism.



Figure 3: An alternative angle of a white plastic connector, illustrating how the frame poles slot into place to form the tent's structure.

3. **Attach the Top Cover:** Once the main frame is erected, carefully drape the polyethylene top cover over the frame. Ensure it is centered and evenly distributed.
4. **Install Sidewalls:** Attach the five window style sidewalls using the Velcro fasteners. These can be added or removed as needed.



Figure 4: The Outsunny Gazebo Canopy Party Tent viewed from the side, highlighting the five removable sidewalls with their large pane windows.

5. **Secure with Ropes and Stakes:** For optimal stability, use the provided ropes and stakes to anchor the tent securely to the ground. This is crucial, especially in light wind conditions.

Important Note:
This tent is intended for temporary use. Do not leave it set up for several days, especially in windy or adverse weather conditions. Disassemble and store the tent if strong winds or heavy precipitation are expected.

Operating Instructions

The Outsunny Gazebo Canopy Party Tent is designed for versatility and ease of use during events.

- **Removable Sidewalls:** The five sidewalls can be easily attached or removed using Velcro fasteners. This allows you to customize the tent's configuration based on weather conditions or event needs, providing an open canopy or an enclosed space.
- **UV Protection:** The durable polyethylene cover is designed to block up to 90% of the sun's UV rays, offering protection from sun exposure for your guests.
- **Ventilation:** When sidewalls are installed, ensure adequate ventilation, especially during warm weather. Consider partially opening sidewalls or using fans if necessary.

Maintenance

Proper maintenance will extend the life of your Outsunny Gazebo Canopy Party Tent.

- **Cleaning:** Clean the polyethylene cover and sidewalls with mild soap and water. Avoid harsh chemicals or abrasive cleaners that could damage the material. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Inspect the steel frame periodically for any signs of rust or damage. Clean any dirt or debris from the frame.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure the fabric is completely dry to prevent mold or mildew growth.
- **Component Check:** Before each use, check all poles, connectors, ropes, and stakes for wear and tear. Replace any damaged parts to ensure structural integrity.

Troubleshooting

Here are some common issues and their solutions:

- **Tent Instability:**
    - Ensure all frame connections are fully secured.
    - Verify that ropes are taut and stakes are firmly driven into the ground.
    - This tent is for temporary use; it is not designed for strong winds or prolonged exposure to adverse weather. Disassemble if severe weather is anticipated.
- **Water Accumulation on Canopy:**

- Ensure the canopy is stretched tightly and evenly over the frame to prevent pooling.
- Regularly check for and remove any accumulated water, especially during rain, to prevent damage to the frame and fabric.

- **Difficulty with Assembly:**
  - Confirm that you have at least 6 people assisting with the setup, as recommended.
  - Double-check that all parts are correctly identified and oriented according to the assembly instructions.

Specifications

Feature	Detail
Brand	Outsunny
Model Number	100110-088W
Product Dimensions	360"L x 120"W x 98.4"H (10' x 30' x 8.2')
Item Weight	52 Pounds
Material	Polyethylene, Alloy Steel, Metal
Frame Material	Metal, Alloy Steel
Water Resistance Level	Water Resistant
Ultraviolet Light Protection	Yes (blocks up to 90% of UV rays)
Color	White
Assembly Required	Yes
UPC	799932987397

Warranty and Support

For any questions regarding your Outsunny Gazebo Canopy Party Tent, including warranty information or technical support, please contact Outsunny customer service directly.
You can find more information and contact details by visiting the officialOutsunny Store on Amazon.

© 2024 Outsunny. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question