Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HCDZ HCDZ-X07872

HCDZ Replacement Remote Control User Manual

Model: HCDZ-X07872

Introduction

This manual provides instructions for the HCDZ Replacement Remote Control, designed for use with Samsung SP61L3HRX/STR BP5900071B DLP Projector HDTV TVs. This remote is an infrared (IR) replacement unit that requires no programming, offering a straightforward solution for controlling your compatible device.



Image: Front view of the HCDZ Replacement Remote Control. This image displays the overall design and button layout of the remote

control.

Setup

Battery Installation

The remote control requires two AAA batteries, which are not included with the product. Please ensure you have new AAA batteries available for installation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Rear view of the HCDZ Replacement Remote Control with the battery compartment open, showing the slots for two AAA batteries.

Operating Instructions

Basic Operation

Once batteries are correctly installed, the HCDZ Replacement Remote Control is ready for immediate use. No programming or code entry is required for its operation with compatible Samsung devices.

- Point the remote control directly at the Samsung DLP Projector HDTV TV's infrared (IR) receiver.
- Press the desired function button (e.g., Power, Volume Up/Down, Channel Up/Down, Menu) to control your device.

Ensure there are no physical obstructions between the remote control and the device's IR receiver for optimal performance.

Maintenance

Care and Maintenance Guidelines

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the remote's surface or internal components.
- **Battery Replacement:** If the remote control's performance degrades, buttons become unresponsive, or it stops functioning, replace both AAA batteries with new ones. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or improper operation.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, high humidity, and extreme temperatures. Remove batteries if the remote will not be used for an extended period to prevent battery leakage.

Troubleshooting

Common Issues and Solutions

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the positive (+) and negative (-) terminals aligned as indicated inside the compartment. Replace old or depleted batteries with new AAA batteries.
- **Line of Sight:** Verify that there are no objects blocking the path between the remote control's IR emitter and the device's IR receiver.
- **Distance:** Ensure you are within the effective operating range of the remote control, typically within 15-20 feet (4.5-6 meters) of the device.
- **Device Compatibility:** Confirm that your device is a compatible Samsung SP61L3HRX/STR BP5900071B DLP Projector HDTV TV. This remote is a specific replacement and may not work with other models.

Intermittent Operation

- This may indicate low battery power. Replace the batteries with new ones.
- Ensure the remote's IR emitter (the small LED at the front) is clean and unobstructed.

Specifications

Feature	Detail
Model Number	HCDZ-X07872
Brand	HCDZ
Compatible Devices	Samsung SP61L3HRX/STR BP5900071B DLP Projector HDTV TV
Connectivity Technology	Infrared (IR)
Max Number of Supported Devices	1
Special Feature	Ergonomic design
Batteries Required	2 x AAA (not included)
Item Weight	3.2 ounces (approx. 90.7 grams)

Feature	Detail
Package Dimensions	11.02 x 5.91 x 0.79 inches (approx. 28 x 15 x 2 cm)

Customer Support

For further assistance, technical support, or inquiries regarding your HCDZ Replacement Remote Control, please contact HCDZ customer support. Refer to your product packaging or the seller's information for specific contact details and warranty information.

You may also visit the HCDZ Store on Amazon for additional product information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00ITI674I

More documents and user manuals: **https://manuals.plus/**