Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Adesso 7205-22

Adesso Multi-White Shade Floor Lamp Instruction Manual

Model: 7205-22 | Brand: Adesso

Introduction

The Adesso 7205-22 Multi-White Shade Floor Lamp is designed to provide versatile and stylish lighting for your living space. Featuring adjustable gooseneck arms and a user-friendly rotary switch, this lamp offers customizable illumination to suit various needs. This manual provides essential information for the proper setup, operation, and maintenance of your new floor lamp.

Key Features

- **Stylish and Bright:** Perfect for any living space, featuring a slim 67-inch pole and 10-inch flexible lights for ambient or focused illumination.
- **Adjustable Lighting:** Five movable shades allow light to be aimed in various directions, ideal for lighting large rooms, offices, or hallways.
- **Modern Sleek Design:** Brushed steel finish with five modular white frosted acrylic shades provides a clean, minimalist look.
- **User-Friendly Rotary Switch:** A 4-way rotary switch on the pole offers smooth and easy control over lighting levels.
- **Easy Assembly:** Designed for quick setup, requiring only a few minutes to assemble.

Setup Instructions

Follow these steps to assemble your Adesso floor lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components are present: base, pole sections, lamp head with gooseneck arms, and five white frosted acrylic shades.
2. **Assemble the Pole:** Screw the pole sections together clockwise until secure.
3. **Attach to Base:** Securely screw the assembled pole into the heavy metal base.
4. **Attach Lamp Head:** Screw the lamp head assembly (with gooseneck arms) onto the top of the pole.
5. **Install Shades:** Place each white frosted acrylic shade onto its respective gooseneck arm. Secure them by screwing the retaining rings (if applicable) onto the sockets.
6. **Install Bulbs:** Insert five 25-watt incandescent bulbs (not included) into the E26 sockets. Do not exceed the maximum

wattage.

7. **Position the Lamp:** Place the lamp in your desired location. Ensure the power cord is not pinched or obstructed.



Figure 1: Lamp components ready for assembly.

Operating Instructions

Your Adesso floor lamp is designed for ease of use:

- **Power On/Off:** Plug the lamp into a standard 120V AC outlet. Use the 4-way rotary switch located on the pole to cycle through lighting options.
- **Lighting Modes:** The rotary switch allows you to activate different combinations of the five lights, providing varied illumination levels.
- **Adjusting Light Direction:** The five gooseneck arms are flexible. Gently bend each arm to direct the light exactly where needed, whether for task lighting or ambient glow.

Your browser does not support the video tag.

Video 1: A Closer Look at the Adesso 7205-22 Floor Lamp, demonstrating its adjustable arms and rotary switch functionality.

Maintenance

To ensure the longevity and appearance of your lamp:

- **Cleaning:** Always unplug the lamp before cleaning. Wipe the metal surfaces with a soft, dry cloth. For the acrylic shades, use a soft, damp cloth and mild soap if necessary, then dry thoroughly. Avoid abrasive cleaners.
- **Bulb Replacement:** Ensure the lamp is unplugged and bulbs have cooled completely before attempting to replace them. Use only 25-watt incandescent bulbs with an E26 base.

Troubleshooting

If you encounter issues with your lamp, try these common solutions:

- **Lamp Not Turning On:**
  - Check if the lamp is securely plugged into a working outlet.
  - Ensure the rotary switch is turned to an 'ON' position.
  - Verify that the light bulbs are correctly installed and not burnt out. Replace any faulty bulbs.
- **Flickering Lights:**
  - Tighten the light bulbs in their sockets.
  - Ensure the wattage of the bulbs matches the lamp's requirements (25-watt incandescent).
  - Check for loose connections in the power cord or outlet.
- **Unstable Lamp:**
  - Ensure the pole sections are tightly screwed together.
  - Verify the pole is securely attached to the base.
  - Place the lamp on a flat, stable surface.

Specifications

Attribute	Detail
Brand	Adesso
Model Number	7205-22
Color	Silver
Product Dimensions	8"D x 10.5"W x 72"H
Item Weight	13.31 pounds (6.05 Kilograms)
Material	Acrylic (Shades), Metal (Base)
Finish Type	Brushed
Light Source Type	Incandescent
Number of Light Sources	5
Bulb Base	E26
Wattage	125 watts (total)

Voltage	120 Volts
Switch Type	Rotary
Certification	UL, ETL Listed

Warranty and Support

This product is UL and ETL listed, ensuring it meets government-regulated safety standards for the USA. For specific warranty details or technical support, please refer to the product packaging or contact Adesso customer service directly. Information regarding optional protection plans may be available from your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I buy replacement shades for the Adesso 7205-22 Multi-White Shade Floor Lamp?

The instruction manual for the Adesso 7205-22 Multi-White Shade Floor Lamp does not explicitly list a part number for individual replacement shades. However, the shades are described as modular white frosted acrylic shades that...

Read full answer

Open the live page

https://manuals.plus/asin/B00J0HCDTA

More documents and user manuals: **https://manuals.plus/**