Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Burg-Wächter FAVOR S5 K

Burg-Wächter FAVOR S5 K Safe Instruction Manual

Model: FAVOR S5 K

1. Introduction

This manual provides essential instructions for the proper installation, operation, and maintenance of your Burg-Wächter FAVOR S5 K Safe. Please read this manual thoroughly before using the safe to ensure optimal security and longevity of the product. Keep this manual for future reference.

2. Product Overview

The Burg-Wächter FAVOR S5 K is a compact home safe designed for securing valuables such as passports, cash, jewelry, and important documents. It features a solid single-walled metal body and a reliable double-bit lock system for enhanced security.



Image 1: Front view of the Burg-Wächter FAVOR S5 K Safe. The safe is black with a keyhole centered on the door and a small 'favor' logo in the bottom right corner.

3. Safety Instructions

- Always keep the safe keys in a secure location, separate from the safe itself, and away from unauthorized individuals.
- Do not store the keys inside the safe.
- Ensure the safe is securely mounted to prevent unauthorized removal.
- Keep the safe door closed and locked when not in use.
- Avoid exposing the safe to extreme temperatures or humidity. This safe is not water-resistant.
- Do not attempt to force the lock or tamper with the safe mechanism.

4. Package Contents

Carefully unpack your Burg-Wächter FAVOR S5 K Safe and verify that all components are present:

- 1 x Burg-Wächter FAVOR S5 K Safe
- 2 x Double-bit keys
- Mounting hardware (screws and wall plugs)



Image 2: The Burg-Wächter FAVOR S5 K Safe shown with its two double-bit keys and the included screws and wall plugs for mounting.

5. Setup and Installation

The FAVOR S5 K safe is designed for wall mounting to enhance security. It features pre-drilled holes in the back wall for anchoring.

5.1 Choosing a Location

Select a discreet and secure location for your safe. Ensure the mounting surface (wall) is strong enough to support the weight of the safe and its contents.

5.2 Mounting Instructions

1. Position the safe against the desired mounting surface.
2. Mark the locations of the pre-drilled holes on the wall.
3. Drill pilot holes into the wall at the marked locations, using a drill bit appropriate for the included wall plugs and your wall material.
4. Insert the wall plugs into the drilled holes.
5. Align the safe's pre-drilled holes with the wall plugs and secure the safe using the provided screws. Tighten firmly to ensure the safe is securely anchored.



Image 3: Back view of the Burg-Wächter FAVOR S5 K Safe, highlighting the two pre-drilled holes for wall mounting.

6. Operation

The FAVOR S5 K safe uses a double-bit key lock system.

6.1 Opening the Safe

1. Insert one of the provided double-bit keys into the keyhole on the safe door.
2. Turn the key clockwise (or counter-clockwise, depending on the lock mechanism) until the locking bolts retract.
3. Pull the door open.

6.2 Closing and Locking the Safe

1. Close the safe door firmly.
2. Insert the key into the keyhole.
3. Turn the key counter-clockwise (or clockwise) until the locking bolts extend and the door is securely shut.
4. Remove the key and store it in a secure, separate location.



Image 4: Interior view of the Burg-Wächter FAVOR S5 K Safe with the door open, showing the internal shelf and the double-bit lock mechanism on the inside of the door.

7. Maintenance

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lock Care:** Periodically check the lock mechanism for smooth operation. If the key becomes difficult to turn, a small amount of graphite lubricant can be applied to the key and inserted into the lock. Do not use oil-based lubricants.
- **Key Management:** Ensure keys are not bent or damaged. If a key is lost, contact Burg-Wächter for assistance, providing your safe's serial number if available.

8. Troubleshooting

Problem	Possible Cause	Solution
Key does not turn or is stiff.	Dust or debris in the lock; key is bent or damaged.	Apply graphite lubricant to the key. Ensure the key is not damaged. If the problem persists, contact support.
Safe door does not close properly.	Obstruction in the door frame; safe is not level.	Check for any obstructions. Ensure the safe is mounted level and securely.
Lost keys.	Keys misplaced or stolen.	Contact Burg-Wächter customer support for key replacement options. Provide proof of ownership and safe serial number.

9. Specifications

Brand	Burg-Wächter
Model	FAVOR S5 K
Product Dimensions (HxWxD)	250 x 350 x 250 mm (9.84"D x 13.78"W x 9.84"H)
Internal Capacity	18.6 Liters
Lock Type	Double-bit key lock
Material	Metal
Color	Black
Item Weight	6 kg (15.4 pounds)
Mounting Type	Wall Mount (pre-drilled holes in back)
Water Resistance Level	Not Water Resistant

10. Warranty and Support

For warranty information, technical support, or to order replacement keys, please refer to the official Burg-Wächter website or contact their customer service directly. Please have your product model and any serial numbers available when contacting support.
Manufacturer: Burg-Wächter
Part Number: FAVOR S5 K

© 2025 Burg-Wächter. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00J95WLAE

More documents and user manuals: **https://manuals.plus/**