Burg-Wächter FAVOR S3 K

Burg-Wächter Favor S3 K Safe Instruction Manual

Model: FAVOR S3 K (HxBxT: 200 x 310 x 200 mm)

Introduction

This manual provides essential instructions for the safe and effective use of your Burg-Wächter Favor S3 K Safe. Please read these instructions carefully before installation and operation to ensure proper functionality and security. This furniture safe features a solid walled body and a double-bit lock for reliable protection of your valuables.

Safety Instructions

- Always keep the keys in a secure location, separate from the safe itself.
- Do not store the keys inside the safe.
- Ensure the safe is securely mounted to prevent unauthorized removal.
- Regularly check the mounting for any signs of loosening.
- This safe is designed for indoor use. Avoid exposure to extreme temperatures or humidity.
- While the specifications mention "Fireproof", this typically refers to a degree of fire resistance, not absolute fire immunity. Consult the manufacturer's website for specific fire rating details if critical.

Package Contents

Verify that all components are present in the package:

- 1 x Burg-Wächter Favor S3 K Safe
- 2 x Double-bit keys
- Mounting material (screws and wall plugs)
- Instruction Manual (this document)



Image: The Burg-Wächter Favor S3 K Safe shown with its two double-bit keys and the included mounting screws and wall plugs, illustrating the complete package contents.

Setup and Installation

The Favor S3 K Safe is designed for wall mounting. Proper installation is crucial for security.

1. **Choose a suitable location:** Select a discreet and secure location for mounting the safe. Ensure the wall material is strong enough to support the safe's weight and contents.
2. **Mark drilling points:** Place the safe against the desired mounting surface. Use a pencil to mark the positions of the pre-drilled mounting holes on the back or bottom of the safe onto the wall.
3. **Drill holes:** Using an appropriate drill bit for your wall type, drill holes at the marked positions. The diameter of the drill bit should match the wall plugs provided.
4. **Insert wall plugs:** Insert the provided wall plugs into the drilled holes. Ensure they are flush with the wall surface.
5. **Mount the safe:** Align the safe's mounting holes with the wall plugs. Insert the screws through the safe's holes and into the wall plugs. Tighten the screws firmly using a screwdriver or wrench until the safe is securely fastened to the wall. Do not overtighten.



Image: A rear-side view of the Burg-Wächter Favor S3 K Safe, highlighting the pre-drilled holes for secure wall mounting.

Operating Instructions

The Favor S3 K Safe uses a double-bit key lock mechanism.

1. **Opening the safe:**
    - Insert one of the provided double-bit keys into the keyhole on the safe door.
    - Turn the key clockwise (or counter-clockwise, depending on the lock mechanism) until the locking bolts retract.
    - Pull the door open.
2. **Closing and locking the safe:**
    - Close the safe door firmly.
    - Insert the key into the keyhole.
    - Turn the key counter-clockwise (or clockwise) until the locking bolts extend and the door is securely shut.
    - Remove the key and store it in a secure, separate location.



Image: A front view of the Burg-Wächter Favor S3 K Safe, showing the double-bit keyhole where the key is inserted for locking and unlocking.



Image: The Burg-Wächter Favor S3 K Safe with its door open, revealing the interior storage space and the locking mechanism on the inside of the door.

Maintenance

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lock Mechanism:** Periodically apply a small amount of graphite powder or a specialized lock lubricant to the keyhole to ensure smooth operation of the double-bit lock. Do not use oil-based lubricants.
- **Inspection:** Regularly inspect the safe for any signs of damage, wear, or tampering. Check the mounting bolts for tightness.

Troubleshooting

Problem	Possible Cause	Solution
Key is difficult to turn or stuck.	Dust or debris in the lock mechanism; lack of lubrication.	Apply graphite powder or lock lubricant to the keyhole. Do not force the key.
Safe door does not close properly.	Obstruction in the door frame; safe not level; bent locking bolts.	Check for any obstructions. Ensure the safe is mounted level. If bolts are bent, contact customer support.
Safe feels loose after mounting.	Mounting screws are loose; wall material is compromised.	Retighten mounting screws. If the wall material is damaged, consider remounting in a new location or reinforcing the wall.

Specifications

Brand: Burg-Wächter

Model: FAVOR S3 K

External Dimensions (H x W x D): 200 x 310 x 200 mm (approx. 8.66"H x 12.99"W x 9.06"D)

Internal Dimensions (H x W x D): 198 x 308 x 166 mm

Lock Type: Double-bit key lock

Color: Black

Capacity: 10.2 Liters

Material: Metal

Mounting Type: Wall Mount

Item Weight: 5 kg (approx. 11 lbs)

Special Feature: Fireproof (refer to manufacturer for specific rating)

Warranty Information

Specific warranty details for the Burg-Wächter Favor S3 K Safe are provided by the manufacturer. Please refer to the official Burg-Wächter website or the documentation included with your purchase for comprehensive warranty terms and conditions.

Support and Contact

For further assistance, technical support, or inquiries regarding your Burg-Wächter Favor S3 K Safe, please visit the official Burg-Wächter website or contact their customer service department.
Official Website: www.burg.biz

© 2024 Burg-Wächter. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question