Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Crosley CR1101A

Crosley CR1101A Jukebox Instruction Manual

Model: CR1101A

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Crosley CR1101A Jukebox. This unit features a CD player, AM/FM radio, and a portable audio input for connecting external devices. It also includes color-shifting LED lighting and dynamic full-range stereo speakers.

2. Setup

2.1 Unpacking

Carefully remove the jukebox from its packaging. Retain all packing materials for future transport or storage.

2.2 Power Connection

Connect the AC power adapter to the DC input jack located on the rear of the unit. Plug the adapter into a standard wall outlet (AC 120V~60Hz).

2.3 Antenna Setup

For optimal FM reception, extend the FM wire antenna fully. For AM reception, the unit has a built-in AM antenna. Adjust the unit's position for best AM signal.

2.4 Placement

Place the jukebox on a stable, flat surface. Ensure adequate ventilation around the unit. Avoid placing it near heat sources or in direct sunlight.

3. Operating Instructions

3.1 Basic Controls

The song chart on the front of the unit can be flipped down to reveal the tuning dial and volume control. The LED display shows track information or radio frequency.

3.2 CD Player Operation

1. Press the **CD**/**AUX** button to select CD mode.
2. Gently pull the front panel marked "PULL TO OPEN" to access the CD tray.
3. Place a CD onto the spindle with the label side facing up.
4. Close the CD tray by pushing the front panel back into place.
5. The CD will begin playing automatically. Use the **PLAY**/**PAUSE**, **STOP**, **SKIP FORWARD**, and **SKIP BACKWARD** buttons for control.
6. The unit supports programmable 20-track memory. Refer to the detailed manual for programming instructions.



Image: Front view of the Crosley CR1101A Jukebox with the CD player door open, showing the CD tray. This illustrates how to insert a compact disc for playback.

3.3 AM/FM Radio Operation

1. Press the **AM/FM** button to select the desired radio band.
2. Rotate the **TUNING** dial (located behind the flip-down song chart) to select a radio station.
3. Adjust the **VOLUME** control to your preferred listening level.

3.4 Auxiliary Input (AUX)

The jukebox features a portable audio input for connecting external audio devices such as smartphones or MP3 players.

1. Connect one end of a 3.5mm audio cable (not included) to the headphone jack or line-out of your external device.
2. Connect the other end of the cable to the **AUX IN** jack located on the rear of the jukebox.
3. Press the **CD/AUX** button to select AUX mode.
4. Start playback on your external device. Adjust the volume on both the external device and the jukebox for optimal sound.



Image: Front view of the Crosley CR1101A Jukebox with a smartphone connected to the auxiliary input. This demonstrates how to connect an external audio device for playback.

3.5 LED Lighting

The unit features color-shifting LED lighting. The lights activate automatically when the unit is powered on. There is no separate control for the LED lighting.

4. Maintenance

4.1 Cleaning the Unit

Wipe the exterior of the jukebox with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Ensure the unit is unplugged before cleaning.

4.2 CD Player Care

To clean the CD lens, use a commercially available CD lens cleaner. Avoid touching the lens directly.

5. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not active	Ensure power cord is securely plugged into the unit and a working outlet.
No sound	Volume too low; incorrect mode selected; external device volume low	Increase volume; select correct mode (CD, AM/FM, AUX); increase volume on external device.
CD not playing	CD inserted incorrectly; CD dirty or scratched; CD player in wrong mode	Reinsert CD with label side up; clean or replace CD; ensure CD mode is selected.
Poor radio reception	Antenna not extended/positioned correctly; interference	Extend and reposition FM antenna; adjust unit's position for AM; move away from electronic devices causing interference.
Auxiliary input not working	Cable not connected; AUX mode not selected; external device not playing or volume low	Ensure 3.5mm cable is securely connected; select AUX mode; start playback and increase volume on external device.

6. Specifications

- **Model:** CR1101A
- **Power Input:** AC 120V~60Hz
- **Product Dimensions (L x W x H):** 7.25 x 10.25 x 14.25 inches
- **Item Weight:** 8 pounds
- **Connectivity Technology:** Auxiliary
- **Speaker Type:** Stereo
- **Functions:** CD Player, AM/FM Radio, Auxiliary Input



Image: Side view of the Crosley CR1101A Jukebox, showing the depth and speaker grilles. This provides a perspective on the unit's physical dimensions.

7. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Crosley website. Keep your proof of purchase for warranty claims.

Crosley Official Website: www.crosleyradio.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00JENX5WO

More documents and user manuals: **https://manuals.plus/**