## Microsoft 768522732990

# Microsoft 1045 Wireless Comfort Keyboard 1.0A User Manual

Model: 768522732990

## Introduction

This manual provides essential information for the setup, operation, and maintenance of your Microsoft 1045 Wireless Comfort Keyboard 1.0A. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

**Important Note:** This product includes the keyboard only. A wireless receiver, mouse, and batteries are **NOT** included and must be acquired separately for the keyboard to function.

## Setup Guide

Follow these steps to set up your Microsoft 1045 Wireless Comfort Keyboard 1.0A:

1. **Acquire Necessary Components:** Ensure you have the required wireless receiver (specifically, an Optical Desktop Receiver 3.0A, P/N x804357-002, PiD 75709-507-9459976-00713) and two AA batteries (not included).
2. **Install Batteries:**
   Locate the battery compartment on the underside of the keyboard. Open the compartment cover and insert two AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment. Close the cover securely.




*Image: Underside of the Microsoft 1045 Wireless Comfort Keyboard 1.0A. This view shows the battery compartment, which requires two AA batteries, and the product label with model information.*

3. **Connect Wireless Receiver:** Plug the compatible wireless receiver (Optical Desktop Receiver 3.0A) into an available USB port on your computer.
4. **Establish Connection:** The keyboard should automatically connect to the receiver. If not, refer to the troubleshooting section or the receiver's specific instructions for pairing.

## Operating Instructions

The Microsoft 1045 Wireless Comfort Keyboard 1.0A is designed for comfortable and efficient typing. Its ergonomic design helps reduce strain during extended use.




*Image: Top view of the Microsoft 1045 Wireless Comfort Keyboard 1.0A. This image highlights the ergonomic curved design, standard QWERTY layout, and dedicated media and function keys located above the main key area.*

- **Standard Typing:** Use the main QWERTY layout for standard text input.
- **Function Keys (F1-F12):** These keys perform various functions depending on the application or operating system. Some may have secondary functions accessible via the 'Fn' key (if present) or software configuration.
- **Media and Hot Keys:** The keyboard features dedicated keys for media control (play/pause, volume up/down, mute) and other common functions (e.g., My Favorites, Email, Web/Home, Calculator). Refer to your operating system's settings for customization options.
- **Numeric Keypad:** The dedicated numeric keypad on the right provides quick entry for numbers and mathematical operations.
- **Wireless Range:** The keyboard operates wirelessly within a typical range, which may vary based on environmental factors and interference. Ensure the keyboard is within reasonable proximity to the receiver for optimal performance.

## Maintenance

Proper maintenance ensures the longevity and performance of your keyboard:

- **Cleaning:**
  Regularly clean the keyboard surface and keys with a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Avoid excessive moisture and never submerge the keyboard in liquid.
  Use compressed air to remove dust and debris from between the keys.
- **Battery Replacement:**
  When the keyboard's performance degrades or it stops responding, it's likely time to replace the batteries. Follow the battery installation steps in the "Setup Guide" section. Always use fresh, high-quality AA batteries.
- **Storage:**
  When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. Consider removing batteries if storing for several months to prevent leakage.

## Troubleshooting

If you encounter issues with your keyboard, try the following troubleshooting steps:

- **Keyboard Not Responding:**
  - Ensure the batteries are correctly installed and not depleted. Replace them if necessary.
  - Verify that the wireless receiver is securely plugged into a working USB port on your computer.
  - Confirm that you are using the correct wireless receiver (Optical Desktop Receiver 3.0A, P/N x804357-002). This keyboard is not compatible with other receivers.
  - Move the keyboard closer to the receiver to rule out range issues or interference.
  - Try plugging the receiver into a different USB port.
  - Restart your computer.
- **Keys Not Working or Lagging:**
  - Check for debris under the affected keys and clean as described in the "Maintenance" section.
  - Ensure batteries are fresh.
  - Reduce potential wireless interference from other devices (e.g., Wi-Fi routers, cordless phones).
- **Unexpected Behavior:**
  - If the keyboard exhibits unusual behavior, try re-establishing the connection by unplugging and re-plugging the

receiver.

- Check your computer's device manager for any driver issues related to the keyboard or USB receiver.

If problems persist after trying these steps, it may indicate an issue with the keyboard or receiver itself. Remember, the wireless receiver is not included with this keyboard and must be the specific model mentioned.

## Specifications

| Feature | Detail |
|---|---|
| Model Number | 768522732990 |
| Product Dimensions | 18.5 x 8.6 x 1.1 inches |
| Item Weight | 10.1 ounces |
| Color | Black |
| Connectivity Technology | Wireless (requires USB receiver) |
| Compatible Devices | Personal Computer |
| Required Receiver | Optical Desktop Receiver 3.0A (P/N x804357-002) |
| Batteries Required | 2 x AA (not included) |
| Date First Available | April 5, 2014 |

## Warranty and Support

Specific warranty details and direct support contact information are not provided within this manual. For warranty claims, technical support, or further assistance, please refer to the official Microsoft website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

© 2024 Microsoft. All rights reserved. Microsoft and the Microsoft logo are trademarks of the Microsoft group of companies.

This manual is for informational purposes only. Specifications are subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**