Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Grey Pneumatic GRE927TT

Instruction Manual

Grey Pneumatic GRE927TT 1/4" Drive x Tt27 Tamper Proof Torx Driver

Model: GRE927TT

Product Overview

The Grey Pneumatic GRE927TT is a 1/4" drive Tt27 Tamper Proof Torx Driver designed for professional use. It is engineered to work effectively with impact tools, providing reliable performance and durability.
Key features include:

- Made from high quality chrome-molybdenum steel for superior strength.
- Heat treated for enhanced durability and longevity.
- Black oxide coated finish for excellent resistance against rust and corrosion.
- Size markings are hard stamped into the socket for clear and easy identification.



Image: The Grey Pneumatic GRE927TT 1/4" Drive x Tt27 Tamper Proof Torx Driver, showcasing its black oxide finish and stamped size marking.

Setup

The Grey Pneumatic GRE927TT Torx Driver is ready for immediate use upon unboxing. No assembly is required.

1. Ensure the driver is clean and free of any debris before use.
2. Select the appropriate 1/4" drive impact tool or ratchet.
3. Firmly attach the GRE927TT Torx Driver to the drive square of your tool. Ensure it is securely seated to prevent slippage during operation.

Operating Instructions

This Torx driver is designed for use with tamper-proof Torx fasteners. Always ensure the correct size (Tt27) is used for the fastener to prevent damage to both the fastener and the driver.

1. Identify the tamper-proof Torx fastener you intend to work with. Verify it requires a Tt27 size.
2. Attach the GRE927TT driver securely to your 1/4" drive impact tool or ratchet.
3. Align the tip of the Torx driver with the head of the fastener, ensuring the tamper-proof pin on the fastener aligns with the hole in the driver's tip.
4. Apply firm, steady pressure while rotating the tool to loosen or tighten the fastener. Avoid excessive force that could strip the fastener or damage the tool.
5. After use, remove the driver from the fastener and your tool.



Image: A close-up view of the Grey Pneumatic Torx Driver, highlighting the tamper-proof tip design.

Maintenance

Proper maintenance will extend the life of your Grey Pneumatic Torx Driver.

- **Cleaning:** After each use, wipe the driver clean with a dry cloth to remove any dirt, grease, or debris. For stubborn grime, a mild degreaser can be used, followed by thorough drying.
- **Storage:** Store the driver in a dry environment to prevent rust, ideally in a tool box or on a tool rack. Avoid storing in damp or corrosive conditions.
- **Inspection:** Periodically inspect the driver for any signs of wear, cracks, or damage to the drive end or the Torx tip. Discontinue use if significant damage is observed.
- **Lubrication:** No lubrication is typically required for this type of hand tool.

Troubleshooting

If you encounter issues while using your Grey Pneumatic Torx Driver, consider the following common solutions:

Problem	Possible Cause	Solution
Driver slips on fastener.	Incorrect size, worn fastener head, or insufficient pressure.	Ensure you are using the correct Tt27 size. Inspect the fastener head for damage. Apply firm, steady pressure while turning.
Driver appears bent or cracked.	Excessive force, improper use, or material fatigue.	Discontinue use immediately. The tool may be damaged beyond repair. Refer to warranty information.
Rust spots appearing on driver.	Exposure to moisture or corrosive substances.	Clean and dry the driver thoroughly. Store in a dry environment. Light surface rust can often be removed with fine steel wool and oil.

Specifications

Attribute	Detail
Brand	Grey Pneumatic
Model Number	GRE927TT
Drive Size	1/4 inch
Torx Size	Tt27 (Tamper Proof)
Material	Chrome Molybdenum Steel
Finish Type	Black Oxide Coated
Item Weight	0.48 ounces
Product Dimensions	13.3 x 2 x 1 inches
Power Source	Hand Powered
UPC	729440486235

Warranty Information

Grey Pneumatic offers a **Lifetime Warranty** on this product. This warranty covers defects in material and workmanship under normal use.
Please note: The lifetime warranty does not cover abuse, misuse, alteration, or normal wear and tear. For specific warranty claims or details, please contact Grey Pneumatic customer support.

Customer Support

For further assistance, technical support, or warranty claims, please contact Grey Pneumatic directly.

- **Manufacturer:** Grey Pneumatic
- **Website:** www.greypneumatic.com (Please visit the official website for the most current contact information.)
- **General Inquiries:** Refer to the contact section on the manufacturer's website.

When contacting support, please have your product model number (GRE927TT) and purchase details available.

© 2023 Grey Pneumatic. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00JNVOOBI

More documents and user manuals: **https://manuals.plus/**