Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SOGO SS-8460

SOGO SS-8460 PC Loudspeaker User Manual

Model: SS-8460

Introduction

This manual provides comprehensive instructions for the safe and efficient operation of your SOGO SS-8460 PC Loudspeaker. Please read this manual thoroughly before using the device and retain it for future reference.
The SOGO SS-8460 is a versatile portable loudspeaker designed for high-quality audio output, featuring 2x 5 Watt high-power speakers with excellent bass and treble. It offers multiple connectivity options including Bluetooth and NFC for seamless pairing with smartphones, tablets, and other music devices. An integrated microphone allows for hands-free calling, and a built-in flip stand provides stability for devices placed on top. Additionally, a 3.5mm AUX line-in port supports connection to external players like notebooks and MP3 players.

Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble, repair, or modify the device yourself. Refer all servicing to qualified personnel.
- Keep the device away from water and other liquids. While the product is indicated as waterproof, prolonged submersion or exposure to high-pressure water jets should be avoided.
- Use only the specified charging accessories.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure proper ventilation when operating the device.

Product Overview

Familiarize yourself with the components of your SOGO SS-8460 loudspeaker:



Figure 1: Front view of the SOGO SS-8460 PC Loudspeaker. This image displays the sleek black body with gold-colored end caps and a central circular SOGO logo. The speaker grille is visible across the front, indicating the audio output area. The overall design is compact and portable.

- **Speaker Grille:** Protects the internal speaker components and allows sound to pass through.
- **Control Panel/Buttons:** (Assumed, typically on top or side) For power, volume, play/pause, and mode selection.
- **Charging Port:** For connecting the power adapter to charge the internal battery.
- **AUX-in Port:** 3.5mm jack for wired audio connection.
- **Microphone:** For hands-free calling.
- **Flip Stand:** Integrated stand for holding smartphones or tablets.

Setup

1. Charging the Battery

Before first use, fully charge the loudspeaker. Connect the charging cable to the charging port on the device and the other end to a suitable USB power source (e.g., computer USB port or USB wall adapter). The charging indicator light will illuminate during charging and turn off or change color when fully charged. The device features a Li-Ion 1050 mAh battery.

2. Powering On/Off

Press and hold the Power button (location typically on the side or top) for a few seconds to turn the loudspeaker on or off. An audible prompt or indicator light will confirm the power status.

Operating Instructions

1. Bluetooth Pairing

1. Ensure the loudspeaker is powered on and in Bluetooth pairing mode (usually indicated by a flashing LED). If not, press the Mode button to switch to Bluetooth mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, enable Bluetooth and search for available devices.
3. Select "SOGO SS-8460" from the list of found devices.
4. Once paired, the loudspeaker will emit a confirmation sound, and the LED indicator will stop flashing.
5. You can now play audio from your device through the SOGO SS-8460 loudspeaker.

2. NFC (Near Field Communication) Pairing

For devices with NFC capability:

1. Ensure NFC is enabled on your smartphone or tablet.
2. Gently tap your NFC-enabled device against the NFC area on the loudspeaker (refer to product diagram for exact location, typically marked with an NFC logo).

3. Your device will automatically attempt to pair with the loudspeaker. Confirm the pairing prompt on your device if necessary.

3. AUX-in Mode

To connect devices without Bluetooth (e.g., MP3 players, older laptops):

1. Connect one end of a 3.5mm audio cable (not included) to the AUX-in port on the loudspeaker.
2. Connect the other end of the cable to the headphone jack or audio output port of your external device.
3. The loudspeaker should automatically switch to AUX mode, or you may need to press the Mode button to select AUX.

4. Hands-Free Calling

When connected via Bluetooth to a smartphone:

- **Answering a Call:** Press the Call/Play button (usually the same as Play/Pause) once to answer an incoming call.
- **Ending a Call:** Press the Call/Play button once to end an ongoing call.
- **Rejecting a Call:** Press and hold the Call/Play button for a few seconds to reject an incoming call.
- **Redialing:** Double-press the Call/Play button to redial the last number.

5. Using the Flip Stand

The integrated flip stand provides a stable base for placing your smartphone or tablet on top of the loudspeaker. Gently pull out the stand from its recess until it locks into position. Place your device securely in the groove of the stand.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the surface of the loudspeaker. Do not use liquid cleaners, aerosols, or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use.

Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the loudspeaker fully.
Cannot pair via Bluetooth	Loudspeaker not in pairing mode; Bluetooth disabled on source device; devices too far apart.	Ensure loudspeaker is in pairing mode. Enable Bluetooth on your device. Move devices closer (within 10 meters).
No sound	Volume too low; incorrect mode selected; AUX cable not fully inserted.	Increase volume on both loudspeaker and source device. Ensure correct mode (Bluetooth/AUX) is selected. Re-insert AUX cable firmly.
Poor sound quality	Interference; source audio quality is low; device too far from loudspeaker.	Move away from other electronic devices. Try a different audio source. Move devices closer.

Specifications

- **Model:** SS-8460
- **Power Output:** 2 x 5 Watts
- **Connectivity:** Bluetooth, NFC, 3.5mm AUX-in
- **Frequency Response:** 90 Hz ~ 20 kHz
- **Signal-to-Noise Ratio:** > 80 dB
- **Battery:** Li-Ion 1050 mAh
- **Dimensions:** Approximately 24 cm (L) x 6.5 cm (W) x 4.5 cm (H)
- **Weight:** Approximately 0.350 kg
- **Features:** Built-in microphone for calls, integrated flip stand for devices.
- **Waterproof:** Yes (as per product specifications, typically splash-proof for portable speakers)

Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or contact SOGO customer service. Specific warranty terms may vary by region and retailer.
Please visit the official SOGO website for the most up-to-date support resources and contact information.

© 2024 SOGO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00KA5S3HC

More documents and user manuals: **https://manuals.plus/**