Janome 4623LE, 6147, DE5124, MX3123, MC5500, MC6000, MC7000, MC7500

Janome Foot Control Instruction Manual

For Models: 4623LE, 6147, DE5124, MX3123, MC5500, MC6000, MC7000, MC7500

Introduction

This manual provides essential information for the proper use, installation, and maintenance of your new genuine Janome Foot Control. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.
The Janome Foot Control is designed to provide variable speed control for compatible Janome sewing machines, allowing for precise operation during sewing tasks.

Product Overview



Figure 1: The Janome Foot Control, showing the pedal unit and the integrated power cord with its connector.

The Janome Foot Control consists of a foot pedal and an attached power cord with a specific connector designed to interface with compatible Janome sewing machines. This unit serves as both the power supply and the speed control mechanism for your sewing machine.

Setup and Installation

Follow these steps to properly connect your Janome Foot Control to your sewing machine:

1. **Ensure Power is Off:** Before connecting the foot control, ensure your sewing machine's power switch is in the OFF position and the machine is unplugged from the wall outlet.
2. **Locate the Port:** Identify the power and foot control port on your Janome sewing machine. This is typically located on the side or back of the machine. Refer to your sewing machine's specific manual if you are unsure.
3. **Connect the Foot Control:** Align the connector of the Janome Foot Control's power cord with the corresponding port on your sewing machine. Gently push the connector firmly into the port until it is securely seated. Do not force the connection.
4. **Plug into Wall Outlet:** Once the foot control is securely connected to the sewing machine, plug the power cord's wall plug into a standard electrical outlet.
5. **Position the Pedal:** Place the foot pedal on the floor in a comfortable position where you can easily operate it with your foot while sewing.

Note: *This foot control is designed for specific Janome models. Using it with incompatible machines may result in damage to the foot control or the sewing machine.*

Operating Instructions

The Janome Foot Control allows you to control the sewing speed of your machine. Follow these guidelines for operation:

- **Power On:** After setup, turn on the power switch on your sewing machine.
- **Start Sewing:** Gently press down on the foot pedal with your foot. The machine will begin to sew.
- **Control Speed:** The harder you press down on the pedal, the faster the sewing machine will operate. To slow down, ease up on the pressure. To stop, completely release the pedal.
- **Practice:** If you are new to using a foot control, practice pressing and releasing the pedal to get a feel for the speed control before starting a project.

Maintenance

Proper care will extend the life of your Janome Foot Control:

- **Cleaning:** Wipe the exterior of the foot control with a soft, dry cloth. Do not use liquid cleaners or immerse the unit in water.
- **Cord Care:** Avoid kinking, twisting, or placing heavy objects on the power cord. Store the cord neatly when not in use.
- **Storage:** Store the foot control in a clean, dry place, away from extreme temperatures and direct sunlight.
- **Inspection:** Periodically inspect the cord and plug for any signs of damage, such as fraying or exposed wires. If damage is found, discontinue use immediately and seek professional repair or replacement.

Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on or sew.	Foot control not properly connected; power outlet issue; machine power switch off.	Ensure foot control connector is fully inserted. Check wall outlet with another appliance. Turn sewing machine power switch ON.
Machine sews erratically or at incorrect speed.	Loose connection; internal issue with foot control or machine.	Check foot control connection. If problem persists, the foot control may need replacement or the sewing machine may require service.
Foot control feels hot during use.	Normal operation (slight warmth); prolonged heavy use; internal fault.	A slight warmth is normal. If it becomes excessively hot or emits a burning smell, unplug immediately and discontinue use. Seek professional assistance.

Specifications

Product Type: Genuine Janome Foot Control

Compatible Models: Janome 4623LE, 6147, DE5124, MX3123, MC5500, MC6000, MC7000, MC7500

Package Dimensions: 6.8 x 5.6 x 1.9 inches

Item Weight: 1.15 pounds

ASIN: B00KCWATHU

Batteries Required: No

Warranty and Support

For warranty information or technical support regarding your Janome Foot Control, please refer to the documentation provided with your original sewing machine or contact Janome customer service directly. You can often find support contact details on the official Janome website or through your authorized Janome dealer.
For additional resources, you may visit the Janome Store on Amazon.

© 2025 Janome. All rights reserved.