Bosch WTE84107EE

Bosch WTE84107EE Condenser Dryer

Instruction Manual

Introduction

Thank you for choosing the Bosch WTE84107EE Condenser Dryer. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read these instructions carefully before using the dryer and keep them for future reference.

Safety Instructions

- Always ensure the appliance is properly grounded.
- Do not allow children to play with or operate the dryer.
- Never block the ventilation openings of the dryer.
- Do not dry items that have been soiled with flammable substances.
- Unplug the appliance before cleaning or maintenance.

Setup

Unpacking

Carefully remove the dryer from its packaging. Inspect the appliance for any transport damage. Keep packaging materials out of reach of children.

Placement

Place the dryer on a clean, level, and stable surface. Ensure there is adequate ventilation around the appliance. The anti-vibration panels help reduce noise during operation.



Image showing the front of the Bosch WTE84107EE condenser dryer, highlighting its compact design and control panel.

Electrical Connection

Connect the dryer to a properly installed and grounded power outlet. Ensure the voltage and frequency match the specifications on the appliance's rating plate.

Drainage Connection

The Bosch WTE84107EE offers the possibility of direct drainage connection. A drainage hose is included for this purpose. Connect the hose to the designated outlet on the dryer and route it to a suitable drain, ensuring there are no kinks. If not using direct drainage, the condensate will collect in the reservoir.

Operating Instructions

Control Panel Overview

Familiarize yourself with the control panel, which typically includes a program selector dial, start/pause button, and

indicator lights for program status, emptying the condensate reservoir, and cleaning the lint filter.

Loading Laundry

Open the front-loading door and load the laundry into the drum. Do not overload the dryer; ensure clothes can tumble freely. Close the door securely. The dryer has a capacity of 7 kg.

Selecting a Program

Turn the program selector dial to choose the appropriate drying program for your laundry type. Special programs include:

- **Sport:** For sportswear and synthetic fabrics.
- **Timed Warm 20 min:** A quick 20-minute warm drying cycle.
- **Quick 40 min:** A rapid 40-minute drying cycle for small loads.

Special Functions

Press the relevant button to activate special functions such as**Gentle Drying** for delicate items.

Starting the Drying Cycle

Once the program and any desired functions are selected, press the Start/Pause button to begin the drying cycle.

End of Program

The dryer will signal the end of the program with an audible alert and/or an indicator light. A special 120-minute anti-crease cooling cycle automatically activates after the program finishes to minimize wrinkles if laundry is not removed immediately.

Maintenance

Cleaning the Lint Filter

After each drying cycle, the "Clean Filter" indicator light will illuminate. Open the door and remove the lint filter. Clean it thoroughly under running water or with a soft brush to ensure optimal drying performance and prevent fire hazards. Reinsert the clean filter.

Emptying the Condensate Container

If you are not using the direct drainage option, the "Empty Reservoir" indicator light will illuminate when the condensate container is full. Pull out the container and empty the collected water. Reinsert the container securely.

Cleaning the Appliance

Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents. Periodically clean the heat exchanger according to the instructions in the full user manual (not provided here).

Troubleshooting

Before contacting customer service, please refer to the following common issues and their solutions:

- **Dryer not starting:** Check if the power plug is inserted correctly, the door is fully closed, and a program has been selected.
- **Poor drying results:** Ensure the lint filter is clean, the condensate container is empty (if applicable), and the load size is appropriate for the selected program.
- **Unusual noises:** Check for foreign objects in the drum or filter area. Ensure the dryer is level.

- **Indicator lights remain on:** Refer to the specific indicator light in the operating section for its meaning (e.g., "Clean Filter," "Empty Reservoir").

Specifications

Model Number:	WTE84107EE
Brand:	Bosch
Type:	Condenser Dryer
Capacity:	7 kg
Dimensions (W x D x H):	59.8 x 63.9 x 84.2 cm
Weight:	1 kg (Product weight, likely shipping weight is higher)
Loading Type:	Front-loading
Color:	White
Special Features:	Anti-vibration panels, Drainage connection option

Warranty Information

This Bosch WTE84107EE Condenser Dryer comes with a product warranty. Please refer to your purchase documentation or the official Bosch website for detailed terms and conditions regarding the warranty period and coverage. Typically, Bosch appliances offer a 3-year warranty.

Customer Support

For further assistance, technical support, or to schedule a service appointment, please contact Bosch Customer Service. You can find contact details on the official Bosch website or in your appliance documentation. When contacting support, please have your model number (WTE84107EE) and serial number ready.

Online Resources: Visit the official Bosch website for FAQs, additional manuals, and product registration.

© 2024 Bosch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question