Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj ICX-3

Bajaj Glass Majesty ICX-3 1400W Induction Cooktop User Manual

Model: ICX-3 | Brand: Bajaj

1. Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Bajaj Glass Majesty ICX-3 1400W Induction Cooktop. Please read this manual thoroughly before using the appliance and retain it for future reference.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. This appliance is for household use only.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the power supply voltage matches the rating label on the appliance (23V operating voltage).
- Do not operate the appliance with a damaged cord or plug. Contact customer service for repairs.
- Place the cooktop on a stable, flat, heat-resistant surface, away from flammable materials.
- Ensure adequate ventilation around the appliance. Do not block air vents.
- Use only induction-compatible cookware. Non-compatible cookware will not heat.
- The cooking surface remains hot after use. Do not touch it immediately.
- Keep children away from the appliance during operation and cooling.
- Do not place metallic objects like knives, forks, spoons, or lids on the induction surface as they can become hot.
- Individuals with pacemakers or similar medical devices should consult their doctor before using an induction cooktop.

3. Product Overview

The Bajaj Glass Majesty ICX-3 Induction Cooktop features a sleek glass surface and intuitive controls for various cooking needs.



Figure 1: Bajaj Glass Majesty ICX-3 1400W Induction Cooktop. This image shows the top-down view of the induction cooktop with its black glass surface and control panel at the bottom.

Control Panel Features:



Figure 2: Close-up view of the control panel. This image highlights the various touch controls and the digital display on the cooktop.

- **Power On/Off:** To switch the appliance on or off.
- **Pre-set/Timer:** To set a cooking timer or select pre-programmed cooking functions.
- **Up/Down Buttons:** To adjust power levels, temperature, or timer settings.
- **Cooking Modes:** Dedicated buttons for specific cooking functions such as Deep Fry, Pressure Cook, Heat Milk, Rice, Water, and Curry.
- **Digital Display:** Shows power level, temperature, or remaining time.

4. Setup

1. **Unpacking:** Carefully remove the induction cooktop from its packaging. Retain packaging for storage or transport.
2. **Placement:** Place the cooktop on a dry, stable, and level surface. Ensure there is at least 10-15 cm of clear space around the sides and back for proper ventilation. Do not place it near heat sources or on metallic surfaces.
3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the outlet meets the appliance's power requirements (23V).
4. **Compatible Cookware:** Use only induction-compatible cookware. These typically have a flat bottom and are made of ferromagnetic materials like cast iron, enameled iron, or stainless steel with a magnetic base. A simple magnet test can confirm compatibility: if a magnet sticks to the bottom of your pot, it is compatible.

5. Operating Instructions

Follow these steps for safe and effective cooking with your induction cooktop.



Figure 3: The Bajaj Induction Cooktop being used in a kitchen environment, demonstrating its integration into daily cooking.

1. **Power On:** Plug in the cooktop. Press the 'Power On/Off' button. The digital display will light up.
2. **Place Cookware:** Place an induction-compatible pot or pan centrally on the cooking zone. The cooktop

features a Pan Sensor that detects the presence of suitable cookware. If no cookware is detected or if it's incompatible, an error message may appear, and the cooktop will not heat.

3. **Select Cooking Mode:** Choose a desired cooking mode by pressing one of the dedicated function buttons (e.g., Deep Fry, Rice, Curry). Each mode has a default power or temperature setting.
4. **Adjust Settings:** Use the 'Up' and 'Down' buttons to adjust the power level or temperature as needed for your recipe. The digital display will show the current setting.
5. **Using the Timer:** Press the 'Pre-set/Timer' button, then use the 'Up' and 'Down' buttons to set the desired cooking time. The cooktop will automatically switch off once the timer expires.
6. **Pro Voltage Technology:** This feature helps protect the appliance from voltage fluctuations, ensuring stable operation and extending product life.
7. **Power Off:** After cooking, press the 'Power On/Off' button to turn off the cooktop. Unplug the appliance from the power outlet when not in use.

Note: The cooling fan may continue to operate for a short period after the cooktop is turned off to dissipate residual heat. This is normal.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your induction cooktop.

- Always unplug the cooktop and allow it to cool completely before cleaning.
- **Glass Surface:** Wipe the glass surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for glass cooktops. Rinse with a clean, damp cloth and dry thoroughly.
- **Body:** Clean the exterior body with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals.
- **Ventilation Vents:** Ensure the air intake and exhaust vents are free from dust and debris. Use a soft brush or vacuum cleaner to gently clean them.
- Do not immerse the cooktop in water or spray water directly onto it.

7. Troubleshooting

If you encounter issues with your Bajaj Glass Majesty ICX-3 Induction Cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; loose plug.	Check if the power cord is securely plugged in. Verify the power outlet is functional.
Cooktop turns on but does not heat.	Incompatible cookware; no cookware detected; cookware not centered.	Use induction-compatible cookware. Ensure the pot is centered on the cooking zone.
Error code displayed (e.g., E0, E1).	Overheating; internal fault; voltage issue.	Turn off the cooktop, unplug it, and let it cool down. Check for proper ventilation. If the issue persists, contact customer service.

Problem	Possible Cause	Solution
Unusual noise during operation.	Normal fan operation; resonance from cookware.	A slight humming sound from the cooling fan is normal. Some cookware may produce a faint buzzing sound due to induction.

For issues not listed here or if problems persist, please contact Bajaj customer support.

8. Specifications

Detailed technical specifications for the Bajaj Glass Majesty ICX-3 Induction Cooktop:



Figure 4: Dimensions of the Bajaj ICX-3 Induction Cooktop, showing its length and width.

- **Model:** ICX-3
- **Item Model Number:** 740054
- **Power:** 1400 Watts
- **Operating Voltage:** 23 Volts
- **Power Input:** 22 - 24 V
- **Heating Elements:** 1
- **Color:** Black
- **Item Weight:** 1 kg 800 g
- **Item Dimensions (LxWxH):** 34.5 x 38.5 x 34.5 Centimeters
- **Special Features:** Pan Sensor, Pro Voltage Technology
- **Included Components:** Induction Cooktop, User Manual, Customer Care List, Guarantee Card
- **Country of Origin:** India

9. Warranty and Customer Support

Your Bajaj Glass Majesty ICX-3 Induction Cooktop comes with a standard manufacturer's warranty. Please refer to the included Guarantee Card for specific terms and conditions.

Customer Support:

For any product-related queries, service requests, or technical assistance, please contact Bajaj customer care:

- **Contact Number:** 18125963

Manufacturer and Importer Information:

- **Manufacturer:** Bajaj
- **Packer:** M/s Colossus Appliances, Plot No 2, Opp ESIS Hospital, NH 22, Sector 1, Parwanoo- 173220, HP, India
- **Importer:** Imported and Marketed by Bajaj Electricals Ltd 45/47, Veer Nariman Road, Mumbai, 400001

© 2024 Bajaj Electricals Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00KW115E2

More documents and user manuals: **https://manuals.plus/**