Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Comfort Glow CEH255

Comfort Glow CEH255 Oscillating Ceramic Safety Furnace User Manual

Introduction

This manual provides essential information for the safe and efficient operation of your Comfort Glow CEH255 Oscillating Ceramic Safety Furnace. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Information

For your safety, this appliance is equipped with an overheat/tip-over shut-off feature. Always ensure the heater is placed on a stable, level surface. Do not cover the heater or block its air intake/outlet. Keep flammable materials at least 3 feet (0.9 meters) away from the front, sides, and rear of the heater. Do not use in wet or moist locations. Always unplug the heater when not in use.

Product Features

- Adjustable thermostat: Allows precise temperature control.
- 750/1500 watt power selections: Provides flexible heating options.
- Fan only setting: Circulates air without heat.
- Overheat/tip-over shut-off: Enhances safety by automatically turning off the unit if it overheats or tips over.
- Oscillates to provide a wide heating area: Distributes warmth evenly across a room.
- Heating coverage: Up to 400 square feet.

Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for storage.
2. **Placement:** Place the heater on a firm, level surface. Ensure there are no obstructions to the air intake or outlet. Maintain a minimum clearance of 3 feet (0.9 meters) from walls, furniture, and other objects.
3. **Power Connection:** Plug the power cord directly into a 120V AC, 60Hz grounded wall outlet. Do not use extension cords or power strips.




Comfort Glow

Figure 1: Front view of the Comfort Glow CEH255 Oscillating Ceramic Safety Furnace. This image displays the heater's front grille and overall compact design.

Operating Instructions

1. **Power On:** Turn the POWER knob to select your desired power setting: OFF, FAN, LOW (750W), or HIGH (1500W). The power indicator light will illuminate.
2. **Adjust Thermostat:** Turn the THERMOSTAT knob to your desired temperature setting. The heater will cycle on and off to maintain the set temperature.
3. **Oscillation:** To activate the oscillation feature, locate the oscillation switch (if present, typically on the base or top panel) and turn it ON. The heater will begin to rotate, distributing heat across a wider area.
4. **Fan Only Mode:** Select the FAN setting on the POWER knob to use the unit as a fan without heat.
5. **Power Off:** Turn the POWER knob to the OFF position and unplug the unit from the wall outlet when not in use.



Figure 2: Close-up view of the top control panel. This image highlights the POWER and THERMOSTAT knobs, along with the power indicator light, for easy operation.

Maintenance

Always unplug the heater and allow it to cool completely before performing any maintenance.

- **Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents. Ensure no water enters the interior of the heater.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment to gently remove dust from the air intake and outlet grilles.
- **Storage:** When not in use, store the heater in a cool, dry place, preferably in its original packaging.

Troubleshooting

- **Heater does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the POWER knob is set to an ON position (FAN, LOW, or HIGH).
  - Verify that the thermostat is set to a temperature higher than the current room temperature.
  - Check your home's circuit breaker or fuse box.
- **Heater turns off unexpectedly:**
  - The tip-over switch may have been activated. Place the heater on a firm, level surface.
  - The overheat protection may have been activated. Unplug the heater, allow it to cool for 10-15 minutes, and ensure air intake/outlet are not blocked.
- **Reduced heat output:**
  - Ensure the heater is set to the HIGH (1500W) power setting for maximum heat.
  - Clean any dust or debris from the air grilles.

Specifications

Feature	Detail
Brand	Comfort Glow
Model Name	CEH255
Special Feature	Adjustable Temperature, Oscillating, Overheat Protection, Tip-Over Protection
Color	No Color
Form Factor	Tower
Indoor/Outdoor Usage	Indoor
Product Dimensions	5"D x 6"W x 10.5"H
Recommended Uses	Home, Office
Heating Coverage	400 Sq.ft.
Fuel Type	Electric
Voltage	120 Volts
Amperage	12.5 Amps
Max Temperature Setting	80 Degrees Fahrenheit

Material	Plastic
Manufacturer	World Marketing



Figure 3: Dimensional view of the Comfort Glow CEH255. This image provides key measurements for product placement and understanding its compact size.

Warranty and Support

This Comfort Glow CEH255 Oscillating Ceramic Safety Furnace comes with a manufacturer's warranty. Please refer to the product packaging or contact Comfort Glow customer service for detailed warranty information and support. Keep your purchase receipt as proof of purchase.
For customer support, please visit the official Comfort Glow website or contact their customer service line. Contact information can typically be found on the product packaging or the brand's official website.

© 2023 Comfort Glow. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00KW9CUE8

More documents and user manuals: **https://manuals.plus/**