Bosch MES25G0

Bosch VitaJuice 2 MES25G0 Electric Juicer User Manual

Model: MES25G0

1. Introduction

This user manual provides essential information for the safe and efficient operation, maintenance, and care of your Bosch VitaJuice 2 MES25G0 electric juicer. Please read these instructions carefully before first use and keep them for future reference.



Image 1: Bosch VitaJuice 2 MES25G0 Electric Juicer and its 1.25L juice container.

2. Safety Instructions

Always observe the following safety precautions to prevent injury or damage to the appliance:

- Ensure the appliance is correctly assembled before switching it on. The motor will only run when all parts are securely in place.
- Do not open the appliance during operation. The safety stop feature automatically turns off the device if opened during use.
- Keep hands and utensils away from the feeding chute and moving parts during operation. Use the pusher provided.
- Always unplug the appliance from the power supply before cleaning or if left unattended.
- Do not immerse the motor unit in water or other liquids.
- This appliance is for household use only.

3. Parts Overview

Familiarize yourself with the components of your juicer:

1. Motor Unit (Base)
2. Pulp Container (2L capacity)
3. Juice Collection Container (1.25L capacity with foam separation)

4. Lid with Feeding Chute
5. Pusher
6. Stainless Steel Microfilter Strainer
7. Spout with DripStop function
8. Control Dial (O/off, 1, 2)
9. Cleaning Brush



Image 2: Key components including the large feeding chute, stainless steel microfilter, and speed control.

4. Setup

Before first use, clean all removable parts as described in the "Maintenance" section. Assemble the juicer as follows:

1. Place the motor unit on a stable, flat surface.
2. Insert the pulp container into its designated slot on the motor unit.
3. Place the juice collection container under the spout.
4. Position the stainless steel microfilter strainer securely onto the motor unit.
5. Place the lid with the feeding chute over the strainer and secure it with the aluminium sealing bracket.

Ensure it clicks into place.

6. Insert the pusher into the feeding chute.
7. Plug the appliance into a suitable power outlet.

5. Operating Instructions

Follow these steps to juice fruits and vegetables:

1. Prepare your fruits and vegetables. Thanks to the extra-large 73mm feeding chute, many whole fruits like apples can be juiced without pre-cutting.



Image 3: The large 73mm feeding chute accommodates whole fruits.

2. Ensure the juice collection container is positioned correctly under the spout.
3. Turn the control dial to the desired speed setting:
    - **Speed 1:** For soft fruits and vegetables (e.g., berries, tomatoes, grapes).
    - **Speed 2:** For hard fruits and vegetables (e.g., apples, carrots, celery).



Image 4: Control dial for selecting speed settings based on produce hardness.

4. Gradually feed the prepared produce into the feeding chute. Use the pusher to gently guide the produce down. Do not force it.
5. Once juicing is complete, turn the control dial to "O/off" to switch off the appliance.
6. Use the DripStop function on the spout to prevent any remaining juice from dripping onto your work surface.



Image 5: The juicer is suitable for a wide variety of fruits and vegetables.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your juicer.

1. Before cleaning, always switch off the appliance and unplug it from the power outlet.
2. Disassemble the juicer by removing the pusher, lid, strainer, pulp container, and juice collection container.
3. All removable parts are dishwasher safe. Alternatively, wash them by hand using warm soapy water and rinse thoroughly.



Image 6: Many parts of the juicer are dishwasher safe for easy cleaning.

4. Use the included cleaning brush to thoroughly clean the stainless steel microfilter strainer. This helps remove pulp residue and maintain juicing efficiency.
5. Wipe the motor unit with a damp cloth. Never immerse the motor unit in water.
6. Allow all parts to dry completely before reassembling or storing the appliance.

7. Troubleshooting

If you encounter issues with your juicer, refer to the following common solutions:

- **Appliance does not turn on:**
  - Check if the power cord is securely plugged into the outlet.
  - Ensure all parts are correctly assembled and the safety locking mechanism is engaged.
- **Low juice yield or excessive pulp:**
  - Clean the microfilter strainer thoroughly, as clogged pores can reduce efficiency.
  - Ensure you are using the correct speed setting for the type of produce (Speed 2 for harder items).
  - Feed produce slowly and gently, allowing the juicer to process it effectively.
- **Appliance stops during operation:**
  - This may be due to the safety stop mechanism if a part became loose. Reassemble and restart.

- The motor may have overheated due to continuous heavy use. Turn off, unplug, and let it cool down for 30 minutes before resuming.

8. Specifications

Brand	Bosch
Model Number	MES25G0
Power / Wattage	700 Watts
Voltage	220 Volts
Capacity (Juice Container)	1.25 Litres
Capacity (Pulp Container)	2 Litres
Number of Speeds	2
Material	Stainless Steel (Microfilter)
Product Dimensions	Approximately 31 cm (W) x 31.2 cm (H) x 17.3 cm (D); 5 kg
Dishwasher Safe Parts	Yes (removable parts)



Image 7: Dimensions of the Bosch VitaJuice 2 MES25G0 juicer.

9. Warranty and Support

For warranty information, product registration, or technical support, please refer to the official Bosch website or contact their customer service department. Keep your proof of purchase for warranty claims.
You can find more information and contact details on the official Bosch website: www.bosch-home.com

© 2023 Bosch. All rights reserved.