Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BOSCH 059129

Bosch Freezer Compartment Door Handle (Model 059129) Instruction Manual

Genuine Replacement Part for Bosch Freezers

1. Introduction

This instruction manual provides essential information for the safe and correct installation, operation, and maintenance of your Bosch Freezer Compartment Door Handle, Model 059129. This is a genuine Bosch replacement part designed to restore the functionality and appearance of your freezer compartment door.

Compatibility: This handle is suitable for a wide range of Bosch freezer models. Please verify your appliance's model number against the list below or consult your appliance's original documentation to ensure compatibility:

- KDL1955GB/52, KDL1955GB/53, KDL1956GB/52, KDL1956GB/53, KDL1958GB/52, KDL1959GB/52
- KIL2332/01, KIL2332CH/01, KIL2332FF/01, KIL2332SD/01, KIL2335/01, KIL2335CH/01, KIL2335SD/01, KIL2337GB/01, KIL2337GB/02, KIL2374GB/31
- KIL2440GB/31, KIL2440GB/33, KIL2440GB/34, KIL2440GB/35, KIL2440GB/36, KIL24440GB/01, KIL24440GB/02, KIL24440GB/03, KIL24443GB/01, KIL24443GB/02
- KIR1830/01, KIR18301/01, KIR18305/01, KIR18308/01
- KTL1444GB/41, KTL1444GB/42, KTL1444GB/43, KTL1501GB/01, KTL1501GB/02, KTL1501GB/03, KTL1502GB/01, KTL1502GB/02, KTL1502GB/44, KTL1502GB/45, KTL1503GB/41
- KTL1542/01, KTL1542/02, KTL15420/01, KTL15420/02, KTL15420/03, KTL15420CH/01, KTL15420CH/02, KTL15420FF/01, KTL15420GB/01, KTL15420GB/02, KTL15421/02, KTL15421CH/02, KTL15421FF/02, KTL15423GB/01, KTL15423GB/02, KTL15424GB/01, KTL15425GB/01, KTL1542SD/01
- KTL1572GB/01, KTL1572GB/02, KTL1572GB/03, KTL1572GB/04, KTL1572GB/43, KTL1572GB/45, KTL1572GB/46, KTL1572GB/47, KTL15V20/01, KTL15V20/02, KTL15V20GB/01, KTL15V20GB/02, KTL15V21GB/01, KTL15V21GB/02, KTL15V22GB/01
- KTL16420/01, KTL16420/02, KTL16420/03, KTL16420/04, KTL16420GB/01, KTL16420GB/02, KTL16420GB/03, KTL16420GB/04, KTL16421/01, KTL16424GB/01
- KTL1740GB/01, KTL1740GB/02, KTL1741GB/01, KTL1741GB/02, KTL1742GB/01, KTL1742GB/02, KTL1743GB/01, KTL1743GB/02

2. Safety Information

Always prioritize safety when performing any maintenance or repair on an appliance. Failure to follow these safety guidelines may result in injury or damage to the appliance.

- **Disconnect Power:** Before attempting any installation or replacement, always unplug the freezer from the electrical outlet

to prevent electric shock.

- **Wear Protective Gear:** Consider wearing gloves to protect your hands from sharp edges or components.
- **Handle with Care:** The replacement part is made of plastic. Avoid excessive force during installation to prevent breakage.
- **Professional Assistance:** If you are unsure about any step or uncomfortable performing the replacement, contact a qualified appliance technician.

3. Package Contents

Your package should contain the following genuine Bosch components:

- 1 x Bosch Freezer Compartment Door Handle (White, Model 059129)
- 1 x Retaining Clip (translucent plastic)



Figure 1: An image showing the white plastic Bosch freezer compartment door handle and its translucent retaining clip, ready for installation.

4. Installation Instructions

Follow these steps carefully to replace the freezer compartment door handle.

1. **Prepare the Appliance:** Ensure the freezer is unplugged from the power supply. Open the freezer door to access the compartment with the broken handle.
2. **Remove Old Handle (if applicable):** If parts of the old handle or clip remain, carefully remove them. This may involve gently prying off broken plastic pieces. Note how the old handle was attached to understand the mechanism.
3. **Identify Attachment Points:** Locate the two small slots or holes on the freezer compartment door where the handle's retaining clip will attach.

4. **Attach Retaining Clip:** Take the translucent plastic retaining clip. Align its small tabs with the slots on the freezer door. Gently push the clip into place until it clicks securely. Ensure it is flush with the door surface.
5. **Install New Handle:** Take the new white plastic handle. Align the handle's internal grooves with the installed retaining clip.
6. **Secure the Handle:** Apply gentle, even pressure to the handle, pushing it firmly onto the retaining clip until it snaps into place. You should hear a click, and the handle should feel secure and not wobble.
7. **Test Functionality:** Gently pull on the newly installed handle to ensure it is firmly attached and operates correctly.
8. **Restore Power:** Once the handle is securely installed, plug the freezer back into the electrical outlet.

5. Operating Instructions

The Bosch Freezer Compartment Door Handle is designed for straightforward operation. Simply grasp the handle and pull gently to open the freezer compartment door. Push the door closed until it seals properly.

6. Maintenance

To ensure the longevity and cleanliness of your handle:

- **Cleaning:** Wipe the handle regularly with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents, as these can damage the plastic finish.
- **Inspection:** Periodically check the handle for any signs of looseness or damage. If the handle becomes loose, gently press it back into place.

7. Troubleshooting

If you encounter issues with your new handle, consider the following:

Problem	Possible Cause	Solution
Handle feels loose or wobbly.	Handle not fully seated on the retaining clip.	Apply firm, even pressure to the handle until it clicks securely into place.
Handle does not attach.	Retaining clip not installed correctly or damaged.	Ensure the retaining clip is correctly aligned and fully inserted into the door slots. Inspect the clip for damage.
Door does not open easily.	This issue is unlikely to be caused by the handle itself.	Check for ice buildup around the door seal or issues with the door hinge.

8. Specifications

Feature	Detail
Brand	Bosch
Model Number	059129
Part Number	5054127788285
Material	Plastic
Color	White (Weiß)
Product Dimensions	12 x 7 x 2 cm

Feature	Detail
Item Weight	18.1 g
Item Package Quantity	1
Number of Pieces	2 (Handle and Retaining Clip)
Specific Use	Freezer Compartment Door

9. Warranty and Support

As a genuine Bosch product, this replacement part is manufactured to high-quality standards. For specific warranty information, please refer to the original documentation of your Bosch appliance or contact Bosch customer support directly.

For further assistance or to purchase other genuine Bosch parts, please visit the official Bosch Home Appliances Store or contact your local Bosch service center.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00L7ZEQA2

More documents and user manuals: **https://manuals.plus/**