Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj MK14463680014

Bajaj Majesty New RCX 7 Multifunction Cooker

Model: MK14463680014

Introduction

Thank you for purchasing the Bajaj Majesty New RCX 7 Multifunction Cooker. This appliance is designed for efficient and convenient cooking of rice, pasta, and other dishes. Please read this instruction manual carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.

Important Safety Instructions

- Always ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Use only accessories recommended by the manufacturer.
- Always unplug the appliance from the power outlet when not in use and before cleaning.
- Avoid touching hot surfaces. Use handles or knobs.
- Ensure proper ventilation around the appliance during operation.
- This appliance is for household use only.

Product Overview

The Bajaj Majesty New RCX 7 Multifunction Cooker is a versatile appliance designed to simplify your cooking. It features a durable cooking bowl, a steamer for healthy cooking, and essential accessories for ease of use.



Image: Bajaj Majesty New RCX 7 Multifunction Cooker. This image displays the cooker with its lid, showing the main body and the included accessories.

Included Components:

- Cooking Bowl
- Instruction Manual
- Spatula
- Measuring Cup
- Trivet (Steamer)

Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and accessories.
2. **Clean:** Wash the cooking bowl, lid, spatula, measuring cup, and steamer with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the cooker on a stable, flat, heat-resistant surface, away from water and direct heat sources. Ensure adequate ventilation.
4. **Initial Burn-in (Optional):** For first-time use, you may run a cycle with just water to eliminate any manufacturing odors. Fill the cooking bowl with water up to the halfway mark, close the lid, and turn on the cooker. Let it boil for 10-15 minutes, then turn off and discard the water.

Operating Instructions

Cooking Rice:

1. Measure the desired amount of rice using the provided measuring cup. Rinse the rice thoroughly until the water runs clear.
2. Place the rinsed rice into the cooking bowl.
3. Add the appropriate amount of water. A general guideline is 1.5 to 2 cups of water for every 1 cup of rice, but this may vary based on rice type. Refer to rice packaging for specific ratios.

4. Place the cooking bowl into the main unit and ensure it is seated correctly.
5. Close the lid securely.
6. Plug the power cord into a suitable electrical outlet.
7. Press the 'Cook' switch or button. The 'Cook' indicator light will illuminate.
8. Once the rice is cooked, the cooker will automatically switch to 'Warm' mode, and the 'Warm' indicator light will illuminate.
9. Allow the rice to rest in 'Warm' mode for 10-15 minutes before serving for best results.
10. Unplug the cooker after use.

Using the Steamer:

1. Add water to the cooking bowl (ensure it does not exceed the maximum fill line for steaming).
2. Place the trivet (steamer tray) into the cooking bowl.
3. Arrange the food to be steamed (e.g., vegetables, dumplings) on the steamer tray.
4. Close the lid securely.
5. Plug in the cooker and press the 'Cook' switch.
6. Steam for the recommended time for your food. Monitor the water level to prevent boiling dry.
7. Once steaming is complete, switch off and unplug the cooker. Carefully remove the lid, avoiding steam.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your multifunction cooker.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Cooking Bowl and Accessories:** The cooking bowl, lid, spatula, measuring cup, and steamer are dishwasher safe or can be hand washed with warm, soapy water. Rinse thoroughly and dry completely.
- **Exterior:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water.
- **Storage:** Ensure all parts are clean and dry before storing. Store the cooker in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; check household circuit breaker; try a different outlet.
Rice is undercooked or hard.	Insufficient water; lid not sealed properly.	Add more water next time; ensure lid is closed tightly.
Rice is overcooked or mushy.	Too much water.	Reduce water amount next time.
Water overflows during cooking.	Too much water; cooking too much rice.	Ensure water and rice levels are within recommended limits.
Cooker does not switch to 'Warm' mode.	Malfunction.	Unplug and contact customer support.

Technical Specifications

Feature	Specification
Brand	Bajaj
Model Number	MK14463680014
Capacity	1.8 litres (Raw rice cooking capacity)
Wattage	550 Watts
Voltage	230 Volts
Power Source	Corded Electric
Lid Material	Stainless Steel
Item Weight	2.5 kg
Product Care Instructions	Hand Wash
Colour	Light Blue

Warranty and Customer Support

For warranty information, service, or support, please refer to the warranty card included with your product or contact Bajaj customer service. Keep your purchase receipt as proof of purchase for any warranty claims.
You can typically find contact details for customer support on the official Bajaj website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00LMA6COK

More documents and user manuals: **https://manuals.plus/**