Epson C11CE33201

Epson Workforce WF-2660 All-in-One Wireless Color Printer User Manual

Model: WF-2660 (C11CE33201)

Product Overview

The Epson Workforce WF-2660 is a versatile all-in-one wireless color printer designed for home and small office use. Powered by Precision Core technology, it offers printing, scanning, copying, and faxing capabilities. Key features include wireless connectivity, NFC (Near Field Communication) for touch-to-print functionality, fast laser-quality prints, a 150-sheet paper capacity, automatic two-sided printing, and a 2.7-inch color touchscreen for easy navigation. This printer is engineered to work exclusively with genuine Epson-brand ink cartridges to ensure optimal performance and reliability.



Front view of the Epson Workforce WF-2660 All-in-One Wireless Color Printer, showcasing its compact design and control panel.

Setup Guide

1. Unpacking and Initial Placement

Carefully remove the printer from its packaging. Ensure all protective tapes and packing materials are removed from the exterior and interior of the printer. Place the printer on a stable, flat surface with adequate space around it for ventilation and paper handling.

2. Power Connection

Connect the power cord to the printer's power input and then to a grounded electrical outlet. Do not connect the printer to your computer yet.

3. Ink Cartridge Installation

Open the ink cartridge cover. Gently shake each ink cartridge before unwrapping it. Insert each cartridge into its corresponding color slot until it clicks into place. Close the ink cartridge cover. The printer will begin an initial charging process, which may take several minutes.



View of the ink cartridge compartment with individual black, cyan, magenta, and yellow cartridges installed.

4. Loading Paper

Extend the output tray and open the paper support. Load plain paper into the paper feeder, ensuring it is aligned correctly. Adjust the paper guides to fit the width of the paper.



The paper output tray extended, showing a stack of plain paper loaded into the printer.

5. Software and Network Setup

Insert the software CD into your computer's CD/DVD drive or download the latest drivers and software from the official Epson support website. Follow the on-screen instructions to install the necessary software. During the setup process, you will be prompted to connect the printer to your network (Wi-Fi or Ethernet) or directly via USB.

- **Wi-Fi Setup:** Select your Wi-Fi network from the printer's control panel and enter the password.
- **Ethernet Setup:** Connect an Ethernet cable from the printer to your router or network hub.
- **USB Setup:** Connect a USB cable from the printer to your computer (only if not using network connectivity).



An illustration showing wireless connectivity between the Epson WF-2660 printer and a smartphone, demonstrating mobile printing capabilities.

Operating Instructions

Printing Documents

To print from a computer, open the document or image you wish to print. Select "Print" from the application's menu. Choose the Epson WF-2660 from the list of available printers. Adjust print settings such as paper size, print quality, and color options as needed. Click "Print".

For mobile printing, use Epson Connect apps like Epson iPrint, or utilize Wi-Fi Direct/NFC for direct connection from compatible devices. Simply select the document on your mobile device and choose the printer.



The Epson WF-2660 actively printing a colorful document, with the paper exiting the front tray.

Copying Documents

Place the original document face-down on the scanner glass or face-up in the Automatic Document Feeder (ADF). On the printer's control panel, select "Copy". Use the touchscreen to adjust settings such as number of copies, color/black & white, and paper size. Press the Start button (Black & White or Color) to begin copying.



Close-up view of the Epson WF-2660's control panel, highlighting the touchscreen display with copy, scan, and fax options visible.

Scanning Documents

Place the original document on the scanner glass or in the ADF. On the printer's control panel, select "Scan". Choose your desired scan destination (e.g., computer, cloud, email) and adjust scan settings like resolution and file format. Initiate the scan from the printer or your computer's scanning software.



A document being fed through the Automatic Document Feeder (ADF) of the Epson WF-2660, indicating scanning or copying in progress.

Faxing Documents

Load the document into the ADF or place it on the scanner glass. On the printer's control panel, select "Fax". Enter the recipient's fax number using the numeric keypad. Adjust any necessary fax settings. Press the Start button to send the fax.

Maintenance

Replacing Ink Cartridges

When an ink cartridge is low or empty, a message will appear on the printer's display. Open the ink cartridge cover. Press the tab on the empty cartridge to release it and pull it out. Unpack a new genuine Epson cartridge and insert it firmly into the correct slot until it clicks. Close the cover. The printer will automatically prepare the new cartridge for use.

Cleaning the Print Head

If print quality declines (e.g., missing lines, faded prints), perform a print head cleaning. Navigate to the "Setup" or "Maintenance" menu on the printer's control panel. Select "Print Head Cleaning" and follow the on-screen prompts. This process uses ink, so perform it only when necessary.

Resolving Paper Jams

If a paper jam occurs, the printer display will show an error message. Carefully open all covers and trays to locate the jammed paper. Gently pull the paper out in the direction of the paper path, avoiding tearing. Ensure no small pieces of paper remain inside. Close all covers and trays. The printer should resume operation.

Firmware Updates

Epson periodically releases firmware updates to improve printer performance and address issues. It is recommended to keep your printer's firmware updated. You can check for and install updates through the printer's control panel or via the Epson software installed on your computer.

Troubleshooting

Printer Not Responding

- Check power connections and ensure the printer is turned on.
- Verify network connectivity (Wi-Fi or Ethernet) or USB cable connection.
- Restart the printer and your computer/router.
- Ensure printer drivers are correctly installed and updated.

Poor Print Quality

- Perform a print head cleaning and nozzle check from the printer's maintenance menu.
- Check ink levels and replace any low or empty cartridges.
- Ensure you are using genuine Epson ink cartridges.
- Verify paper type and quality settings in your print driver match the paper loaded.

Error Messages

Refer to the specific error code displayed on the printer's screen. Consult the Epson support website or the full user manual for detailed explanations and solutions for specific error codes.

Specifications

Feature	Detail
Model Name	WF2660
Item Model Number	C11CE33201
Functions	Print, Scan, Copy, Fax
Printing Technology	Inkjet (PrecisionCore)
Connectivity	Wi-Fi, USB 2.0, Ethernet, Wi-Fi Direct, NFC
Max Print Resolution (Color)	4800x2400 dpi
Max Print Resolution (B&W)	1200 x 2400 dpi
Print Speed (ISO Black)	13 ISO ppm

Feature	Detail
Print Speed (ISO Color)	7.3 ISO ppm
Automatic Duplex Printing	Yes
Paper Capacity	150 sheets
Automatic Document Feeder (ADF)	30 pages
Display	2.7" Color Touchscreen
Item Dimensions (LxWxH)	17.1 x 19.2 x 11.9 inches
Item Weight	17.35 pounds
Included Components	Multi Function Inkjet Printer, Inkjet Multifunction Office Machine

Warranty and Support

For detailed warranty information, please refer to the warranty statement included with your product packaging or visit the official Epson support website. Epson provides technical support and resources to assist with product setup, operation, and troubleshooting.
Online Support: Visit epson.com/support for drivers, FAQs, manuals, and contact options.
Phone Support: Contact Epson customer service for direct assistance.

© 2024 Epson Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question