UNGER UNGRT92DZ

Unger RT920 ErgoTec Replacement Squeegee Blades Instruction Manual

Model: UNGRT92DZ

Product Overview

The Unger RT920 ErgoTec Replacement Squeegee Blades are high-quality rubber components designed to restore the performance of your Unger ErgoTec Squeegee (sold separately). These blades are precisely sized to ensure optimal cleaning results and feature a slip-out, slip-in design for quick and easy installation, minimizing downtime during cleaning tasks. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of these replacement blades.



This image displays several Unger ErgoTec replacement squeegee blades. Some blades are shown flat, indicating their straight form, while others are coiled, demonstrating their flexibility and how they might be packaged or stored. These are the replacement rubber components for the ErgoTec Squeegee.

Setup and Installation

Proper installation of the replacement blade is crucial for effective cleaning and to prolong the life of the blade. Ensure your ErgoTec Squeegee handle and channel are clean before beginning the installation process.

Installation Steps:

1. **Remove the Old Blade:** Carefully slide the worn or damaged blade out of the squeegee channel. Some ErgoTec models may have a release mechanism or clips; consult your squeegee's original manual if unsure.
2. **Clean the Channel:** Wipe down the squeegee channel to remove any dirt, debris, or residue that could interfere with the new blade's fit or performance.
3. **Insert the New Blade:** Gently slide the new Unger RT920 replacement blade into the squeegee channel. Ensure the blade is centered and fully seated within the channel. The precise sizing of these blades ensures a snug fit.

4. **Secure the Blade:** If your squeegee channel has clips or a locking mechanism, engage them to secure the new blade firmly in place. The blade should be straight and taut, without any kinks or twists.
5. **Test the Blade:** Before full use, perform a small test pass on a clean, wet surface to ensure the blade makes even contact and removes water effectively without leaving streaks.

Operating Instructions

Once installed, the Unger RT920 replacement blade operates as part of your ErgoTec Squeegee system. For optimal cleaning performance, follow these general guidelines:

- **Prepare the Surface:** Ensure the surface to be cleaned is adequately wet with a suitable cleaning solution.
- **Maintain Proper Angle:** Hold the squeegee at a consistent angle (typically 10-15 degrees) against the surface.
- **Apply Even Pressure:** Apply light, even pressure across the entire length of the blade to ensure uniform water removal.
- **Overlap Strokes:** Overlap each stroke slightly to prevent streaks and ensure complete coverage.
- **Clean the Blade:** Periodically wipe the blade clean with a damp cloth during use to remove accumulated dirt and maintain streak-free results.

Maintenance

Proper maintenance extends the life of your Unger RT920 replacement blades and ensures consistent cleaning performance.

- **Clean After Each Use:** Rinse the blade thoroughly with clean water after each cleaning session to remove soap residue and dirt.
- **Inspect for Damage:** Regularly inspect the blade for nicks, tears, or hardening. A damaged blade will leave streaks and should be replaced.
- **Store Properly:** Store the squeegee with the blade protected from direct sunlight and extreme temperatures. Avoid storing the blade bent or creased, as this can deform the rubber.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals on the rubber blade, as this can degrade the material.

Troubleshooting

If you encounter issues while using your Unger ErgoTec Squeegee with the replacement blades, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Streaks left on surface	• Blade is dirty: Clean the blade thoroughly. • Blade is damaged/worn: Inspect for nicks or hardening; replace if necessary. • Uneven pressure: Apply consistent, even pressure across the blade. • Incorrect angle: Adjust the squeegee angle (10-15 degrees is typical). • Insufficient lubrication: Ensure the surface is adequately wet with cleaning solution.
Blade slips out of channel	• Blade not fully seated: Re-insert the blade, ensuring it is pushed all the way into the channel. • Locking mechanism not engaged: Ensure any clips or locking mechanisms on the squeegee channel are properly secured.

Problem	Possible Cause / Solution
Blade feels stiff or rigid	• Exposure to extreme temperatures: Store blades in a moderate environment. • Age/Wear: Rubber can harden over time; replace the blade.

Specifications

Attribute	Detail
Brand	UNGER
Model Number	UNGRT92DZ (RT920 series)
Blade Material	High-quality Rubber
Item Weight (per pack)	Approximately 0.15 Pounds (2.4 ounces)
Package Dimensions	20 x 6 x 1.5 inches
Date First Available	October 22, 2012
Manufacturer	UNGER
Contents	Pack of 12 replacement blades (as per product title)

Warranty Information

Unger products are manufactured to high standards. Specific warranty details for the RT920 ErgoTec Replacement Squeegee Blades are typically provided with the original product purchase or can be found on the official Unger website. Please retain your proof of purchase for any warranty claims.

Customer Support

For further assistance, technical support, or inquiries regarding your Unger RT920 ErgoTec Replacement Squeegee Blades, please visit the official UNGER website or contact their customer service department. Contact information and FAQs are usually available on their website.
You can find more information at theUNGER Store on Amazon.

© 2024 UNGER. All rights reserved.