Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LG MAN62570901

LG MAN62570901 Dishwasher Door Basket Instruction Manual

1. Product Overview

This document provides instructions for the LG MAN62570901 Dishwasher Door Basket, an authorized Original Equipment Manufacturer (OEM) replacement part designed for various LG brand dishwasher models. This basket is intended to replace a damaged or missing door basket, ensuring proper dish organization and washing performance.

The LG MAN62570901 is a genuine LG part, ensuring compatibility and optimal performance with your appliance.



Image 1.1: The LG MAN62570901 Dishwasher Door Basket. This image shows the overall design and structure of the replacement basket, typically made of durable plastic or coated metal, designed to fit into the dishwasher door.

2. Safety Information

Please read and understand all safety instructions before installing or using this replacement part. Failure to follow these instructions may result in personal injury or property damage.

- **Disconnect Power:** Always disconnect power to the dishwasher at the circuit breaker before attempting any installation or maintenance.
- **Sharp Edges:** Be aware of potential sharp edges on the dishwasher or the new part during installation. Wear protective gloves if necessary.
- **Proper Fit:** Ensure the basket is securely installed to prevent it from dislodging during operation, which could damage dishes or the dishwasher.
- **Children:** Keep children away from the dishwasher during installation and ensure the basket is properly secured before resuming normal use.

3. Package Contents

Verify that all components are present and undamaged upon opening the package.

- One (1) LG MAN62570901 Dishwasher Door Basket

4. Installation

Follow these steps to install the LG MAN62570901 Dishwasher Door Basket:

1. **Power Disconnection:** Ensure the dishwasher's power supply is disconnected at the circuit breaker.
2. **Open Dishwasher Door:** Fully open the dishwasher door to access the interior.
3. **Remove Old Basket (if applicable):** If replacing an existing basket, carefully unclip or slide out the old basket from its mounting points on the dishwasher door. Note how the old basket was attached.
4. **Position New Basket:** Align the new LG MAN62570901 door basket with the designated mounting slots or clips on the inside of the dishwasher door.
5. **Secure Basket:** Gently push or slide the basket into place until it clicks or locks securely. Ensure it is firmly seated and does not wobble.
6. **Test Fit:** Lightly tug on the basket to confirm it is properly installed and will not detach during normal use.
7. **Restore Power:** Once the basket is securely installed, restore power to the dishwasher at the circuit breaker.

5. Operating Instructions

The door basket is designed to hold smaller items securely during the wash cycle. Proper loading ensures effective cleaning and prevents damage.

- **Loading Items:** Place small, lightweight items such as lids, small plastic containers, or other accessories into the basket. Ensure items are not overlapping excessively to allow water and detergent to reach all surfaces.
- **Avoid Overloading:** Do not overload the basket, as this can impede water circulation and lead to poor cleaning results or prevent the door from closing properly.
- **Secure Items:** Ensure all items are securely placed within the basket to prevent them from falling out during the wash cycle.
- **Door Closure:** Confirm that the dishwasher door closes and latches completely after loading the basket.

6. Maintenance and Care

Regular cleaning and inspection will prolong the life of your door basket.

- **Cleaning:** Periodically remove the basket and rinse it under warm water to remove any food debris or residue. A soft brush can be used for stubborn spots.
- **Inspection:** Regularly inspect the basket for any signs of wear, cracks, or damage. If the basket becomes damaged, it should be replaced to prevent potential issues during dishwasher operation.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals on the basket, as these can damage the material.

7. Troubleshooting

If you encounter issues with your LG MAN62570901 Dishwasher Door Basket, consider the following:

- **Basket Not Fitting:**
    - Ensure you have the correct model number (MAN62570901) for your LG dishwasher.
    - Verify that the basket is aligned correctly with the mounting points.
    - Check for any obstructions preventing the basket from seating properly.
- **Items Falling Out of Basket:**

- Ensure items are placed securely and not stacked too high.
- Avoid overloading the basket.
- Inspect the basket for any broken clips or dividers that might allow items to escape.

- **Poor Cleaning of Items in Basket:**
  - Ensure items are not blocking spray arms or water jets.
  - Do not overcrowd the basket, allowing sufficient space for water circulation.
  - Check that the dishwasher's spray arms are not clogged and are rotating freely.

8. Specifications

Brand Name	LG
Model Info / Part Number	MAN62570901
Item Weight	14.9 ounces (approx. 0.42 kg)
Product Dimensions	28 x 4 x 3 inches (approx. 71.12 x 10.16 x 7.62 cm)
Color	Multicolor
Included Components	Appliance replacement part (Dishwasher Door Basket)
Batteries Required?	No

9. Warranty and Support

As an authorized OEM part, the LG MAN62570901 Dishwasher Door Basket is typically covered under LG's standard warranty policy for replacement parts. For specific warranty details, claims, or technical support, please refer to your original dishwasher's warranty documentation or contact LG customer service directly.

You can find contact information for LG customer support on the official LG website or in your dishwasher's user manual.

This manual is for informational purposes only. Always refer to your specific appliance's user manual for detailed instructions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00M6K6BOQ

More documents and user manuals: **https://manuals.plus/**