Clatronic 263658

Clatronic EKI 3569 Single Induction Cooktop User Manual

Model: 263658

1. Product Overview

The Clatronic EKI 3569 is a portable single induction cooktop designed for efficient and fast cooking. It features a smooth, scratch-resistant ceramic surface and an intuitive electronic control panel with an LED display. This cooktop offers advanced safety features, including automatic pot detection and child lock, making it a reliable addition to any kitchen, camping setup, or dormitory.



Image: Front view of the Clatronic EKI 3569 Single Induction Cooktop, showing the ceramic surface, control panel, and LED display.

2. Key Features

- **High Power:** 2000 Watts for rapid heating.
- **Temperature and Power Control:** 10 power levels and 10 temperature levels (60°C – 240°C) with LED indicator.
- **ECO-Save Function:** Reduces cooking time by approximately 55% with no preheating required, leading to energy savings.
- **Automatic Pot Detection:** Automatically shuts off if non-induction compatible cookware is used.
- **Timer Function:** 180-minute timer with automatic shut-off and end signal.
- **Safety Features:** Child lock, automatic shut-off after 120 minutes of inactivity, and no risk of burns on the cooktop surface.
- **Stability:** Equipped with non-slip feet for secure placement.
- **Easy Cleaning:** Smooth ceramic surface for simple maintenance.



Image: A family enjoying a meal, highlighting the energy-saving benefits of the induction cooktop compared to traditional heating plates, with no preheating phase and quick heating.



Image: Visual representation of key features including 2000W power, high-quality ceramic surface, 180-minute timer, LED indicator, easy cleaning, and high stability.

3. Setup and Installation

3.1 Unpacking

Carefully remove the induction cooktop from its packaging. Retain the packaging for future storage or transport. Verify that all components listed in the package contents are present.

3.2 Placement

- Place the cooktop on a stable, flat, and heat-resistant surface.
- Ensure adequate ventilation around the unit. Do not block the ventilation openings.
- Keep the cooktop away from water sources and heat-sensitive materials.
- Maintain a safe distance from walls and other appliances.

3.3 Power Connection

- Ensure the voltage of your power outlet matches the specifications of the cooktop (230 Volts).
- Plug the power cord into a grounded electrical outlet.

4. Operating Instructions

4.1 Compatible Cookware

Only use induction-compatible cookware. These typically have a flat bottom and are made of ferromagnetic materials such as cast iron, enameled steel, or stainless steel with a magnetic base. The cooktop features automatic container detection and will shut off if incompatible cookware is used.



Image: Illustration of the induction principle and the automatic detection of compatible cookware, ensuring the cooktop only operates with suitable pots and pans.

4.2 Basic Operation

1. **Power On:** Place suitable cookware on the ceramic surface. Press the**ON/OFF** button to turn on the cooktop. The LED display will illuminate.
2. **Select Mode:** The cooktop typically defaults to a power setting. Use the**"Up"** and **"Down"** buttons to adjust power levels (10 levels available).
3. **Temperature Control:** Press the **"Select"** button to switch to temperature mode. Use the**"Up"** and **"Down"** buttons to set the desired temperature (60°C – 240°C, 10 levels).
4. **Timer Function:** Press the **"Time"** button to activate the timer. Use the**"Up"** and **"Down"** buttons to set the cooking duration up to 180 minutes. The cooktop will automatically shut off and signal when the timer expires.
5. **Power Off:** Press the **ON/OFF** button to turn off the cooktop after use.



Image: Examples of cooking applications such as boiling, reheating, and roasting, demonstrating the versatility of the cooktop for various culinary tasks.

4.3 Child Lock

The cooktop is equipped with a child lock feature to prevent accidental operation. Refer to the specific instructions in the included manual for activating and deactivating the child lock, as this may vary. (Note: The provided product description mentions child lock but not specific activation steps. Users should consult the physical manual for this detail.)

4.4 Automatic Shut-off

For safety, the cooktop will automatically shut off after 120 minutes of non-use. This feature helps conserve energy and prevents potential hazards.

5. Maintenance and Cleaning

5.1 General Cleaning

- Always unplug the cooktop and allow it to cool completely before cleaning.
- Wipe the ceramic surface with a soft, damp cloth and mild detergent.
- For stubborn stains, use a ceramic hob cleaner.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
- Ensure no water enters the internal components.

5.2 Storage

When not in use for extended periods, store the cooktop in a dry, cool place, preferably in its original packaging, to protect it from dust and damage.

6. Troubleshooting

Before contacting customer support, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power supply; try a different outlet.
"Lo" error on display.	Child lock activated or system error.	Consult the physical manual for child lock deactivation steps. If issue persists, contact support.
Cooktop shuts off during use.	Incompatible cookware; overheating; automatic shut-off due to inactivity.	Ensure cookware is induction-compatible; allow unit to cool; restart if necessary.
No heating or weak heating.	Cookware not centered; incorrect power/temperature setting.	Center the cookware; adjust power/temperature settings.

7. Specifications

Feature	Detail
Brand	Clatronic
Model Number	263658 (EKI 3569)
Dimensions (L x W x H)	37 x 29 x 6.5 cm (14.57 x 11.42 x 2.56 inches)
Weight	2.5 Kilograms (5.5 lbs)
Power	2000 Watts
Voltage	230 Volts

Feature	Detail
Number of Hobs	1
Control Type	Touch
Material	Stainless Steel (Cooktop surface: Ceramic)
Color	Black
Special Features	Automatic Shut-off, Portable, Child Lock, LED Display, Timer
Energy Efficiency	A
Noise Level	44 dB



Image: Diagram showing the dimensions of the Clatronic EKI 3569 induction cooktop: 370 mm length, 290 mm width, and 65 mm height.

8. Warranty and Support

8.1 Warranty Information

Clatronic offers a **1-year warranty** on this product. Additionally, spare parts availability is guaranteed for **2 years**. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact Clatronic customer service. Refer to the contact information provided in your product packaging or on the official Clatronic website.

© 2024 Clatronic. All rights reserved.