Glade 71773

Glade Automatic Spray Air Freshener Refill: Clean Linen (Model 71773) Instruction Manual

1. Introduction

This manual provides instructions for the safe and effective use of the Glade Automatic Spray Air Freshener Refill, Clean Linen scent. This product is designed to provide continuous fragrance in your home when used with a compatible Glade Automatic Spray Dispenser (sold separately). The Clean Linen scent features notes of crisp air, fresh laundry, and lily of the valley.



Image: Two Glade Automatic Spray Refills in Clean Linen scent.

2. Safety Information

CAUTION: CONTENTS UNDER PRESSURE.

- Contains propellants. Do not expose to heat or store at temperatures above 120°F (49°C).
- Do not puncture or incinerate container.

EYE IRRITANT.

- Contains acetone. Avoid contact with eyes.

FIRST AID:

- **EYES:** Immediately rinse eyes with plenty of water for at least 15 minutes. If irritation persists, get medical attention.

- Do not use in small confined pet areas without adequate ventilation.
- Store in a cool, dry place.
- KEEP OUT OF REACH OF CHILDREN AND PETS.

3. Product Overview

The Glade Automatic Spray Air Freshener Refill provides a consistent fragrance experience. Each 6.2 oz refill delivers the Clean Linen scent, characterized by crisp air, fresh laundry, and lily of the valley notes. These refills are designed for use with Glade Automatic Spray Dispensers, which offer adjustable time-release settings.



Image: Scent profile of Clean Linen, highlighting Crisp Air, Fresh Laundry, and Lily of the Valley.



Image: Glade Automatic Spray Dispenser, illustrating timed fragrance release.

4. Setup Instructions

Follow these steps to install the refill and batteries into your Glade Automatic Spray Dispenser:

1. **Open the Unit:** Press the button located at the top of the dispenser while simultaneously pulling the sides of the holder apart. When the unit is open, always ensure the timer is set to the OFF position and keep the spray nozzle pointed away from your face.
2. **Activate Batteries:** If installing for the first time, pull out the red tab to activate the batteries.
3. **Insert the Can:** Remove the cap from the Glade Automatic Spray Refill can. Insert the can into the dispenser with the nozzle facing outwards.
4. **Set Timer and Close:** Turn the unit on by selecting your desired time setting (9, 18, or 36 minutes) for fragrance release. Close the unit securely. A spray will occur at the selected time interval.

Image: Visual guide for refill and battery installation.

5. Operating Instructions

Once the refill is installed and the unit is closed, the dispenser will automatically release fragrance at your chosen interval (9, 18, or 36 minutes). This provides continuous freshness for up to 60 days on the 36-minute setting.

- **Automatic Release:** The dispenser will spray automatically based on the selected time interval.
- **Instant Boost:** For an immediate burst of Glade fragrance at any time, press the boost button located on the back of the unit.



Image: Glade Automatic Spray providing continuous freshness.



Image: Using the boost button for additional fragrance.

6. Maintenance

Replacing the Battery:

1. Open the unit and remove the refill can to access the batteries.
2. Remove the old batteries and replace them with two new alkaline batteries.
3. Replace the refill can, set your desired time interval, and close the unit.

7. Troubleshooting

- **No Spray or Weak Spray:**
  - Ensure the refill can is inserted correctly with the nozzle facing outwards.
  - Check if the batteries are correctly installed and have sufficient power. Replace with new alkaline batteries if

necessary.
    - Verify that the timer is set to an active interval (9, 18, or 36 minutes) and not the OFF position.
    - Confirm the refill can is not empty.
- **Dispenser Not Included:** Please note that this product is a refill pack only. The Glade Automatic Spray Dispenser is sold separately.
- **Damaged Can:** If a refill can appears damaged or does not function properly, do not attempt to repair it. Dispose of it according to local regulations and replace it with a new, undamaged refill.

8. Specifications

Feature	Detail
Brand	Glade
Model Number	71773
Scent	Clean Linen
Item Form	Liquid (Aerosol)
Product Dimensions	2.6 x 5.2 x 5.6 inches
Item Weight	12.4 ounces (total for 2 count)
Manufacturer	SCJohnson
UPC	0046500745416

9. Ingredients

Isobutane; Distillates (petroleum), hydrotreated light; Acetone; Propane; Fragrance. Contains Fragrance Allergens. SCJ Formula # 35*14838

10. Support & Warranty

For questions, comments, or support regarding your Glade Automatic Spray Air Freshener Refill, please contact SCJohnson directly.

- **Customer Service:** Call 800-558-5252
- **Website:** Visit www.glade.com

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question