Primo 900130-C

Primo Bottom Loading Water Dispenser User Manual

Model: 900130-C
Brand: Primo

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Primo Bottom Loading Water Dispenser. Designed for convenience, this dispenser offers three temperature settings: piping-hot, cool, and ice-cold water, with a child-resistant safety feature for hot water dispensing. Its bottom-loading design eliminates the need for heavy lifting, making bottle replacement simple and mess-free.





Image: Front view of the Primo water dispenser with the lower door open, revealing a 5-gallon water bottle inside. The dispenser is black with a bright stainless steel lower door.

Setup

1. Unpacking and Placement

Carefully remove the dispenser from its packaging. Place the dispenser on a flat, level surface in a cool, dry location away from direct sunlight and heat sources. Ensure there is adequate clearance (at least 4 inches) from walls to allow for proper ventilation.



Image: The Primo water dispenser positioned in a kitchen, demonstrating its compact size and aesthetic integration with home decor.

2. Water Bottle Installation

1. Open the lower cabinet door of the dispenser.
2. Remove the protective seal from a new 5-gallon Primo water bottle.
3. Insert the probe assembly (the tube with the cap) into the bottle opening. Ensure it is securely seated.
4. Slide the water bottle into the lower cabinet.
5. Close the cabinet door.



Image: A person is shown placing a 5-gallon water bottle into the bottom compartment of the dispenser, highlighting the easy bottom-loading feature.

3. Initial Priming

Before plugging in the dispenser, dispense water from the cold and hot spouts until water flows continuously. This primes the system and removes any air. Once primed, plug the dispenser into a standard grounded electrical outlet.

Operating Instructions

1. Dispensing Water

- Place your cup or container on the drip tray.
- **For Cold Water:** Press the blue button on the top panel.
- **For Cool Water:** Press the light blue button on the top panel.
- **For Hot Water:** Engage the child-resistant safety feature (usually a red button or lever) and then press the red hot water button.



Image: A hand pressing the cold water button on the dispenser, filling a glass with refreshing cold water.



Image: A hand pressing the hot water button on the dispenser, filling a mug with hot water, suitable for tea or other hot beverages.

2. Indicator Lights

The dispenser features indicator lights on the front panel to show the status of heating, cooling, and low water levels. Refer to the labels next to the lights for specific meanings.

Maintenance

1. Cleaning the Drip Tray

The removable stainless steel drip tray should be emptied and cleaned regularly to prevent overflow and maintain hygiene. It is dishwasher safe for easy cleaning.

2. Replacing Water Bottles

When the low water indicator light illuminates, it's time to replace the 5-gallon water bottle. Follow the installation steps in the Setup section.

3. General Cleaning

Wipe down the exterior of the dispenser with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.

Troubleshooting

Problem	Possible Cause	Solution
No water dispensing.	Water bottle empty or not properly installed. Airlock in system.	Replace bottle. Re-prime the system by dispensing from all spouts until water flows.
Water not hot/cold enough.	Heating/cooling switch off. Dispenser recently plugged in.	Ensure heating/cooling switches on back are ON. Allow 15-30 minutes for water to reach desired temperature.
Low water indicator blinking.	Water bottle is low or empty.	Replace the 5-gallon water bottle.

Specifications

Feature	Detail
Color	Bright Stainless Door
Material	Stainless Steel
Capacity	5 Gallons
Product Dimensions	12.2"D x 14.2"W x 40.9"H
Style	Bottom Load

Feature	Detail
Installation Type	Freestanding
Access Location	Bottom
Number of Settings	3 (Hot, Cool, Cold)
Power Source	Corded Electric
Item Weight	41.5 pounds

Warranty and Support

Your Primo Water Dispenser comes with a 1-Year Limited Warranty. For warranty claims, technical support, or additional information, please refer to the contact details provided in your product packaging or visit the official Primo website.