De'Longhi 5525103400

De'Longhi Deep Fryer Filter Set 5525103400 Instruction Manual

Model: 5525103400

1. Introduction

This manual provides instructions for the proper installation and replacement of the De'Longhi Deep Fryer Filter Set, model 5525103400. This set is designed to maintain the performance and longevity of your compatible De'Longhi deep fryer by effectively filtering oil vapor, odors, and impurities. Please read these instructions carefully before proceeding with filter replacement.

2. Package Contents

The De'Longhi Deep Fryer Filter Set 5525103400 includes the following components:

- **3 Oil-Vapor Filters:** Designed to capture oil mist and vapor.
- **3 Charcoal Filters:** Designed to absorb odors.
- **3 Paper Filters:** Designed for general filtration of impurities.



Image 1: Packaging of the De'Longhi Deep Fryer Filter Set 5525103400. The image displays the De'Longhi brand logo, the filter types (oil-vapor, charcoal, paper), and indicates a total of 3+3+3 pieces. Compatible deep fryer series such as FP, FPA, PFAEC, FRAY, FPEC, FPXEC, FPT, and FPX are also visible on the packaging.

3. Compatible Deep Fryer Models

This filter set is compatible with various De'Longhi deep fryer models. Please verify your deep fryer's model number against the list below to ensure compatibility. The model number is typically located on a label on the underside or back of your appliance.

- De'Longhi FP Series
- De'Longhi FPA Series (e.g., FPA100A, FPa)
- De'Longhi PFAEC Series (e.g., FPaEC, FPaEC-e9)
- De'Longhi FRAY Series (e.g., FPaY)
- De'Longhi FPEC Series
- De'Longhi FPXEC Series
- De'Longhi FPT Series
- De'Longhi FPX Series

4. Installation and Replacement Instructions

Safety Precaution:
Always ensure your deep fryer is unplugged from the power outlet and completely cooled down before attempting to replace any filters. Refer to your deep fryer's specific instruction manual for details on accessing the filter compartments.

4.1. Replacing Oil-Vapor Filters

1. Locate the oil-vapor filter compartment, typically found in the lid of the deep fryer.
2. Carefully open the compartment cover.
3. Remove the old oil-vapor filter. Dispose of it according to local regulations.
4. Insert a new oil-vapor filter from the 5525103400 set, ensuring it fits securely.
5. Close the compartment cover firmly.

4.2. Replacing Charcoal Filters

1. Identify the charcoal filter location, usually adjacent to or integrated with the oil-vapor filter compartment.
2. Open the designated access point for the charcoal filter.
3. Remove the used charcoal filter.
4. Place a new charcoal filter from the 5525103400 set into position.
5. Securely close the access point.

4.3. Replacing Paper Filters

Some deep fryer models may utilize paper filters for additional oil filtration. Consult your deep fryer's manual for specific instructions.

1. Locate the paper filter tray or area within your deep fryer.
2. Remove and discard any soiled paper filters.
3. Place a fresh paper filter from the 5525103400 set into the designated area.
4. Ensure it lies flat and does not obstruct any moving parts or heating elements.

5. Maintenance and Filter Replacement Frequency

The lifespan of your filters depends on the frequency of deep fryer use and the types of food being cooked. Regular inspection is recommended.

- **Oil-Vapor Filters:** Replace when they appear saturated with oil or when oil mist becomes noticeable during operation.
- **Charcoal Filters:** Replace when odors are no longer effectively neutralized, typically every 10-15 uses, or as recommended by your deep fryer's manual.
- **Paper Filters:** Replace after each use or when visibly soiled to maintain optimal oil quality.

6. Troubleshooting

6.1. Filter Does Not Fit

Ensure you have purchased the correct filter set for your specific De'Longhi deep fryer model. Double-check the model number on your appliance against the compatibility list in this manual and on the filter packaging. If the filter still does not fit, do not force it. Contact De'Longhi customer support for assistance.

6.2. Odors Persist After Replacement

Verify that the charcoal filter is correctly installed and that the filter compartment is securely closed. If odors continue, it may indicate that the deep fryer itself requires a thorough cleaning, or that the filter needs to be replaced more frequently based on usage.

7. Specifications

- **Brand:** De'Longhi
- **Model Number:** 5525103400
- **UPC:** 730133135392
- **Package Dimensions:** 20.6 x 16.4 x 3.9 cm
- **Package Weight:** 70 grams
- **Number of Pieces:** 9 (3 oil-vapor, 3 charcoal, 3 paper)

8. Customer Support and Warranty Information

For further assistance, technical support, or warranty inquiries regarding your De'Longhi deep fryer or filter set, please visit the official De'Longhi website or contact their customer service department. Specific warranty terms and conditions are typically provided with your original deep fryer purchase.
Note: Filters are consumable items and are generally not covered under standard product warranties unless a manufacturing defect is present upon purchase.