**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Classic Cantabile DP-50 WM

# Classic Cantabile DP-50 WM Digital Piano User Manual

Model: DP-50 WM

## Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Classic Cantabile DP-50 WM Digital Piano. Please read this manual thoroughly before using the instrument to ensure safe and optimal performance.

## Package Contents

Before assembly, verify that all components are present in the package.

- Classic Cantabile DP-50 WM Digital Piano
- Power Adapter
- Piano Bench
- Headphones
- Piano Learning Method Book




*Image: The Classic Cantabile DP-50 WM Digital Piano set, including the piano, adjustable bench, headphones, and a piano learning method book.*

## Setup

### 1. Assembly

The Classic Cantabile DP-50 WM Digital Piano requires assembly. It is recommended to have two people for the assembly process, especially when lifting the main keyboard unit, as it is heavy (approximately 51 kg). Follow the detailed instructions provided in the separate assembly guide (if included) or refer to the general assembly steps below.

1. Unpack all components carefully.
2. Assemble the piano stand structure according to the diagrams.
3. Attach the pedal unit to the stand.
4. Carefully place the main keyboard unit onto the assembled stand, ensuring it is securely fastened.
5. Assemble the piano bench and adjust its height as desired.

### 2. Power Connection

Connect the provided power adapter to the DC IN jack on the rear panel of the piano. Plug the other end of the adapter into a suitable electrical outlet.

### 3. Initial Power On

Locate the power button, usually on the left side of the keyboard. Press it to turn on the digital piano.




*Image: Front view of the Classic Cantabile DP-50 WM Digital Piano, showcasing its 88-key weighted keyboard and pedal unit.*

## Operating Instructions

### 1. Basic Playback

- **Volume Control:** Adjust the master volume using the dedicated knob or buttons.
- **Voice Selection:** The piano features 14 different voices. Use the voice selection buttons or menu to choose your desired instrument sound (e.g., Grand Piano, Electric Piano, Organ, Strings).
- **Touch Response:** The 88 weighted hammer-action keys provide a realistic piano feel. The touch response allows for dynamic expression based on how hard or soft you press the keys.

### 2. Pedal Functions

The DP-50 WM includes three pedals, mimicking an acoustic piano:

- **Soft Pedal (Left):** Reduces the volume and softens the tone of the notes played.

- **Sostenuto Pedal (Middle):** Sustains only the notes held down at the moment the pedal is pressed, allowing subsequent notes to be played without sustain.
- **Sustain Pedal (Right):** Sustains all notes played while the pedal is held down, allowing them to ring out longer.




*Image: A close-up view of the three pedals (Soft, Sostenuto, Sustain) on the digital piano.*

## 3. Advanced Features

- **Effects:** Explore the 13 built-in effects to enhance your sound. Refer to the display and control panel for effect selection and parameter adjustment.
- **Layer Function:** Combine two different voices to play simultaneously (e.g., piano and strings).
- **Split Function:** Divide the keyboard into two sections, allowing different voices to be played with the left and right hands.
- **Twin Function (Duo Mode):** Splits the keyboard into two identical pitch ranges, ideal for student-teacher lessons.
- **Recording Function:** Record your performances directly on the piano. Consult the manual for specific recording and playback procedures.
- **Metronome:** Use the built-in metronome to practice with precise timing. Adjust tempo and beat as needed.

## 4. Connectivity

The DP-50 WM offers various connectivity options:

- **Headphone Jacks (2x):** Connect up to two pairs of headphones (3.5mm jack) for silent practice or duet playing without disturbing others.
- **USB Audio/MIDI Interface:** Connect the piano to a computer via USB for MIDI data transfer (e.g., using with GarageBand or other DAW software) or for audio recording/playback.
- **Line-In:** Connect external audio devices (e.g., smartphone, MP3 player) to play along with your favorite music.
- **Line-Out:** Connect the piano to external amplifiers, speakers, or recording equipment.




*Image: A detailed diagram illustrating the various connection ports available on the DP-50 WM, including USB, headphone jacks, Line-In, and Line-Out.*

## Maintenance

Proper care will ensure the longevity and optimal performance of your digital piano.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the piano. For stubborn dirt, slightly dampen the cloth with water. Avoid abrasive cleaners, solvents, or waxes, as these can damage the finish.
- **Dust Cover:** When not in use, cover the keyboard with a dust cover to protect it from dust and debris.
- **Environment:** Place the piano in a stable location, away from direct sunlight, heat sources, and excessive humidity. Extreme temperature or humidity changes can affect the instrument.
- **Power Off:** Always turn off the piano using the power button and unplug it from the wall socket when not in use for extended periods or during electrical storms.

## Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| No sound | Volume is too low.<br>Headphones are plugged in.<br>Power adapter not connected. | Increase the master volume.<br>Unplug headphones if using internal speakers.<br>Ensure power adapter is securely connected and power is on. |
| Keys do not respond | Piano is not powered on.<br>Local MIDI control is off (if using external MIDI). | Turn on the piano.<br>Check MIDI settings to ensure local control is enabled if playing directly. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Distorted sound | Volume is too high.<br>External audio source is distorted. | Lower the master volume.<br>Adjust the volume of the external audio source. |

## Specifications

| Feature | Detail |
|---|---|
| Model Name | DP-50 WM |
| Keys | 88 Weighted Hammer-Action Keys |
| Polyphony | Max. 32 Voices |
| Voices | 14 |
| Effects | 13 |
| Functions | Layer, Split, Twin (Duo Mode), Recording, Metronome |
| Pedals | Soft, Sostenuto, Sustain |
| Connectivity | USB Audio/MIDI, 2x Headphone Jacks (3.5mm), Line-In, Line-Out |
| Dimensions (H x W x D) | Approx. 85 cm x 137 cm x 44 cm |
| Weight | Approx. 51 kg (including packaging) |
| Color | Matte White |
| Included Components | Power adapter, Piano bench, Headphones, Piano learning method |




*Image: Diagram illustrating the dimensions of the Classic Cantabile DP-50 WM Digital Piano.*

## Warranty and Support

Your Classic Cantabile DP-50 WM Digital Piano is covered by standard legal guarantees. For specific warranty details, please refer to your purchase documentation or contact the retailer.
For technical support, troubleshooting assistance, or inquiries regarding your product, please contact the seller, Maison de la musique Kirstein, or visit their official website.

- **Seller:** Maison de la musique Kirstein
- **Returns Policy:** 30-day returns
- **Support:** Specialized Customer Support

© 2023 Classic Cantabile. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B00N2UP0SW**

More documents and user manuals: **https://manuals.plus/**