Bose 627840-1110

Bose SoundLink Color Bluetooth Speaker User Manual

Model: 627840-1110

Introduction

The Bose SoundLink Color Bluetooth speaker delivers clear, full-range audio from a compact and durable design. Engineered for portability, it allows you to enjoy your favorite music wirelessly from Bluetooth-enabled devices almost anywhere. Its robust construction and intuitive controls make it an ideal companion for an active, mobile lifestyle.

Key features include:

- Clear, full-range sound from a compact speaker.
- Voice prompts for easy device pairing.
- Up to 8 hours of music playback from its rechargeable lithium-ion battery.
- Wireless connection to smartphones, tablets, and other Bluetooth-enabled devices.



Figure 1: Front view of the Bose SoundLink Color Bluetooth Speaker.

What's in the Box

Your Bose SoundLink Color Bluetooth Speaker package includes the following items:

- Bose SoundLink Color Bluetooth speaker
- Wall charger
- USB Cable

Setup

Charging the Battery

Before initial use, fully charge your SoundLink Color speaker. The speaker charges using the included wall charger and Micro USB cable. A full charge takes approximately 8 hours. The battery indicator light on the top panel will show charging status.



Figure 2: Rear view of the speaker with charging and auxiliary input ports.

Bluetooth Pairing

The SoundLink Color speaker uses voice prompts to guide you through the Bluetooth pairing process, making it simple to connect your devices.

1. Power on the speaker by pressing the **Power** button.
2. The speaker will announce its battery level and indicate if it's ready to pair. If not, press and hold the **Bluetooth** button until the Bluetooth indicator light blinks blue and you hear "Ready to pair".
3. On your smartphone, tablet, or other Bluetooth device, enable Bluetooth and select "Bose Color SoundLink" from the list of available devices.
4. Once connected, the speaker will announce "Connected to [Device Name]" and the Bluetooth indicator light will glow solid white.

The speaker remembers the eight most recently paired devices, making reconnection easier in the future. It can also connect to two Bluetooth devices simultaneously, allowing for quick switching between audio sources.

Auxiliary Connection

For devices without Bluetooth, you can connect them using a 3.5mm auxiliary cable (not included). Simply plug one end of the cable into the AUX IN port on the back of the speaker and the other end into your audio device's headphone jack.

Operating Your Speaker

The top panel of the SoundLink Color speaker features all the necessary controls for basic operation:



Figure 3: Top control panel of the speaker.

Button	Function
Power (*Power symbol*)	Turns the speaker on or off.
Bluetooth (*Bluetooth symbol*)	Initiates Bluetooth pairing mode or switches between connected Bluetooth devices.
AUX	Switches to auxiliary input mode.
Play/**Pause** (*Play/Pause symbol*)	Plays or pauses audio playback.
Volume - (*Minus symbol*)	Decreases the volume. Hold to skip to the previous track.

Button	Function
Volume + (*Plus symbol*)	Increases the volume. Hold to skip to the next track.

For advanced functions like track skipping or answering calls, control directly from your connected Bluetooth device.

Maintenance

To ensure the longevity and optimal performance of your Bose SoundLink Color speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Care:** The integrated lithium-ion battery provides up to 8 hours of playback. To maximize battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in constant use.
- **Durability:** The speaker is constructed with durable materials and features a soft, rubbery exterior that provides a good grip and helps protect against minor impacts. While robust, it is not waterproof and should be protected from excessive moisture.



Figure 4: The speaker's compact and durable design makes it suitable for various environments.

Troubleshooting

If you encounter issues with your SoundLink Color speaker, refer to the following common troubleshooting steps:

- **No Power:** Ensure the speaker is charged. Connect it to the wall charger and allow it to charge for at least 30 minutes before attempting to power it on.
- **Bluetooth Connection Issues:**
  - Make sure Bluetooth is enabled on your device and the speaker is in pairing mode (blinking blue light).
  - Move your device closer to the speaker (within 30 feet).
  - Forget "Bose Color SoundLink" from your device's Bluetooth settings and attempt to re-pair.
  - Turn off and on both the speaker and your Bluetooth device.

- **Poor Sound Quality:**
  - Ensure the volume on both the speaker and your connected device is adequately set.
  - Check for interference from other wireless devices.
  - If using an auxiliary cable, ensure it is fully inserted and not damaged.
- **Speaker Not Responding:** If the speaker becomes unresponsive, try a soft reset by holding the Power button for 10 seconds until it turns off. Then, power it back on.

Specifications

Detailed specifications for the Bose SoundLink Color Bluetooth Speaker:

Feature	Detail
Model Name	SoundLink Color
Model Number	627840-1110
Dimensions (D x W x H)	2.1"D x 5"W x 5.3"H
Item Weight	1.25 Pounds
Connectivity Protocol	Bluetooth
Wireless Communication Technology	Bluetooth, 3.5MM Aux
Battery Life	Up to 8 Hours
Charging Time	8 Hours
Power Source	Battery Powered
Speaker Type	Portable Outdoor Speaker
Color	Black (as per product data, though other colors exist)



Figure 5: Product dimensions for the SoundLink Color speaker.

Warranty and Support

Bose products are designed for durability and performance. For specific warranty information and terms, please refer to the warranty card included with your product or visit the official Bose website.

For further assistance, technical support, or to download the full user guide in PDF format, please visit the official Bose User Guide or the Bose support page.

© 2024 Bose Corporation. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question