Beurer 606.67

Beurer FC 100 Microdermabrasion Device User Manual

Model: FC 100 (606.67)

Introduction

The Beurer FC 100 Pureo Derma Peel Microdermabrasion device is designed for professional-grade facial exfoliation and skin revitalization in the comfort of your home. This device utilizes a dual-action approach: revitalizing exfoliation to remove excess skin particles and activating pressure massage to promote blood circulation and stimulate cell renewal. Regular use can contribute to firmer, healthier skin and refined pores.



Image: The Beurer FC 100 Microdermabrasion device, showcasing its compact design and various attachments.

Safety Information

Please read these instructions carefully before using the device. Keep this manual for future reference.

- Ensure the device is used only for its intended purpose as described in this manual.
- Do not use on irritated, damaged, or inflamed skin.
- Consult a dermatologist if you have any pre-existing skin conditions or concerns.
- Keep out of reach of children.
- Only use the provided power adapter.

Package Contents

Verify that all items are present in the package:

- Beurer FC 100 Microdermabrasion Device
- 3 high-quality sapphire-coated attachments
- 20 replacement filters
- Power adapter

- Instruction Manual



Image: The Beurer FC 100 device, showing the three attachments and a note about the 20 included disposable filters.

Setup

1. **Unpack the Device:** Carefully remove the Beurer FC 100 from its packaging.
2. **Connect to Power:** Plug the device into a suitable mains power outlet using the provided adapter.
3. **Select Attachment:** Choose one of the three sapphire-coated attachments based on your skin sensitivity and the area to be treated.



Image: Detailed view of the three sapphire-coated attachments: a large attachment for sensitive areas, a rough attachment for intensive treatment of problem skin, and a precision head for small areas like the nose.

- **Large Attachment:** For larger, sensitive areas such as the forehead and cheeks.
- **Rough Attachment:** For intensive treatment of problem skin.
- **Precision Head:** For small areas like the nose, temples, and around the mouth.

4. **Integrated Mirror:** The device features an integrated mirror in the lid for convenient use.



Image: The Beurer FC 100 device open, showing the integrated mirror in the lid.

Operating Instructions

1. **Power On:** Turn on the device by pressing the illuminated power switch.
2. **Adjust Intensity:** Adjust the intensity level according to your skin type and sensitivity. The device offers five intensity levels for individual adaptation.



Image: A visual representation of the five intensity levels available on the Beurer FC 100 device.

3. **Application:** Gently and evenly glide the device over your skin. The device provides a dual-action effect:



Image: Illustration of the device's dual effect: 1. Revitalizing exfoliation gently removes excess skin particles. 2. Activating negative pressure massage promotes blood circulation and stimulates cell renewal.

- **Revitalizing Exfoliation:** Gently removes excess skin particles.
- **Activating Pressure Massage:** Promotes blood circulation and stimulates cell renewal.

Maintenance

1. **Cleaning Attachments:** After each application, clean the attachments with soap and water. Allow them to dry overnight.
2. **Filter Replacement:** The device includes 20 replacement filters for hygienic application. Replace filters as needed to maintain optimal performance and hygiene.

Troubleshooting

If you encounter any issues with your Beurer FC 100 device, please refer to the following common solutions:

- **Device not turning on:** Ensure the power adapter is securely connected to both the device and a working power outlet.
- **Reduced suction power:** Check if the attachment is properly seated. Replace the filter if it appears clogged or dirty.
- **Skin irritation:** Reduce the intensity level or use a different attachment (e.g., the large attachment for sensitive areas). Ensure you are not applying too much pressure or staying in one area for too long.

For further assistance, please contact Beurer customer support.

Specifications

Brand:	Beurer
Model Number:	606.67 (FC 100)
Dimensions (L x W x H):	33.4 x 10.4 x 25.2 cm
Weight:	1.01 grams
Power Source:	Mains operated
Special Features:	Dual action, 3 sapphire-coated attachments, 5 intensity levels, integrated mirror, 20 replacement filters.
Country of Origin:	China

Warranty and Support

For warranty information, product registration, or technical support, please visit the official Beurer website or contact their customer service department.
Beurer Official Website: www.beurer.com

© 2023 Beurer GmbH. All rights reserved.