Goki 55937

Goki Wooden Crane Toy Instruction Manual

Model: 55937

1. Introduction

Thank you for choosing the Goki Wooden Crane Toy. This manual provides essential information for the safe and proper use, assembly, and maintenance of your new toy. The Goki Wooden Crane is a high-quality, handcrafted toy designed to provide a soft and pleasant tactile experience. Made from solid and durable maple wood, it is hand-painted in Germany with water-based satin colors that are resistant to saliva and perspiration, ensuring a safe and long-lasting play experience.

Please read this manual thoroughly before allowing children to play with the product and retain it for future reference.

2. Safety Information

Important: This product is suitable for children aged **3 years and up**. Adult supervision is recommended during play, especially during initial setup and operation.

- Ensure all parts are securely attached before play.
- Regularly inspect the toy for any signs of wear, damage, or loose parts. Discontinue use if damage is found.
- Keep packaging materials away from children to prevent suffocation hazards.
- This toy is made with child-safe, water-based paints. However, discourage children from putting the toy in their mouth excessively.
- Do not modify the toy in any way, as this may compromise its safety and durability.

3. Parts List

The Goki Wooden Crane Toy typically comes as a single main unit with minimal assembly required for certain components. Please verify that all parts are present and undamaged upon unpacking.

- Main Crane Assembly (Tower, Boom, Base with wheels)
- Crane Hook and Pulley System
- Lifting Platform/Pallet (if included as an accessory)

- Any small screws or fasteners for minor assembly (if applicable)



Figure 3.1: Main Goki Wooden Crane Toy assembly. This image shows the complete crane with its yellow tower, wooden boom, base with wheels, and the attached hook and lifting platform.

4. Setup and Assembly

The Goki Wooden Crane Toy is largely pre-assembled. Minimal setup is typically required to prepare it for play.

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or disposal.
2. **Minor Assembly (if required):** Some models may require attaching the boom to the tower or securing the base. If screws are provided, use a suitable screwdriver to firmly attach these parts. Do not overtighten.
3. **Check Stability:** Once assembled, ensure the crane stands stably on a flat surface. Verify that all wheels rotate

freely and the crane's rotating mechanism (if applicable) moves smoothly.

4. **Hook and Pulley System:** Ensure the string for the hook and pulley system is correctly threaded and the hook moves up and down smoothly when the winding mechanism is operated.



Figure 4.1: A child interacting with the Goki Wooden Crane, demonstrating its operational size and how the lifting mechanism can be used to pick up small objects.

5. Operating Instructions

The Goki Wooden Crane is designed for intuitive play, simulating the functions of a real construction crane.

- **Movement:** The crane can be moved across flat surfaces using its wheels. Encourage pushing or pulling from the base for stability.
- **Rotation:** The crane's boom and tower can typically rotate 360 degrees on its base. Gently turn the upper section to position the hook over desired objects.

- **Lifting Mechanism:** Use the winding handle (usually located on the side of the tower) to raise or lower the hook. Turn clockwise to lift and counter-clockwise to lower.
- **Attaching Objects:** The hook is designed to pick up small, lightweight objects. The included lifting platform can be used to transport miniature cargo.



Figure 5.1: Close-up of a child engaging with the crane's hook and lifting mechanism, demonstrating the interactive nature of the toy.

6. Maintenance

Proper care will ensure the longevity of your Goki Wooden Crane Toy.

- **Cleaning:** Wipe the toy with a damp cloth. Do not immerse in water or use harsh cleaning agents, as this may damage the wood or paint.
- **Storage:** Store the toy in a dry place, away from direct sunlight and extreme temperatures, to prevent warping or fading of the wood.
- **Inspection:** Periodically check the string of the pulley system for fraying and the wheels for smooth operation.

7. Troubleshooting

Problem	Possible Cause	Solution
Crane is unstable or wobbly.	Loose connections or uneven surface.	Ensure all screws (if any) are tightened. Place on a flat, stable surface.
Hook mechanism is stiff or not moving.	String tangled or mechanism obstructed.	Untangle the string. Check for any small objects obstructing the winding mechanism.
Wheels are not rolling smoothly.	Debris caught in wheels or axle.	Remove any debris. Ensure axles are not bent.

If you encounter issues not listed here, please refer to the support section.

8. Specifications

- **Model Number:** 55937
- **Brand:** Goki
- **Dimensions (L x W x H):** 100 x 32 x 100 cm (approximately 39.4 x 12.6 x 39.4 inches)
- **Weight:** Approximately 508.02 grams (1.12 pounds)
- **Recommended Age:** 3 years and up
- **Main Material:** Solid Maple Wood, Beech
- **Number of Pieces:** 1 (main assembly)
- **Assembly Required:** Minimal (product comes largely pre-assembled)
- **Batteries Required:** No
- **Educational Value:** Creativity, fine motor skills, imaginative play
- **Origin:** Handcrafted and hand-painted in Germany

9. Warranty and Support

Goki products are known for their quality and durability. Specific warranty details may vary by region and retailer. Please retain your proof of purchase for any warranty claims.

For product support, inquiries, or to report any issues, please contact the retailer where the product was purchased or visit the official Goki website for contact information. Information regarding spare parts availability is not provided in the product specifications.

© 2024 Goki. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question