Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Demert 52134

Demert Nail Enamel Dryer Spray Instruction Manual

Model: 52134

1. Introduction

The Demert Nail Enamel Dryer Spray is a professional finishing spray formulated to accelerate the drying process of nail enamel. It helps prevent smearing and saves time during manicures. This product also contains beneficial ingredients such as dl-Panthenol, organic protein, and mink oil to condition cuticles and nails.

Key Features:

- Professional manicurist finishing spray with dl-Panthenol
- Fast drying, non-smearing formula
- Conditions cuticles and nails with organic protein and Mink Oil



An image of the Demert Nail Enamel Dryer Spray in a red aerosol can. The label clearly displays the brand 'DeMert' and product name 'nail enamel Dryer', along with descriptions like 'MANICURIST'S FINISHING SPRAY' and key ingredients such as 'dl-PANTHENOL, ORGANIC PROTEIN, MINK OIL'. It also highlights 'Fast Drying' and 'Non-Smearing' properties, and its ability to 'Conditions Cuticles and Nails'. The net weight is stated as 212g (7.5 OZ).

2. Setup

Before using the Demert Nail Enamel Dryer Spray, ensure your workspace is well-ventilated. Shake the can gently for a few seconds before each use to ensure proper mixing of the contents. Apply your nail enamel as usual, ensuring each coat is applied evenly. Allow the final coat of nail enamel to set for a brief moment (approximately 30-60 seconds) before applying the dryer spray.

3. Operating Instructions

1. **Prepare Nails:** After applying your final coat of nail enamel, wait for approximately 30-60 seconds to allow the polish to slightly set.
2. **Shake Can:** Gently shake the Demert Nail Enamel Dryer Spray can.

3. **Apply Spray:** Hold the can upright, approximately 6-8 inches (15-20 cm) away from your nails.
4. **Spray Evenly:** Apply a short, even burst of spray over each nail. Avoid holding the can too close or spraying excessively, as this may affect the nail enamel finish, potentially causing pitting or dullness.
5. **Allow to Dry:** Allow a few moments for the spray to work and the enamel to dry. The drying time may vary depending on the thickness of your nail enamel coats.
6. **Repeat (if necessary):** If additional drying is desired, apply another short burst after a minute or two.

Important: For best results, use in a well-ventilated area. Do not spray near open flames or heat sources.

4. Maintenance

To ensure the longevity and proper function of your Demert Nail Enamel Dryer Spray, follow these maintenance guidelines:

- **Storage:** Store the spray can in a cool, dry place, away from direct sunlight, heat, and extreme temperatures.
- **Nozzle Care:** Ensure the nozzle is clear before and after each use. If the nozzle becomes clogged, gently clean it with a small amount of nail polish remover on a cotton swab. Ensure no liquid enters the can during cleaning.
- **Disposal:** Dispose of empty cans according to local regulations for aerosol products.

5. Troubleshooting

Issue	Possible Cause	Solution
Nail enamel appears pitted or uneven after spraying.	Spray applied too close or too heavily.	Hold the can 6-8 inches away and use short, light bursts.
Spray does not dry nails effectively.	Nail enamel not set, can empty, or nozzle clogged.	Allow polish to set for 30-60 seconds. Check can contents. Clean nozzle as per Maintenance section.
Nozzle leaks or clogs.	Residue buildup or internal defect.	Clean nozzle thoroughly. If leaking persists, discontinue use and contact customer support.

6. Specifications

- **Brand:** Demert
- **Item Form:** Spray
- **Item Weight:** 1.2 Pounds
- **Liquid Volume:** 221 Milliliters (7.5 Ounce)
- **Model Number:** 52134
- **Package Dimensions:** 8.7 x 5.79 x 2.56 inches
- **Specialty:** Protein
- **Manufacturer:** Demert
- **UPC:** 688047736559

7. Warranty and Support

No specific warranty information is provided with this product. For product support, inquiries, or to report any issues, please contact the manufacturer, Demert, directly through their official customer service channels.

© 2025 Demert. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NFVH284

More documents and user manuals: **https://manuals.plus/**