Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Emerson MWG9115SB

Emerson MWG9115SB Microwave Oven User Manual

Model: MWG9115SB

Introduction

This manual provides essential information for the safe and efficient operation of your Emerson MWG9115SB Microwave Oven. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Emerson MWG9115SB Microwave Oven, showcasing its grilling capability with a roasted chicken inside.

Important Safety Information

WARNING: To reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy, read all instructions before using the appliance.

- Always ensure proper ventilation around the microwave.

- Do not operate the oven if it is damaged.
- Do not attempt to service or repair the oven yourself.
- This appliance is designed for residential use only.
- Keep out of reach of children. The child-safe lock feature should be utilized.

Setup and Installation

The Emerson MWG9115SB is a countertop microwave oven. Follow these steps for proper setup:

1. **Unpacking:** Carefully remove all packaging materials and accessories. Inspect the oven for any damage, such as dents or a broken door. Do not install if damaged.
2. **Placement:** Place the microwave on a flat, stable surface that can support its weight (approximately 36 pounds). Ensure there is adequate space for ventilation: at least 4 inches (10 cm) of clearance on the top, sides, and rear.
3. **Power Connection:** Plug the microwave into a grounded 110V AC outlet. Do not use extension cords.
4. **Turntable Installation:** Place the turntable ring inside the oven cavity, then position the glass turntable securely on top of the ring.



Image: The microwave oven positioned on a kitchen countertop with its door open, revealing the interior and removable glass turntable.



Image: Dimensional view of the microwave oven, indicating its width (20.6"), depth (17.3"), and height (12.8").

Operating Instructions

Your Emerson MWG9115SB Microwave Oven offers various cooking functions, including microwave, grill, and combination cooking.

Control Panel Overview



Image: Detailed view of the microwave's control panel, highlighting the digital display and various function buttons.

- **LED Display:** Shows time of day, cooking time, and program indicators.
- **Number Pad (0-9):** Used to enter cooking times, weights, and select pre-programmed recipes.
- **Time Cook:** For manual microwave cooking.
- **Weight/Time Defrost:** For defrosting food by weight or time.
- **Power:** Adjusts microwave power levels (11 levels available).
- **Dinner Plate, Popcorn, Potato, Frozen Vegetable, Beverage, Meat:** Pre-programmed recipe buttons.
- **Grill/Combo:** Selects grill or combination cooking modes.

- **Clock/Kitchen Timer:** Sets the clock or functions as a standalone kitchen timer.
- **Stop/Clear:** Stops cooking or clears settings.
- **Start/+30Sec:** Starts cooking or adds 30 seconds to cooking time.

Microwave Cooking

1. Place food in a microwave-safe container on the glass turntable.
2. Close the door.
3. Press **TIME COOK**.
4. Enter desired cooking time using the number pad (e.g., 1-0-0 for 1 minute).
5. Press **POWER** to adjust power level (default is 100%). Use number pad to select level (e.g., 5 for 50% power).
6. Press **START/+30Sec** to begin cooking.

Grill Function

The grill function is ideal for browning and crisping food. Use the included metal grill rack for best results.



Image: Visual examples of dishes prepared using the grill function, including a wire rack accessory.

1. Place food on the grill rack, then place the rack on the glass turntable.
2. Close the door.
3. Press **GRILL/COMBO** once for pure grill mode.
4. Enter desired grilling time using the number pad.
5. Press **START/+30Sec** to begin grilling.

Pre-Programmed Recipes

The microwave features 9 pre-programmed recipes for common foods:

- Popcorn

- Potato
- Frozen Pizza
- Frozen Vegetable
- Beverage
- Dinner Plate
- Meat/Chicken
- Meat/Beef
- Meat/Pork

1. Place food in the oven.
2. Press the corresponding pre-programmed recipe button (e.g.,**POPCORN**).
3. Press **START/+30Sec**. The oven will automatically set the appropriate cooking time and power level.

Defrosting

You can defrost food by weight or by time.

- **Weight Defrost:** Press **WEIGHT/TIME DEFROST** once, enter the food's weight, then press**START/+30Sec**.
- **Time Defrost:** Press **WEIGHT/TIME DEFROST** twice, enter the defrosting time, then press**START/+30Sec**.

Child Safety Lock

To activate the child safety lock, press and hold the**STOP/CLEAR** button for 3 seconds. The display will show "LOCK". To deactivate, press and hold **STOP/CLEAR** again for 3 seconds.

Product Overview Video

Your browser does not support the video tag.

Video: An official product overview of the Emerson 1.2 Cu. Ft. 1100W Griller Microwave Oven, demonstrating its features and capabilities, including the powerful grill, pre-programmed recipes, and removable glass turntable for easy cleaning.

Care and Maintenance

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your microwave oven.

- **Cleaning the Interior:** After each use, wipe the interior with a damp cloth and mild detergent. For stubborn stains, a microwave-safe cleaner can be used. Ensure the oven is unplugged before cleaning.
- **Cleaning the Exterior:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Turntable and Grill Rack:** The glass turntable and metal grill rack are removable for easy cleaning. They can be washed with warm, soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the oven.
- **Odor Removal:** To remove odors, combine a cup of water with a few slices of lemon or a tablespoon of vinegar in a microwave-safe bowl. Microwave on high for 2-3 minutes, then let it sit for 5 minutes before wiping the interior.

Troubleshooting Guide

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Oven does not start.	Power cord not securely plugged in; Door not closed properly; Fuse blown or circuit breaker tripped; Child safety lock is active.	Ensure plug is firmly in outlet; Close door securely; Check household fuse/circuit breaker; Deactivate child safety lock by holding STOP/CLEAR for 3 seconds.
Food is not cooking or heating properly.	Incorrect cooking time/power level set; Food not suitable for microwave cooking; Turntable not rotating.	Adjust time/power; Use microwave-safe cookware; Ensure turntable is correctly placed and not obstructed.
Sparking or arcing inside the oven.	Metal objects in the oven; Food residue buildup; Damaged oven interior.	Remove all metal objects; Clean oven interior thoroughly; If damage persists, discontinue use and contact service.
Oven light not working.	Light bulb burned out.	Contact qualified service personnel for bulb replacement. Do not attempt to replace yourself.

Product Specifications

Feature	Detail
Model Number	MWG9115SB
Capacity	1.2 Cubic Feet
Microwave Power Output	1100 Watts
Power Levels	11 Microwave Power Levels, 1 Pure Grill Power Level
Voltage	110 Volts
Product Dimensions (W x D x H)	20.6 x 17.3 x 12.8 inches
Item Weight	36 pounds
Color	Stainless Steel / Black
Installation Type	Countertop
Special Features	Child Safety Lock, Defrost, Shortcut Keys, Digital Timer, Removable Glass Turntable, Grill Function
Included Components	Microwave Oven, Glass Turntable, Grill Rack

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the official Emerson website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: Emerson Radio
Website: www.emersonradio.com
User Manual (PDF): For a downloadable PDF version of this manual, please visit:Emerson MWG9115SB User Manual PDF

© 2024 Emerson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NN7C4TW

More documents and user manuals: **https://manuals.plus/**