Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEYBLADE A7652000

Instruction Manual

Beyblade Legends Beybattle Tops BB-59 Burn Fireblaze 135MS Top

Model: A7652000

1. Introduction

The Beyblade Legends Beybattle Tops BB-59 Burn Fireblaze 135MS Top is a high-performance spinning top designed for competitive play. This top is engineered for stamina, allowing for extended spin times during battles. It is part of the Beyblade Legends series, offering a unique combination of parts for strategic customization and enhanced battling capabilities.



Image: The Beyblade Legends Burn Fireblaze 135MS Top, showcasing its assembled form.

2. Safety Information

- Recommended for ages 8 years and up.
- Do not aim at eyes or face.
- Use only official Beyblade components.
- Do not modify the top or launcher.
- Play in a safe, open area, preferably in a Beyblade Beystadium (sold separately).
- Keep small parts away from young children to prevent choking hazards.

3. Parts List

The Beyblade Legends Burn Fireblaze 135MS Top consists of five primary components:

- **Face Bolt:** The top-most part, often featuring a unique design.
- **Energy Ring: Fireblaze:** The transparent or translucent ring that sits below the Face Bolt.
- **Fusion Wheel: Burn:** The main metal part that provides weight and impact.
- **Spin Track: 135:** A mid-profile track that connects the Fusion Wheel to the Performance Tip.
- **Performance Tip: Metal Spike (MS):** The bottom-most part that determines the top's movement and stamina.



Image: Disassembled components of the Beyblade Burn Fireblaze 135MS Top, including the launcher and ripcord.

4. Setup

Follow these steps to assemble your Beyblade top:

1. Attach the Performance Tip (Metal Spike) to the Spin Track (135).
2. Connect the Fusion Wheel (Burn) to the assembled Spin Track and Performance Tip.
3. Place the Energy Ring (Fireblaze) on top of the Fusion Wheel.
4. Secure all parts by twisting the Face Bolt onto the top until it clicks into place. Ensure all components are tightly secured for optimal performance.

5. Operating Instructions

To launch your Beyblade top:

1. Insert the ripcord into the launcher.
2. Attach the assembled Beyblade top to the launcher by aligning the grooves and twisting until it locks.
3. Hold the launcher firmly at arm's length over a Beyblade Beystadium.
4. Pull the ripcord swiftly and forcefully to launch the top into the stadium.
5. Observe the battle. The Burn Fireblaze 135MS is designed for stamina, aiming to out-spin opponents.

6. Maintenance

Proper maintenance ensures the longevity and performance of your Beyblade top:

- After each use, wipe down the Beyblade top with a dry, soft cloth to remove dust and debris.
- Store the top and its components in a clean, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping the top on hard surfaces, as this can damage the components, especially the Performance Tip.
- Regularly check for any loose parts and re-tighten the Face Bolt if necessary.

7. Troubleshooting

Top does not spin properly or stops quickly:

- Ensure all parts are securely assembled and the Face Bolt is tightened.
- Check the Performance Tip for any damage or wear. A worn tip can affect spin stability.
- Verify that the ripcord is fully inserted into the launcher and pulled with sufficient force.
- Ensure the battle surface is flat and clean.

Difficulty attaching top to launcher:

- Make sure the top is aligned correctly with the launcher's grooves before twisting to lock.
- Check for any obstructions or damage on either the top's connection point or the launcher.

8. Specifications

Feature	Detail
Product Name	Beyblade Legends Beybattle Tops BB-59 Burn Fireblaze 135MS Top
Model Number	A7652000
Brand	BEYBLADE (Hasbro)
Product Dimensions	1.61 x 5.51 x 8.27 inches
Item Weight	3.2 ounces
Performance Type	Stamina
Recommended Age	8 years and up

9. Warranty and Support

This product is manufactured by Hasbro under license. For information regarding warranty coverage, product defects, or replacement parts, please refer to the official Hasbro customer service channels or visit their official website. Keep your proof of purchase for any warranty claims.
For further assistance or inquiries, please contact the manufacturer's customer support. Contact details can typically be found on the product packaging or the official brand website.

© 2024 BEYBLADE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00NQFFQVY

More documents and user manuals: **https://manuals.plus/**