I.SOUND ISOUND-6346

iSound PopDrop Wireless Speaker User Manual

Model: ISOUND-6346
Brand: I.SOUND

Introduction

This manual provides instructions for the iSound PopDrop Wireless Speaker, a compact Bluetooth speaker designed for portable audio playback and speakerphone functionality. Please read this manual thoroughly before using your device to ensure proper operation and to maximize its lifespan.



Figure 1: The iSound PopDrop Wireless Speaker in blueberry color, shown next to a US quarter to illustrate its compact size.

Package Contents

- iSound PopDrop Wireless Speaker
- USB Charging Cable
- Color-coordinated Wrist Strap



Figure 2: The iSound PopDrop Wireless Speaker shown in its retail box, indicating the product and its accessories.

Product Overview

Familiarize yourself with the various parts of your PopDrop speaker.



Figure 3: Side view of the speaker, highlighting the Micro USB charging port and 3.5mm audio input jack.



Figure 4: Bottom view of the speaker, showing the power button, volume controls, and play/pause button.

- **Speaker Grille:** Front surface for audio output.
- **LED Indicator:** Displays power and Bluetooth status.
- **Micro USB Port:** For charging the speaker.
- **3.5mm Audio Input:** For connecting non-Bluetooth devices.
- **Power Button:** Turns the speaker on or off.
- **Volume Buttons:** Adjusts audio volume.
- **Play/Pause Button:** Controls audio playback and call functions.
- **Microphone:** For speakerphone functionality.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the Micro USB port on the speaker and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The LED indicator will show charging status. A full charge takes approximately 90 minutes and provides up to 3 hours of playback time.

2. Powering On/Off

- To power on, press and hold the Power button until the LED indicator lights up.
- To power off, press and hold the Power button again until the LED indicator turns off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and within 33 feet (10 meters) of your Bluetooth-enabled device.
2. The speaker will automatically enter pairing mode, indicated by a flashing LED.
3. On your device, navigate to the Bluetooth settings and search for available devices.
4. Select "PopDrop" from the list of found devices.
5. Once paired, the LED indicator will stop flashing and remain solid. You are now connected and ready to play audio.

Note: The speaker will attempt to reconnect to the last paired device automatically when powered on.

Operating Instructions

Playing Audio

- After successful Bluetooth pairing, open your preferred music application on your device and begin playback.
- Press the Play/Pause button on the speaker to pause or resume audio playback.

Volume Control

- Press the '+' button to increase volume.
- Press the '-' button to decrease volume.
- Volume can also be adjusted directly from your connected device.

Speakerphone Function

When connected via Bluetooth, the PopDrop speaker can be used as a speakerphone.

- **Answering a Call:** Press the Play/Pause button once to answer an incoming call.
- **Ending a Call:** Press the Play/Pause button once during a call to end it.
- **Rejecting a Call:** Press and hold the Play/Pause button for approximately 2 seconds to reject an incoming call.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use harsh chemicals or abrasive cleaners.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in use for extended periods. Store in a cool, dry place.
- **Storage:** When not in use, store the speaker in a clean, dry environment away from extreme temperatures.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable.
Cannot pair with Bluetooth device.	◦ Ensure the speaker is in pairing mode (flashing LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device (within 33 feet / 10 meters). ◦ Turn off and on both the speaker and your device's Bluetooth. ◦ Forget "PopDrop" from your device's Bluetooth list and try pairing again.

Problem	Solution
No sound or low volume.	◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the speaker is properly paired and connected. ◦ Check if the audio source on your device is playing.
Poor audio quality.	◦ Move the speaker closer to your device to reduce interference. ◦ Ensure there are no obstructions between the speaker and your device. ◦ Try playing a different audio source.

Specifications

Model Number	ISOUND-6346
Bluetooth Version	V2.1
Transmission Range	Up to 33 feet (10 meters)
Battery Type	Rechargeable 300mA Lithium-ion
Playback Time	Up to 3 hours
Charge Time	Approximately 90 minutes
Audio Output Mode	Stereo
Item Weight	141 g
Manufacturer	DreamGEAR (CE)
UPC	845620063468

Safety Information

Please read and follow these safety guidelines to prevent damage to your device or injury to yourself.

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause harm.
- Keep the speaker away from heat sources, direct sunlight, and flammable materials.
- Dispose of the battery and speaker according to local regulations. Do not dispose of in household waste.
- Avoid listening to audio at excessively high volumes for prolonged periods to prevent hearing damage.

Warranty and Support

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service. Keep your purchase receipt as proof of purchase.
Manufacturer: DreamGEAR (CE)
Brand Website: www.isound.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question