Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Brother DCP-J100

Brother DCP-J100 Colour Multifunction Ink Tank Printer User Manual

Model: DCP-J100

1. Introduction

This manual provides essential instructions for setting up, operating, and maintaining your Brother DCP-J100 Colour Multifunction Ink Tank Printer. Please read this manual thoroughly before using the printer to ensure correct operation and to prevent damage.

The Brother DCP-J100 is an all-in-one inkjet printer designed for home and office use, offering print, scan, and copy functionalities. It features an ink tank system for cost-effective printing.

2. Safety Information

Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury.

- Do not place the printer in an unstable location.
- Do not block or cover the slots and openings in the cabinet.
- Use only the power cord supplied with the printer.
- Do not allow water or other liquids to spill into the printer.
- Keep the printer away from heat sources and direct sunlight.
- Unplug the printer from the electrical outlet before cleaning.

3. Package Contents

Verify that all items are included in the box:

- Brother DCP-J100 Printer
- Power Cord
- Set of Ink Bottles (Black, Cyan, Magenta, Yellow)
- USB Cable (may not be included in all regions)
- Installation CD-ROM (for drivers and software)
- Quick Setup Guide and User Manual (this document)

4. Setup

4.1 Unpacking the Printer

Carefully remove the printer from its packaging. Remove all protective tapes and packing materials from the exterior and interior of the printer.



Image 1: Brother DCP-J100 Printer. This image shows the compact design of the multifunction printer, highlighting its main body and the visible ink tank system on the front right side.

4.2 Installing Ink

1. Open the ink tank cover located on the front of the printer.
2. Uncap the ink bottles (LC539XL for Black, LC535XL for Cyan, Magenta, Yellow).
3. Carefully pour the corresponding color ink into each tank, ensuring not to overfill.
4. Close the ink tank cover securely.

4.3 Loading Paper

1. Pull out the paper tray completely from the printer.
2. Adjust the paper guides to the size of the paper you are loading (e.g., A4).
3. Load up to 100 sheets of plain paper or envelopes into the tray.
4. Gently push the paper tray back into the printer.

4.4 Connecting to Power

Connect the power cord to the printer and then to a wall outlet. Press the power button to turn on the printer.

4.5 Driver Installation

Insert the installation CD-ROM into your computer's CD/DVD drive and follow the on-screen instructions. Alternatively, download the latest drivers from the official Brother support website.

5. Operating the Printer

5.1 Printing Documents

From your computer, open the document or image you wish to print. Select **Print** from the application's menu. Choose the Brother DCP-J100 as your printer and adjust settings as needed (e.g., paper size, print quality, color/monochrome). Click **Print**.

5.2 Scanning Documents

Place the document face-down on the scanner glass. On your computer, open the Brother ControlCenter software or a scanning

application. Select **Scan** and choose your desired settings (e.g., resolution, file type, destination). Click **Scan** to begin.

5.3 Copying Documents

Place the document face-down on the scanner glass. On the printer's control panel, select **Copy**. Use the navigation buttons to select the number of copies and other settings (e.g., color/mono). Press **Start** to initiate copying.

6. Maintenance

6.1 Replacing Ink

When an ink tank runs low, the printer will display a warning. Purchase genuine Brother LC539XL (Black) and LC535XL (Cyan, Magenta, Yellow) ink bottles. Follow the ink installation steps (Section 4.2) to refill the tanks.

6.2 Cleaning the Printer

- **Exterior:** Wipe the exterior of the printer with a soft, lint-free cloth.
- **Scanner Glass:** Use a soft, dry cloth to clean the scanner glass. For stubborn marks, use a small amount of glass cleaner applied to the cloth, not directly to the glass.
- **Print Head:** If print quality degrades (streaks, missing colors), perform a print head cleaning cycle from the printer's maintenance menu or through the printer driver software on your computer.

6.3 Clearing Paper Jams

If a paper jam occurs, the printer's display will indicate the location. Carefully open the relevant covers (e.g., rear cover, front cover) and gently pull out the jammed paper in the direction of the paper path. Ensure no torn pieces remain inside.

7. Troubleshooting

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Printer not turning on	Power cord not connected; power outlet faulty	Check power cord connection; try a different outlet
Poor print quality	Low ink; clogged print head; incorrect paper type	Refill ink tanks; perform print head cleaning; use recommended paper
Paper jam	Improperly loaded paper; foreign object in paper path	Reload paper correctly; remove jammed paper carefully (refer to Section 6.3)
Cannot scan	Driver not installed; incorrect software settings	Install scanner drivers; check scanning software settings

8. Specifications

Feature	Specification
Model	DCP-J100
Functions	Print, Scan, Copy (All In One)

Feature	Specification
Printing Technology	Inkjet
Print Speed (Mono/Color)	Up to 27 ppm (mono) / 10 ppm (color) A4
Print Resolution	Up to 1200 x 6000 dpi
Scan Type	Flatbed
Copy Speed (Black and White)	Up to 27 ppm
Max Input Sheet Capacity	100 sheets
Paper Sizes Supported	A4, Envelopes, Plain Paper
Ink Colors	Black, Cyan, Magenta, Yellow
Connectivity	USB (1 Total USB Port)
Duplex Printing	Manual
Item Weight	8.05 kg

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Brother website. Technical support and driver downloads are available on the Brother support website. You can also contact Brother customer service for assistance.
Brother Support Website: www.brother.in (or your regional Brother website)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00OA0YBFQ

More documents and user manuals: **https://manuals.plus/**