Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney BMJ70

Disney Toy Story Buzz Lightyear Action Figure BMJ70 User Manual

Model: BMJ70 | Brand: Disney

1. Introduction

This manual provides essential information for the safe and proper use of your Disney Toy Story Buzz Lightyear Action Figure, model BMJ70. Please read these instructions carefully before use and retain them for future reference.

2. Safety Information

WARNING: Not suitable for children under 36 months (3 years) due to small parts that may present a choking hazard.

- Always supervise children during play.
- Inspect the figure regularly for any damage. Discontinue use if damaged.
- Keep away from extreme heat sources and open flames.
- Clean only with a damp cloth; do not immerse in water.

3. Product Overview

The Buzz Lightyear action figure is a detailed representation of the Space Ranger from Disney's Toy Story. It stands approximately 24 cm tall and is designed for imaginative play.


SPACE RANGER
LIGHTYEAR
LASER

Figure 3.1: Front view of the Buzz Lightyear action figure, showing its iconic white, green, and purple suit with the right arm raised.



Figure 3.2: Front view of the Buzz Lightyear action figure with its wings folded and retracted, showcasing the detailed chest plate and helmet.



Figure 3.3: Rear view of the Buzz Lightyear action figure, highlighting the jetpack details and warning labels on the wings.

4. Setup

The Buzz Lightyear action figure comes fully assembled and ready for play. No additional setup or assembly is required.

1. Remove the figure from its packaging.
2. Ensure all packaging materials are safely discarded, especially plastic bags, to prevent suffocation hazards.

5. Operating Instructions

This action figure is designed for interactive play. It features articulated joints and a button-activated mechanism.

1. **Articulation:** The figure has movable arms, legs, and head, allowing for various poses. Gently move the limbs to position the figure as desired.
2. **Wing Deployment:** The figure's wings can be deployed for flight poses. Locate the button on the chest (refer to

Figure 5.1) and press it to extend the wings.



Figure 5.1: A hand demonstrating how to press the button on Buzz Lightyear's chest to activate features, such as wing deployment.
Note: This specific model (BMJ70) does not include electronic sounds, lights, or remote control functionality.

6. Maintenance and Care

- **Cleaning:** Wipe the figure with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent material degradation and color fading.
- **Handling:** Avoid excessive force when moving articulated parts to prevent breakage.

7. Troubleshooting

This product is a simple action figure with minimal moving parts. Most issues can be resolved with basic inspection.

- **Stiff Joints:** If joints are stiff, gently manipulate them. Avoid forcing movement.
- **Wings not deploying:** Ensure the chest button is pressed firmly. Check for any obstructions around the wing mechanism.
- **Damage:** If the figure is visibly damaged (e.g., broken limbs, cracks), discontinue use to prevent injury.

8. Specifications

Feature	Detail
Model Number	BMJ70
Brand	Disney
Product Dimensions (L x W x H)	28 x 11 x 28 cm (approximately 11 x 4.3 x 11 inches)
Weight	550 grams (approximately 1.2 lbs)
Recommended Age	3 years and up
Main Material	Plastic
Assembly Required	No
Batteries Required	No
Number of Pieces	1

9. Warranty and Support

Information regarding specific warranty terms for this product is not available in the provided documentation. For support or inquiries, please refer to the retailer or manufacturer's official customer service channels.
Spare parts availability information is currently unavailable.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00OUQHG6Q

More documents and user manuals: **https://manuals.plus/**