Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Renkforce E0111H

Renkforce E0111H Thermo-Hygrometer User Manual

Model: E0111H

1. Introduction

Thank you for choosing the Renkforce E0111H Thermo-Hygrometer. This device is designed to provide accurate measurements of indoor temperature and humidity, helping you monitor your environment for optimal comfort and health. Its compact and portable design, along with a foldable stand, makes it suitable for various settings, including travel.
Key features include:

- Temperature and Humidity Display
- Min/Max Value Memory
- Comfort Level Indicator
- Alarm with Snooze Function
- Foldable Stand/Protective Cover

2. Safety Information

Please read and understand the following safety instructions before using the device:

- Keep the device away from water and high humidity to prevent damage.
- Avoid exposing the device to extreme temperatures (hot or cold) or direct sunlight.
- Do not attempt to disassemble or modify the device. This will void the warranty.
- Dispose of used batteries according to local regulations. Do not mix old and new batteries, or different types of batteries.
- Keep batteries out of reach of children.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

3. Package Contents

Please check the package contents upon unpacking:

- 1 x Renkforce E0111H Thermo-Hygrometer
- This User Manual

Note: Batteries are not included and must be purchased separately.

4. Device Overview

4.1 Front View



Figure 1: Front view of the Renkforce E0111H Thermo-Hygrometer. The display shows temperature, humidity, time, and comfort level indicators.

The front of the device features a clear LCD display that shows the current temperature, relative humidity, time, and comfort level icons. The foldable cover acts as a stand when open and protects the screen when closed.

4.2 Rear View and Controls



Figure 2: Rear view of the Renkforce E0111H Thermo-Hygrometer, highlighting the battery compartment and control buttons.

The rear of the device houses the battery compartment and the control buttons:

- **MODE/SET:** Used to switch between display modes (e.g., time, alarm) and to enter/confirm settings.
- **UP:** Used to increase values during settings or to toggle functions.
- **DOWN:** Used to decrease values during settings or to toggle functions.
- **MAX/MIN:** Used to view the maximum and minimum recorded temperature and humidity values.
- **SNOOZE:** Used to activate the snooze function when the alarm sounds.

5. Setup

5.1 Battery Installation

1. Open the battery compartment cover located on the back of the device.
2. Insert the required batteries (e.g., 2 x AAA, type not specified in product data, please check device for markings) according to the polarity (+/-) indicated inside the compartment.
3. Close the battery compartment cover securely.
4. The device will power on automatically and display current temperature, humidity, and default time.

Important: *Ensure correct battery polarity. Remove batteries if the device will not be used for an extended period.*

6. Operating Instructions

6.1 Setting Time and Date

1. In normal time display mode, press and hold the**MODE/SET** button for a few seconds until the time display starts flashing.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press **MODE/SET** again to confirm the hour and move to setting the minutes.
4. Use the **UP** or **DOWN** buttons to adjust the minutes.
5. Continue pressing **MODE/SET** to cycle through and set the year, month, and day using the**UP** or **DOWN** buttons.
6. Press **MODE/SET** one last time to exit the setting mode.

6.2 Setting the Alarm

1. From the normal time display, press the **MODE/SET** button once to switch to alarm display mode (usually indicated by an alarm icon).
2. Press and hold the **MODE/SET** button until the alarm time starts flashing.
3. Use the **UP** or **DOWN** buttons to set the desired alarm hour.
4. Press **MODE/SET** to confirm the hour and move to setting the alarm minutes.
5. Use the **UP** or **DOWN** buttons to set the desired alarm minutes.
6. Press **MODE/SET** to confirm and exit alarm setting mode.
7. To activate/deactivate the alarm, press the **UP** button while in alarm display mode. An alarm icon will appear/disappear on the display.

6.3 Using the Snooze Function

When the alarm sounds, press the **SNOOZE** button to temporarily silence the alarm. The alarm will sound again after a few minutes (typical snooze duration is 5-10 minutes, may vary). To turn off the alarm completely, press any other button.

6.4 Viewing Min/Max Values

Press the **MAX/MIN** button once to display the maximum recorded temperature and humidity since the last reset. Press it again to display the minimum recorded values. Press it a third time to return to current readings.
To reset the Min/Max values, press and hold the **MAX/MIN** button while the maximum or minimum values are displayed.

6.5 Temperature Unit Selection (°C/°F)

While in normal display mode, press the **UP** button to toggle between Celsius (°C) and Fahrenheit (°F) temperature units.

6.6 Comfort Level Indicator

The device displays icons to indicate the comfort level based on current temperature and humidity:

- **:)** (Smiling Face): Indicates a comfortable environment.
- **:|** (Neutral Face): Indicates a normal or slightly less comfortable environment.
- **:(** (Frowning Face): Indicates an uncomfortable environment (too dry, too humid, too hot, or too cold).

7. Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or chemical agents.
- **Battery Replacement:** When the display becomes dim or the device stops functioning, replace the batteries with new ones. Follow the battery installation steps in Section 5.1.
- **Storage:** If not in use for a long period, remove the batteries and store the device in a cool, dry place away from direct sunlight.

8. Troubleshooting

Problem	Possible Cause	Solution
No display or dim display	Batteries are dead or incorrectly installed.	Replace batteries with new ones, ensuring correct polarity.

Problem	Possible Cause	Solution
Incorrect temperature/humidity readings	Device is placed near a heat source, vent, or in direct sunlight. Sensor is obstructed.	Relocate the device to a stable environment away from direct influences. Ensure sensors are clear. Allow time for readings to stabilize.
Buttons not responding	Low battery power. Device malfunction.	Replace batteries. If problem persists, contact customer support.

9. Specifications

Model:	E0111H
Brand:	Renkforce
Dimensions (L x W x H):	17 x 9 x 1 cm (approximate)
Weight:	120 Grams (approximate, without batteries)
Color:	Black
Mounting Type:	Table Mount (with foldable stand)
Power Source:	Batteries (type not specified, typically AAA)
Temperature Range:	Not specified (typical indoor range)
Humidity Range:	Not specified (typical indoor range)

10. Warranty and Support

Renkforce products are manufactured to high-quality standards. For warranty information, please refer to the terms and conditions provided at the point of purchase or visit the official Renkforce website. If you encounter any issues or require technical assistance, please contact your retailer or Renkforce customer support.
Please retain your proof of purchase for warranty claims.

© 2023 Renkforce. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00PH8M2S8

More documents and user manuals: **https://manuals.plus/**