Creda 842618-FDU20IX

Indesit FDU20IX Fan Oven Element 2500W User Manual

Model: 842618-FDU20IX | Brand: Creda

Introduction

This manual provides essential information for the proper use, installation, and maintenance of your Creda Indesit FDU20IX Fan Oven Element. Please read this manual thoroughly before attempting any installation or maintenance to ensure safety and optimal performance.

Product Overview

The Indesit FDU20IX Fan Oven Element is a crucial component designed to provide heat within your oven. It is a circular heating element, also known as a round element, specifically engineered for compatibility with the Indesit FDU20IX oven model.



Figure 1: Indesit FDU20IX Fan Oven Element. This image shows the circular heating element with its two electrical terminals at the top, ready for connection.

Key Features:

- Designed specifically for Indesit FDU20IX oven models.
- 2500W power rating for efficient heating.
- Circular design with 2 turns for even heat distribution.

Specifications

Attribute	Value
Brand	Creda
Model Number	842618-FDU20IX
ASIN	B00PHDNA5W
Power Rating	2500W
Element Length	230mm
Element Width	235mm
Bracket Length	60mm
Tag Length	37mm
Turns	2

Installation and Setup

Disclaimer: Installation of oven heating elements should only be performed by a qualified technician or an individual with appropriate electrical knowledge. Always disconnect the appliance from the main power supply before attempting any installation or repair.

General Installation Steps (Consult your oven's specific service manual for detailed instructions):

1. **Safety First:** Ensure the oven is completely unplugged from the wall socket or the circuit breaker is switched off.
2. **Access the Element:** Depending on your oven model, you may need to remove the back panel of the oven or access the element from inside the oven cavity.
3. **Disconnect Wiring:** Carefully note or photograph the existing wiring connections to the old element. Disconnect the wires from the terminals.
4. **Remove Old Element:** Unscrew or unclip the old heating element from its mounting points.
5. **Install New Element:** Position the new Creda Indesit FDU20IX Fan Oven Element in place, ensuring it fits securely.
6. **Connect Wiring:** Reconnect the electrical wires to the new element's terminals, ensuring a secure and correct connection as noted in step 3.
7. **Reassemble:** Reattach any panels or covers that were removed.
8. **Test:** Restore power to the oven and test the heating function to ensure the new element is working correctly.

Operating Considerations

Once installed, the fan oven element operates automatically as part of your oven's heating system. No specific user operation is required for the element itself beyond the normal use of your oven. Ensure your oven's thermostat and fan are functioning correctly for optimal performance of the heating element.

Maintenance

The fan oven element is a sealed unit and generally requires no routine maintenance. However, to prolong its lifespan and ensure efficient operation:

- **Keep Oven Clean:** Regularly clean your oven cavity to prevent grease and food debris buildup, which can affect element performance and potentially cause damage.
- **Avoid Physical Damage:** Be careful not to strike or bend the element during cleaning or when placing/removing oven racks and dishes.
- **Professional Inspection:** If you suspect any issues with the element, such as uneven heating or failure to heat, consult a qualified appliance technician.

Troubleshooting

If your oven is not heating correctly after element replacement, consider the following common issues:

- **No Heat:**
  - Check if the oven is properly plugged in and the circuit breaker has not tripped.
  - Verify that the element's electrical connections are secure and correct.
  - Ensure the oven's thermostat is set correctly and is functioning.
- **Uneven Heating:**
  - This could indicate a partial failure of the element or an issue with the oven's fan or thermostat.
  - Inspect the element for any visible breaks or deformities.
- **Burning Smell:**
  - A new element may produce a slight burning smell during its first few uses as manufacturing residues burn off. This is usually normal and should dissipate.
  - If the smell persists or is accompanied by smoke, immediately disconnect power and inspect for foreign objects or incorrect installation.

For persistent issues or if you are unsure about any step, it is highly recommended to contact a certified appliance repair professional.

Warranty and Support

This product is covered by the standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact the retailer. For technical support or assistance with installation, please contact the Creda customer service or a qualified appliance technician.
You can often find contact information for support on the original packaging or the retailer's website where the product was purchased.

© 2024 Creda. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question