Lennox 61W89

Lennox 61W89 1/4HP 208/230V 1PH Fan Motor Instruction Manual

Model: 61W89 | Brand: Lennox

Introduction

This manual provides essential information for the safe and effective installation, operation, and maintenance of the Lennox 61W89 1/4HP 208/230V 1PH Fan Motor. This motor is designed for use in HVAC systems, specifically as a condenser fan motor, ensuring proper airflow and system efficiency. Please read this manual thoroughly before proceeding with any installation or service.



Figure 1: Lennox 61W89 1/4HP 208/230V 1PH Fan Motor. This image shows the cylindrical motor body with a shaft extending from one end, typically used to drive a fan blade in HVAC condenser units.

Safety Information

WARNING: Electrical shock hazard. Disconnect all power to the unit before installing or servicing this motor. Failure to do so may result in serious injury or death.

- Installation and servicing must be performed by a qualified HVAC technician or electrician.
- Always wear appropriate personal protective equipment (PPE), including safety glasses and electrical gloves.
- Ensure all wiring connections comply with local and national electrical codes.
- Verify the motor's voltage and horsepower ratings match the system requirements before installation.
- Do not operate the motor if it is damaged or if any components are missing.

Package Contents

Upon opening the package, verify that the following item is present and undamaged:

- Lennox 61W89 1/4HP 208/230V 1PH Fan Motor

Specifications

Feature	Specification
Brand	Lennox
Model Number	61W89
Horsepower (HP)	1/4 HP (0.25 HP)
Voltage	208/230 Volts
Phase	1 Phase (1PH)
Diameter	5 5/8 inches
Material	Lead (referring to internal components/windings)
Item Weight	11.8 Pounds
UPC	066255141820

Setup and Installation

NOTE: Installation should only be performed by a qualified technician. Improper installation can lead to equipment damage, electrical shock, or fire.

1. **Power Disconnection:** Ensure all electrical power to the HVAC unit is completely disconnected at the main breaker or fuse box before beginning any work. Verify with a voltage tester.
2. **Access Old Motor:** Carefully open the access panel of the condenser unit to expose the existing fan motor.
3. **Document Wiring:** Take clear photos or make a detailed diagram of the existing motor's wiring connections before disconnecting them. Note the color and terminal location of each wire.
4. **Remove Old Motor:** Disconnect all electrical wires, remove any mounting bolts or clamps securing the old motor, and carefully remove it from the unit. Note the orientation of the motor and fan blade.
5. **Install New Motor:** Mount the new Lennox 61W89 motor in the same position and orientation as the old motor. Secure it with appropriate fasteners.
6. **Connect Wiring:** Refer to your documented wiring diagram and the motor's wiring schematic (if provided) to connect the electrical wires to the new motor. Ensure all connections are secure and insulated.
7. **Check Fan Blade:** Reattach the fan blade to the motor shaft, ensuring it is properly balanced and secured. Verify that the blade spins freely without obstruction and has adequate clearance.
8. **Close Unit:** Replace all access panels and secure them.
9. **Restore Power:** Restore electrical power to the HVAC unit.
10. **Test Operation:** Initiate a cooling cycle and observe the fan motor's operation. Check for proper rotation, unusual noises, or vibrations.

Operating Instructions

The Lennox 61W89 fan motor operates automatically as part of your HVAC system's cooling cycle. Once properly installed and wired, it will engage when the thermostat calls for cooling, driving the condenser fan blade to dissipate heat from the refrigerant.

- Ensure the HVAC system's thermostat is set to the desired cooling temperature.
- The motor should start smoothly and run quietly.
- Monitor the system for the first few cycles after installation to confirm proper function.

Maintenance

Regular maintenance helps ensure the longevity and efficient operation of your fan motor. Always disconnect power before performing any maintenance.

- **Annual Inspection:** Have a qualified technician inspect the motor and fan assembly annually, typically as part of routine HVAC system maintenance.
- **Cleaning:** Keep the motor and fan blades free of dirt, dust, and debris. Accumulated grime can reduce efficiency and cause overheating. Use a soft brush or compressed air for cleaning.
- **Check Connections:** Periodically check electrical connections for tightness and signs of corrosion.
- **Listen for Noise:** Pay attention to any unusual noises (grinding, squealing) which may indicate a bearing issue or other problem.

Troubleshooting

If you encounter issues with your Lennox 61W89 fan motor, refer to the following common problems and solutions. For complex issues, contact a qualified technician.

Problem	Possible Cause	Solution
Motor does not start	No power, faulty capacitor, wiring error, seized bearings.	Check power supply and circuit breaker. Inspect capacitor for bulging or leaks (replace if faulty). Verify wiring connections. If bearings are seized, motor replacement may be necessary.
Motor runs but fan blade does not turn	Loose fan blade, obstruction.	Disconnect power. Tighten fan blade set screw. Remove any obstructions.
Unusual noise or vibration	Loose mounting, unbalanced fan blade, worn bearings.	Disconnect power. Check motor mounting bolts for tightness. Inspect fan blade for damage or imbalance. Worn bearings typically require motor replacement.
Motor overheats	Poor airflow, dirty coils, incorrect voltage, prolonged operation.	Ensure condenser coils are clean and free of obstructions. Verify correct voltage supply. Ensure proper system sizing and operation.

Warranty and Support

For warranty information or technical support regarding your Lennox 61W89 fan motor, please contact Lennox customer service or refer to the official Lennox website. Keep your purchase receipt and model number handy when contacting support.
Lennox Official Website: www.lennox.com

© 2024 Lennox Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question