Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zippo 041689494100

Zippo 49410 Ellis Island - Statue Lighter User Manual

Model: 041689494100

Product Overview

The Zippo 49410 Ellis Island - Statue lighter is a classic windproof lighter featuring a distinctive design commemorating Ellis Island and the Statue of Liberty. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your Zippo lighter.

A silver Zippo lighter featuring a green circular emblem with the Statue of Liberty, the words 'Ellis Island Gateway to America', 'In God We Trust', and '1986'. This image illustrates the unique design of the Zippo 49410 model.

Setup

Your Zippo lighter is shipped without fuel for safety reasons. Before first use, it must be filled with Zippo premium lighter fluid.

Filling Instructions:

1. Remove the lighter insert from the case.
2. Lift the felt pad on the bottom of the insert to expose the packing material.
3. Slowly saturate the packing material with Zippo lighter fluid until the cotton is saturated. Do not overfill.
4. Replace the felt pad and insert the lighter back into the case.
5. Wipe any excess fluid from the lighter and your hands before igniting.

Caution: Lighter fluid is highly flammable. Keep away from open flames and heat sources. Use in a well-ventilated area. Keep out of reach of children.

Operating Instructions

Once filled with fuel, your Zippo lighter is ready for use.

Ignition:

1. Open the lid of the lighter.
2. Spin the flint wheel downwards with your thumb to create a spark.

3. The wick will ignite.
4. To extinguish the flame, close the lid firmly. The flame will go out due to lack of oxygen.

Warning: Do not keep the lighter lit for extended periods. The metal case will become hot. Always close the lid to extinguish the flame.

Maintenance

Regular maintenance ensures optimal performance and longevity of your Zippo lighter.

Refueling:

- Refuel your lighter when the flame becomes weak or fails to ignite consistently. Follow the "Filling Instructions" in the Setup section.

Flint Replacement:

- When the flint wheel no longer produces sparks, the flint needs to be replaced.
- Remove the lighter insert.
- Unscrew the flint spring from the bottom of the insert.
- Remove the old flint (and any remaining flint dust).
- Insert a new Zippo flint into the flint tube.
- Replace the flint spring and tighten it securely.

Wick Replacement:

- If the wick becomes black or frayed, it may need trimming or replacement.
- Using tweezers, gently pull the wick up until a clean section is exposed.
- Trim the black portion of the wick with scissors, ensuring it is level with the top of the chimney.
- If the wick is too short to pull up, it needs to be replaced. This involves disassembling the packing material inside the insert.

Troubleshooting

Problem	Possible Cause	Solution
Lighter won't light.	No fuel.	Refill with Zippo lighter fluid.
Lighter won't light.	Worn flint.	Replace flint.
Lighter won't light.	Wick needs attention.	Trim or replace wick.
Flame is weak or inconsistent.	Low fuel or dirty wick.	Refuel or trim/replace wick.
Lid is loose.	Hinge pin may be bent or worn.	Contact Zippo customer service for repair.

Specifications

Brand: Zippo

Model Number: 041689494100

ASIN: B00RM3IZCI

Style:	Modern
UPC:	041689494100
First Available:	December 30, 2014

Warranty and Support

Zippo lighters are known for their durability and come with a famous lifetime guarantee. If your Zippo lighter ever fails to work, you can send it to Zippo for repair, free of charge.
For detailed warranty information, repair instructions, or to contact customer support, please visit the official Zippo website or refer to the documentation included with your purchase.
Official Zippo Website: www.zippo.com

© 2024 Zippo Manufacturing Company. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00RM3IZCI

More documents and user manuals: **https://manuals.plus/**