Whirlpool 481246678412

Whirlpool Ikea Microwave Turntable Plate Instruction Manual

Model: 481246678412 | Brand: Whirlpool

Introduction

This manual provides essential information for the proper installation, use, and maintenance of your Whirlpool Ikea Microwave Turntable Plate. Please read these instructions carefully to ensure safe and efficient operation and to prolong the lifespan of your product.

Product Overview

The microwave turntable plate is a crucial component designed to ensure even heating of food by rotating it during the cooking process. This specific model is a replacement glass plate with a diameter of 250 mm, compatible with various Whirlpool and Ikea microwave ovens, including those that use the MBI 500 S part.



Image 1: The Whirlpool Ikea Microwave Turntable Plate. This image displays the clear glass plate with three central indentations designed to fit onto the microwave's rotating support.

Compatibility

This turntable plate is designed as a replacement part for specific microwave models. Verify the diameter and model number of your existing turntable or microwave oven before installation.

- **Diameter:** 250 mm
- **Compatible Brands:** Whirlpool, Ikea
- **Known Compatible Models/Part Numbers:** MBI 500 S, 481246678412

If you are unsure about compatibility, consult your microwave oven's original manual or contact the manufacturer with your microwave's model number.

Setup and Installation

1. **Unpack:** Carefully remove the new turntable plate from its packaging. Inspect it for any damage during transit.
2. **Clean Microwave:** Ensure the inside of your microwave oven, especially the turntable support area, is clean and free of food debris.
3. **Position Support Ring:** Place the microwave's roller ring (if applicable) correctly on the bottom of the microwave cavity. This ring supports the turntable plate.
4. **Install Turntable Plate:** Carefully place the glass turntable plate onto the central coupler (spindle) in the microwave oven. Ensure the indentations on the underside of the plate align properly with the coupler, allowing the plate to sit flat and securely.
5. **Test Rotation:** Gently rotate the plate by hand to confirm it moves freely and is properly seated.

Safety Precaution: Always ensure the microwave oven is unplugged before performing any installation or cleaning procedures inside the cavity.

Operating Instructions

Once installed, the turntable plate operates automatically with your microwave oven. It is designed to rotate food during cooking to ensure even heat distribution.

- Always place food containers centrally on the turntable plate.
- Avoid placing excessively heavy items on the plate, as this may strain the motor or cause the plate to crack.
- Ensure the plate is clean and dry before each use to prevent food residue from burning onto the surface.

Maintenance and Cleaning

Regular cleaning and proper maintenance will extend the life of your turntable plate and ensure hygienic operation.

- **Daily Cleaning:** After each use, wipe the plate with a damp cloth to remove any food splatters.
- **Deep Cleaning:** For stubborn food residues, the glass plate can be removed and washed by hand with warm, soapy water. It is also typically dishwasher safe.
- **Drying:** Ensure the plate is completely dry before placing it back into the microwave.
- **Inspection:** Periodically inspect the plate for any chips, cracks, or signs of wear. A damaged plate should be replaced immediately to prevent further issues or safety hazards.

Troubleshooting

Problem	Possible Cause	Solution
Turntable plate does not rotate.	Plate not seated correctly on the coupler or roller ring. Obstruction beneath the plate. Motor malfunction.	Re-seat the plate and roller ring. Check for and remove any debris. If the issue persists, consult a qualified technician.
Plate makes unusual noise during rotation.	Debris under the plate or roller ring. Damaged roller ring.	Clean the area beneath the plate. Inspect the roller ring for damage and replace if necessary.
Plate is chipped or cracked.	Impact damage. Thermal stress.	Replace the plate immediately. Do not use a damaged plate in the microwave.

Specifications

Brand: Whirlpool

Manufacturer: Elettrogea

Model Number: 481246678412

Item Weight: 2.1 kg

Diameter: 250 mm

Material: Glass

ASIN: B00SR6LMYW

First Available Date: 19 June 2017

Warranty and Support

This product is a replacement part. Warranty coverage, if any, is typically provided by the original manufacturer of the microwave oven or the seller of the replacement part. Please retain your proof of purchase.
For technical support or further inquiries regarding this turntable plate, please contact the seller or the manufacturer, Elettrogea, directly. Refer to the ASIN (B00SR6LMYW) and model number (481246678412) when seeking assistance.

© 2023 Elettrogea. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question