Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi ECOV311.BK

De'Longhi ECOV311.BK Espresso Machine User Manual

Model: ECOV311.BK

Introduction Safety Information Product Overview Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides essential information for the safe and efficient operation of your De'Longhi ECOV311.BK Espresso Machine. Please read these instructions carefully before using the appliance and keep them for future reference.
The De'Longhi ECOV311.BK is an elegant pump espresso machine designed to deliver perfect and authentic Italian espresso. It features a "Cappuccino System" that combines steam, air, and milk to produce a rich and creamy foam for delicate cappuccinos.

2. Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then

remove plug from wall outlet.

- Do not use appliance for other than intended use.

3. Product Overview

Familiarize yourself with the main components of your De'Longhi ECOV311.BK Espresso Machine.



Figure 3.1: Front view of the De'Longhi ECOV311.BK Espresso Machine, showcasing its elegant design, control buttons, portafilter, and drip tray. Two espresso cups are placed on the drip tray, and a glass of latte is beside the machine.

- **Control Panel:** Buttons for power, espresso shot, and steam.
- **Water Tank:** Removable tank for easy refilling. Capacity: 1.4 Liters.
- **Portafilter:** Holds ground coffee or ESE pods.
- **Steam Wand/Cappuccino System:** For frothing milk.
- **Drip Tray:** Collects excess liquid and is removable for cleaning.
- **Cup Warmer:** Top surface to pre-heat cups.


EASY SERVING ESPRESSO
E.S.E.



Figure 3.2: A hand demonstrating the removal of the transparent water tank from the rear of the espresso machine for refilling or cleaning.



Figure 3.3: The portafilter shown with a scoop of ground coffee being added, alongside an ESE (Easy Serving Espresso) pod, illustrating the machine's compatibility with both coffee types.

4. Initial Setup

1. **Unpacking:** Carefully remove the machine from its packaging. Remove all packing materials and ensure all components are present.
2. **First Use Cleaning:** Before first use, wash all removable parts (water tank, portafilter, filter baskets, drip tray) with warm water and mild detergent. Rinse thoroughly and dry.
3. **Filling the Water Tank:** Remove the water tank from the back of the machine. Fill it with fresh, cold drinking water up to the MAX level indicator. Replace the tank securely.
4. **Priming the Circuit:**
    - Place a container under the steam wand.
    - Plug the machine into a grounded power outlet.

- Press the power button to turn on the machine. The lights will flash as the machine heats up.
- Once the lights are steady, turn the steam knob to release water through the steam wand until a steady stream flows. Close the steam knob.
- Place a cup under the coffee spouts and press the espresso button to dispense water until a steady stream flows.

This process removes air from the circuit and prepares the machine for use.

5. Operating Instructions

5.1 Making Espresso

1. Ensure the water tank is filled.
2. Insert the desired filter basket into the portafilter (one cup or two cups).
3. Add ground coffee to the filter basket. For a single shot, use one level scoop (approx. 7g). For a double shot, use two level scoops (approx. 14g). Tamp the coffee firmly. Alternatively, insert an ESE pod.
4. Attach the portafilter to the brewing head by aligning it and rotating it to the right until it is securely locked.
5. Place one or two pre-heated cups under the coffee spouts.
6. Press the **Espresso** button (single or double shot, depending on your filter basket). The machine will start brewing.
7. Once the desired amount of espresso is dispensed, the machine will stop automatically.

5.2 Frothing Milk for Cappuccino/Latte



Figure 5.1: A hand holding a milk frothing pitcher under the steam wand, demonstrating the process of frothing milk for beverages like cappuccino or latte.

1. Fill a pitcher with cold milk (preferably skim or semi-skimmed) up to one-third full.
2. Press the **Steam** button. The light will flash until the machine reaches the correct steam temperature, then it will become steady.
3. Submerge the steam wand tip just below the surface of the milk.
4. Slowly turn the steam knob to release steam. Move the pitcher up and down gently to incorporate air and create foam.
5. Once the milk has frothed to your desired consistency and temperature, turn the steam knob off.
6. Immediately clean the steam wand with a damp cloth to prevent milk residue from drying.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your espresso machine.

- **Daily Cleaning:**

- Empty and rinse the drip tray after each use.
- Remove used coffee grounds from the portafilter and rinse the portafilter and filter basket under running water.
- Wipe down the exterior of the machine with a damp cloth.
- Clean the steam wand immediately after frothing milk. Purge a small amount of steam to clear any internal milk residue.

- **Weekly Cleaning:**
  - Wash the water tank with warm soapy water.
  - Clean the shower screen (where the portafilter attaches) with a brush to remove coffee residue.

- **Descaling:**
  The frequency of descaling depends on water hardness and usage. It is recommended to descale every 2-3 months or when the descaling indicator light (if present) illuminates.

  a. Use a suitable descaling solution recommended by De'Longhi.
  b. Follow the instructions on the descaling solution packaging and your machine's specific descaling procedure (refer to the full manual for detailed steps).
  c. Rinse the machine thoroughly after descaling by running several cycles of fresh water through it.

7. Troubleshooting

Problem	Possible Cause	Solution
No coffee dispensed.	Water tank empty; machine not primed; coffee too finely ground or tamped too hard; clogged filter.	Fill water tank; prime the circuit; use coarser grind or less tamping pressure; clean filter basket.
Coffee is too weak/watery.	Coffee too coarsely ground; not enough coffee; insufficient tamping.	Use finer grind; increase coffee quantity; tamp more firmly.
Steam wand not producing steam.	Machine not at steam temperature; steam wand clogged.	Wait for steam light to become steady; clean steam wand hole with a pin.
Machine leaks water.	Water tank not seated correctly; drip tray full.	Re-seat water tank; empty and clean drip tray.

For more complex issues, please contact customer support or refer to the full product manual.

8. Technical Specifications

Feature	Detail
Model Number	ECOV311.BK
Brand	De'Longhi
Color	Black/Dark Brown
Water Tank Capacity	1.4 Liters
Power	1100 Watts

Feature	Detail
Voltage	240 Volts
Material	Stainless Steel
Auto Shut-off	Yes
Coffee Input Type	Ground Coffee, ESE Pods
Dimensions (L x W x H)	29.01 x 26.01 x 31.5 cm
Item Weight	4.1 Kilograms

9. Warranty and Support

De'Longhi products are manufactured to the highest quality standards. This product comes with a manufacturer's warranty covering defects in materials and workmanship.

- **Spare Parts Availability:** 2 Years
- For warranty claims, technical support, or to purchase spare parts, please visit the official De'Longhi website or contact their customer service.
- Keep your proof of purchase for warranty purposes.

© 2025 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00T0HSAGA

More documents and user manuals: **https://manuals.plus/**