TOTO TCF6531

TOTO Washlet S2 Bidet Toilet Seat

Model: TCF6531#SS4

Introduction

This instruction manual provides essential information for the safe and efficient installation, operation, and maintenance of your TOTO Washlet S2 bidet toilet seat, model TCF6531#SS4. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: TOTO Washlet S2 Bidet Toilet Seat (Harvest Brown)

Setup and Installation

Proper installation is crucial for the functionality and safety of your Washlet. If you are unsure about any steps, please consult a qualified professional.

1. Tools Required

The following tools are generally required for installation:

- Phillips screwdriver
- Adjustable wrench (monkey wrench)
- Water container (for draining residual water)

- Cloth or rag

2. Pre-Installation Checks

Before beginning installation, verify the following:

1. **Toilet Space:** Ensure adequate space around the toilet. For a wall-mounted tank type, confirm at least 200mm clearance to the left and 160mm to the right from the mounting holes to the tank. From the center of the toilet bowl, ensure at least 280mm clearance to both the left and right.
2. **Toilet Bowl Size:** Measure the distance from the edge of the toilet bowl to the mounting holes. This model is compatible with both regular (440mm) and elongated (470mm) toilet bowl sizes. The mounting hole spacing should be 140mm.

3. Mounting Plate Installation

Insert the included mounting bolt set into the left and right holes of the toilet bowl. Secure the main unit mounting plate from underneath. The mounting plate can be slid to adjust its position for a perfect fit.

4. Water Supply Connection

First, close the water stopcock to prevent water flow. Then, attach the branch fitting to the water stopcock. Connect the tank water supply hose and the main unit water supply hose to the branch fitting. Ensure all connections are tight to prevent leaks.

5. Power Connection

An electrical outlet with a ground terminal is required. This unit cannot be installed in a bathroom without such an outlet. The water supply hose can accommodate distances up to approximately 2 meters. Connect the power cord to the grounded outlet. After connecting the main unit water supply hose and power, open the water stopcock and perform a test run to confirm proper operation.

Operating Instructions

Your TOTO Washlet S2 is operated via a remote control, providing convenient access to various functions.



Figure 2: TOTO Washlet S2 Remote Control

Key Functions:

- **Premist:** Automatically sprays mist (tap water) onto the toilet bowl when you sit down, making it easier for dirt to wash away.
- **Warm Air Drying:** Provides a comfortable warm air stream for drying after washing.
- **Deodorization:** Reduces unpleasant odors in the toilet bowl.
- **Remote Control:** All functions are easily accessible via the included remote control.

Maintenance and Cleaning

Regular cleaning ensures hygiene and extends the lifespan of your Washlet.

Daily Cleaning:

- Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners.
- The Premist function helps keep the bowl clean with each use.

Deep Cleaning:

For thorough cleaning, the main unit can be easily detached. Press the 'main unit detachment button' located on the right side of the unit to release the lock. Slide the main unit forward to remove it. This allows for easy cleaning of hard-to-reach areas.

Troubleshooting

If you encounter any issues with your TOTO Washlet S2, please refer to the comprehensive troubleshooting guide in the full product manual or contact TOTO customer support for assistance.

Specifications

Feature	Detail
Brand	TOTO
Model Number	TCF6531#SS4
Product Dimensions	18.8 x 39.1 x 53.1 cm
Item Weight	5.6 kg
Color	Harvest Brown
Power Source	Corded Electric
Voltage	100 Volts
Wattage	410 W
Special Feature	Deodorization
Shape	U-shaped

Warranty and Support

This product is eligible for an extended warranty program. By paying an additional warranty fee, the warranty period can be extended from 1 year to 5 years. To apply for the extended warranty, please use the application postcard included with the product or apply online.
For further assistance, technical support, or warranty claims, please contact TOTO customer service directly. Contact information can typically be found on the official TOTO website or in the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question