Supersonic SC-4009

Supersonic SC-4009 Tablet User Manual

Model: SC-4009

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Supersonic SC-4009 Tablet. Please read this manual thoroughly before using your device to ensure proper functionality and longevity.

The Supersonic SC-4009 is a 9-inch tablet featuring a WVGA display, 1GB RAM, 8GB internal storage, and runs on the Android 4.4 KitKat operating system. It is designed for everyday use, offering features such as a capacitive touchscreen, quad-core processor, and built-in cameras.

What's in the Box

Upon unboxing your Supersonic SC-4009 Tablet, please verify that all the following items are included:

- One 9-inch Android 4.4 Tablet with Quad Core Processor
- AC Charger
- Earphones
- USB Cable
- User Manual (this document)

Product Overview



Figure 1: Front view of the Supersonic SC-4009 Tablet. This image shows the tablet's 9-inch screen with a colorful background, indicating its display capabilities. The front-facing camera is visible at the top center of the bezel.



Figure 2: Back view of the Supersonic SC-4009 Tablet. The rear panel features a textured black finish for improved grip and durability. The rear camera lens is located in the upper right corner, and a speaker grille is visible towards the bottom.




Figure 3: Side view of the Supersonic SC-4009 Tablet. This image illustrates the placement of physical buttons and ports, including the power button, volume controls, Micro USB input, 3.5mm earphone jack, and Micro SD card slot.

Setup Guide

1. Initial Charging

Before first use, fully charge your tablet. Connect the supplied AC charger to the tablet's Micro USB port and plug it into a power outlet. The battery indicator on the screen will show charging status. A full charge typically takes approximately 3 hours.

2. Powering On/Off

- **To Power On:** Press and hold the Power button (refer to Figure 3 for location) until the Supersonic logo appears on the screen.
- **To Power Off:** Press and hold the Power button until a power-off menu appears. Select "Power off" and confirm.

3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup wizard. This includes selecting your language, connecting to a Wi-Fi network, and setting up your Google account. A Google account is required to download applications from the Google Play Store.

4. Inserting a Micro SD Card (Optional)

The tablet supports Micro SD cards up to 32 GB for expanded storage. Locate the Micro SD card slot (refer to Figure 3). Gently insert the Micro SD card with the gold contacts facing down until it clicks into place. To remove, gently push the card in until it springs out.

Operating Instructions

1. Navigating the Android Interface

Your tablet runs on Android 4.4 KitKat. Navigation is primarily done via the capacitive touchscreen. Common gestures include:

- **Tap:** To select an item, open an app, or press a button.
- **Tap and Hold:** To access contextual menus or move icons.
- **Swipe:** To scroll through pages, lists, or switch between home screens.
- **Pinch-to-Zoom:** To zoom in or out on images or web pages.

The navigation bar at the bottom of the screen typically includes Back, Home, and Recent Apps buttons.

2. Connecting to Wi-Fi

1. Go to **Settings**.
2. Select **Wi-Fi**.
3. Toggle Wi-Fi **On**.

4. Select your desired network from the list.
5. Enter the password if prompted, then tap **Connect**.

3. Using Cameras

The tablet features a 0.3 MP front camera and a 2.0 MP rear camera. Open the "Camera" application to take photos or record videos. You can switch between front and rear cameras within the app interface.

4. Bluetooth Connectivity

The tablet supports Bluetooth 4.0, allowing connection to compatible external devices such as headphones, speakers, or keyboards.

1. Go to **Settings**.
2. Select **Bluetooth**.
3. Toggle Bluetooth **On**.
4. The tablet will scan for available devices. Select your device from the list to pair.

5. Media Playback

The tablet supports various media file types including MP3, WMA, AAC, WAV, OGG, FLAC for audio, and VP8, H264, H.263, VC1, WMV 7/8 for video. It also supports JPEG, BMP, JPG, and GIF image formats. Use the pre-installed media player apps or download alternatives from the Google Play Store.

Maintenance and Care

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Do not use abrasive cleaners or solvents.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the tablet regularly.
- **Software Updates:** Periodically check for system updates in **Settings > About tablet > System updates** to ensure optimal performance and security.
- **Data Backup:** Regularly back up important data to a computer or cloud storage to prevent data loss.

Troubleshooting

Problem	Possible Cause	Solution
Tablet does not power on.	Battery is drained.	Connect the AC charger and allow the tablet to charge for at least 30 minutes before attempting to power on again.
Screen is unresponsive or frozen.	Software glitch or temporary system error.	Perform a force restart by pressing and holding the Power button for approximately 10-15 seconds until the tablet shuts down and restarts.

Problem	Possible Cause	Solution
Wi-Fi connection issues.	Incorrect password, out of range, or router issue.	Ensure the Wi-Fi password is correct. Move closer to the Wi-Fi router. Restart your Wi-Fi router. Try forgetting the network in tablet settings and reconnecting.
Tablet is slow or lagging.	Too many apps running, low storage, or outdated software.	Close unnecessary applications. Clear cache and data for frequently used apps. Uninstall unused apps. Check for system updates. Consider a factory reset as a last resort (backup data first).
Screen rotation issues (e.g., stuck in portrait).	Auto-rotate setting disabled or software malfunction.	Check if auto-rotate is enabled in the quick settings panel or in **Settings > Display > Auto-rotate screen**. If enabled and still not working, try restarting the tablet.

Technical Specifications

Feature	Detail
Model Number	SC-4009
Display Size	9 Inches
Screen Resolution	1024x600 (WVGA)
Operating System	Android 4.4 KitKat
Processor	1.5 GHz Quad-core Cortex A7
RAM	1 GB DDR_SDRAM
Internal Storage	8 GB (Flash Memory)
Expandable Storage	Micro SD card slot (up to 32 GB)
Front Camera	0.3 MP
Rear Camera	2.0 MP
Wireless Connectivity	802.11b/g/n Wi-Fi, Bluetooth 4.0
Ports	Micro USB input, 3.5 mm earphone jack
Battery Life	Approximately 3 Hours (Average)
Dimensions (LxWxH)	9.3 x 6.1 x 0.5 inches (approx. 23.6 x 15.5 x 1.3 cm)
Weight	1.4 pounds (approx. 0.64 kg)

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Supersonic website. Keep your purchase receipt as proof of purchase for warranty claims.

Online Resources:

- Supersonic Official Website: www.supersonicinc.com (*Note: This is a placeholder URL as no specific support link was provided in the product data. Users should verify the correct support URL.*)
- For product registration or frequently asked questions, please check the support section of the manufacturer's website.

© 2024 Supersonic. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question