Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jobar 017874820450

Jobar 2.5 Quart Ceramic Microwave Cooking Pot User Manual

Model: 017874820450

Introduction

Thank you for choosing the Jobar 2.5 Quart Ceramic Microwave Cooking Pot. This manual provides essential information for the safe and efficient use of your new cooking pot. Please read all instructions carefully before first use and retain this manual for future reference.
This cooking pot is designed for use in microwave ovens to facilitate faster and more efficient cooking of various foods. While referred to as a 'pressure cooker' in some contexts, its primary function is as a microwave-safe vessel that helps retain moisture and heat for improved cooking results.

Important Safety Instructions

- Always ensure the cooking pot is clean before use.
- Do not use the cooking pot on a stovetop, in a conventional oven, or under a broiler. It is designed exclusively for microwave use.
- Always use oven mitts or heat-resistant gloves when handling the hot cooking pot and lid after microwave use.
- Exercise caution when removing the lid, as steam will escape and can cause burns. Always open the lid away from your face and body.
- Do not overfill the cooking pot. Leave adequate space for food expansion during cooking.
- Inspect the cooking pot and lid for any damage before each use. Do not use if cracked or damaged.
- Keep out of reach of children.

Product Overview



Image: The Jobar 2.5 Quart Ceramic Microwave Cooking Pot, showing the main pot and its secure lid.

The Jobar 2.5 Quart Ceramic Microwave Cooking Pot consists of a main cooking vessel and a fitted lid. The lid is designed to create a sealed environment within the pot, helping to trap steam and heat for more efficient microwave cooking.

Setup

Before First Use:

1. Remove all packaging materials and labels from the cooking pot and lid.
2. Wash the cooking pot and lid thoroughly with warm, soapy water.
3. Rinse well and dry completely before storage or use.

Operating Instructions

Cooking with your Microwave Pot:

1. Place your food and any required liquids into the cooking pot. Do not fill above two-thirds capacity to allow for steam and food expansion.
2. Securely place the lid onto the cooking pot. Ensure it is properly seated to create a tight seal.
3. Place the cooking pot into your microwave oven.
4. Set your microwave to the desired power level and cooking time according to your recipe or food type. Cooking times may be shorter than conventional methods due to the pot's design.
5. Once cooking is complete, carefully remove the cooking pot from the microwave using oven mitts. The pot and its contents will be hot.
6. Allow the pot to rest for a few minutes to allow internal temperatures to equalize.
7. To open, carefully release the lid, directing any escaping steam away from your face and hands.
8. Serve food immediately or allow to cool as needed.

Care and Maintenance

Cleaning:

- The Jobar 2.5 Quart Ceramic Microwave Cooking Pot is dishwasher safe. Place on the top rack for best results.
- Alternatively, wash by hand with warm, soapy water and a non-abrasive sponge or cloth.
- Rinse thoroughly and dry completely before storing.
- Do not use abrasive cleaners, steel wool, or scouring pads, as these can damage the pot's surface.

Storage:

Store the clean, dry cooking pot and lid in a cool, dry place when not in use.

Troubleshooting

- **Food not cooking evenly:** Ensure food is cut into uniform pieces. Stir food halfway through cooking if possible. Check your microwave's power settings and adjust cooking time accordingly.
- **Lid difficult to remove after cooking:** Allow the pot to rest for a few minutes after cooking to allow steam to dissipate slightly. Always use oven mitts and open carefully.
- **Pot feels too hot:** This is normal for microwave cooking. Always use oven mitts when handling.

Specifications

Feature	Detail
Brand	Jobar
Model Number	017874820450
Capacity	2.5 Quarts
Material	Ceramic

Control Method	Touch (referring to microwave controls)
Operation Mode	Automatic (referring to microwave operation)
Dishwasher Safe	Yes
Item Weight	1.05 pounds
Package Dimensions	8.7 x 8.4 x 4.9 inches

Warranty and Support

For any questions, concerns, or support regarding your Jobar 2.5 Quart Ceramic Microwave Cooking Pot, please refer to the retailer where the product was purchased or contact the manufacturer directly. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00TSPHM72

More documents and user manuals: **https://manuals.plus/**