**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Stihl SG 11

# Stihl SG 11 Manual Handheld Sprayer User Manual

Model: SG 11

## INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Stihl SG 11 Manual Handheld Sprayer. Please read this manual thoroughly before first use and keep it for future reference.




*Image: The Stihl SG 11 Manual Handheld Sprayer, a white plastic bottle with a black pump handle and nozzle, featuring the "STIHL SG 11" logo on the side.*

## Safety Information

Always observe the following safety precautions to prevent injury or damage:

- Do not spray near face or eyes.
- Use in well-ventilated areas.
- Do not ingest any sprayed substances.
- Wear appropriate personal protective equipment (PPE) such as gloves and eye protection when handling chemicals.
- Keep out of reach of children and pets.
- Store the sprayer in a cool, dry place away from direct sunlight.

## Setup

1. **Unpacking:** Carefully remove all components from the packaging. Verify that all parts are present: sprayer bottle, pump assembly with handle, and nozzle.
2. **Assembly:**
    - Ensure the pump assembly is securely screwed onto the bottle.
    - Check that the nozzle is firmly attached to the spray wand.
3. **Filling the Tank:**
    - Unscrew the pump assembly from the bottle.
    - Pour the desired liquid into the tank, ensuring not to exceed the maximum fill line. The tank volume is 4.5 Liters.
    - *Note:* Always follow the instructions of the liquid being used for proper dilution and handling.
    - Screw the pump assembly back onto the bottle tightly to ensure an airtight seal.

## Operating Instructions

1. **Pressurizing the Sprayer:**
    - With the pump assembly securely attached, pump the handle up and down repeatedly.
    - Continue pumping until resistance is felt, indicating sufficient pressure has built up inside the tank. The maximum pressure is 29 PSI.
2. **Spraying:**
    - Aim the nozzle at the target area.
    - Press the trigger on the handle to release the spray.
    - To maintain consistent spray, periodically pump the handle to re-pressurize the tank.
3. **Adjusting the Spray Pattern:**
    - The spray tip on this model is **not adjustable**. It provides a consistent spray pattern suitable for general applications.
4. **Releasing Pressure:**
    - After use, always release any remaining pressure in the tank. This can typically be done by pressing the pressure release valve (if present) or by holding the trigger until all pressure is dissipated.

## Maintenance

Regular maintenance ensures the longevity and optimal performance of your sprayer.

- **Cleaning After Use:**
  - Empty any remaining liquid from the tank.
  - Rinse the tank thoroughly with clean water.
  - Pump clean water through the nozzle to flush out any residue.
  - Allow all components to air dry completely before storage.
- **Nozzle Cleaning:**
  - If the nozzle becomes clogged, remove it and clean it with the included cleaning kit or a fine wire.
  - Rinse thoroughly before reattaching.
- **Seal Inspection:**
  - Periodically inspect all seals and O-rings for wear or damage. Replace if necessary to maintain proper pressure.
- **Storage:**
  - Store the sprayer in a dry, frost-free environment.
  - Do not store with chemicals inside for extended periods.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| No pressure or low pressure | Loose pump assembly; Worn or dirty seals/O-rings; Insufficient pumping | Tighten pump assembly; Clean or replace seals/O-rings; Pump more vigorously until resistance is felt |
| No spray or weak spray | Clogged nozzle; Low pressure; Empty tank | Clean nozzle with cleaning kit; Re-pressurize the tank; Refill tank |
| Leaking from connections | Loose connections; Damaged seals/O-rings | Tighten all connections; Inspect and replace damaged seals/O-rings |

## Specifications

**Model Name:** SG 11

**Brand:** Stihl

**Tank Volume:** 4.5 Liters

**Material:** Plastic

**Power Source:** Manual

**Maximum Pressure:** 29 Pound per Square Inch (PSI)

**Included Components:** Cleaning Kit

**Item Weight:** 13.1 ounces

**Package Dimensions:** 12.28 x 8.23 x 5.71 inches

**UPC:** 886661023097

## Warranty and Support

For warranty information or technical support, please contact Stihl customer service directly or visit their official website. Keep your purchase receipt as proof of purchase.

*Note:* Specific warranty terms may vary by region and retailer. Refer to the documentation provided at the time of purchase for detailed warranty coverage.

© 2025 Stihl. All rights reserved.
This manual is for informational purposes only. Stihl reserves the right to make changes to product specifications without prior notice.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B00TXIODEE**

More documents and user manuals: **https://manuals.plus/**