Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GARMIN 010-12094-11

GARMIN Edge Remote Control User Manual

Model: 010-12094-11

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your GARMIN Edge Remote Control. This ANT+ compatible remote allows you to control your compatible GARMIN Edge device from a distance, enhancing convenience and safety during your rides.

2. Safety Information

- Always ensure the remote is securely mounted to your bicycle to prevent detachment during operation.
- Do not attempt to disassemble or modify the device. This may void your warranty and cause damage.
- Keep the device away from extreme temperatures and direct sunlight for prolonged periods.
- Dispose of batteries according to local regulations.

3. Package Contents

- GARMIN Edge Remote Control (Model 010-12094-11)
- Mounting Kit
- Documentation

4. Product Overview

The GARMIN Edge Remote Control is a compact, black, ANT+ enabled device designed for seamless interaction with your GARMIN Edge cycle computer. It features three distinct buttons for various functions.



Image: The GARMIN Edge Remote Control. This small, circular, black device features three tactile buttons. The top button has a square icon, the bottom-left button has a curved arrow icon, and the bottom-right button has a stacked squares icon. A small yellow indicator light is located in the center.

Button Functions:

- **Top Button (Square Icon):** Typically used for starting/stopping the timer or turning on the backlight.
- **Bottom-Left Button (Curved Arrow Icon):** Often assigned to manual lap acquisition or navigating backward through pages.
- **Bottom-Right Button (Stacked Squares Icon):** Primarily used for scrolling through training pages or navigating forward.

The remote is waterproof, allowing for reliable operation even in rainy conditions.

5. Setup

5.1 Mounting the Remote

1. Select a suitable location on your bicycle handlebars or stem for easy access.
2. Use the provided mounting kit to securely attach the remote. Ensure it is tight enough to prevent movement during rides but do not overtighten.

5.2 Pairing with Your Edge Device

The remote uses ANT+ technology to connect with compatible GARMIN Edge devices (e.g., Edge 1000J). Follow these steps to pair:

1. Ensure your Edge device is powered on and within 3 meters (10 feet) of the remote.
2. On your Edge device, navigate to the sensor settings menu.
3. Select 'Add Sensor' or 'Search for Sensors'.
4. Activate the remote by pressing any button. The Edge device should detect the remote.
5. Select the remote from the list of detected sensors on your Edge device to complete the pairing process.
6. Once paired, you can customize button functions through your Edge device's settings. Refer to your Edge device's manual for specific customization options.

6. Operating the Remote Control

Once paired, the remote control allows you to perform various actions on your Edge device without removing your hands from the handlebars. This includes:

- **Timer Control:** Start and stop your ride timer.
- **Backlight:** Activate the backlight on your Edge device for improved visibility.
- **Page Navigation:** Scroll through your customized training data pages.
- **Lap Function:** Mark manual laps during your activity.

The specific function of each button can be configured on your compatible Edge device.

7. Maintenance

7.1 Cleaning

Clean the remote control with a damp cloth. Do not use abrasive cleaners or solvents that could damage the device.

7.2 Battery Replacement

The remote control is powered by a replaceable coin cell battery. When the battery is low, the indicator light may flash, or the remote may become unresponsive. To replace the battery:

1. Locate the battery compartment cover on the back of the device.
2. Use a small coin or screwdriver to twist the cover counter-clockwise to unlock it.
3. Carefully remove the old battery.
4. Insert a new compatible coin cell battery (e.g., CR2032) with the positive (+) side facing up.
5. Replace the cover and twist it clockwise to secure.

8. Troubleshooting

- **Remote not pairing:** Ensure the remote is within range of the Edge device, the battery is charged, and no other ANT+ devices are interfering. Try restarting both the remote and the Edge device.
- **Buttons unresponsive:** Check the battery level. If the battery is low, replace it. Ensure the remote is properly paired.
- **Intermittent connection:** Ensure there are no obstructions between the remote and the Edge device. Avoid placing other electronic devices too close to the remote.

9. Specifications

Product Model Number	010-12094-11
Color	Black
Size	Small
Material	Other
Package Dimensions	17.1 x 16.3 x 5.9 cm
Weight	125.99 g

Connectivity	ANT+
Water Resistance	Yes (operable in rain)
UPC	753759133542

10. Warranty and Support

For warranty information and technical support, please refer to the official GARMIN website or contact GARMIN customer service. Keep your proof of purchase for warranty claims.
Official GARMIN Website: www.garmin.com

© 2023 GARMIN Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00U6VXK0K

More documents and user manuals: **https://manuals.plus/**