Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Warner Home Video B00UGQLCY6

Mad Max 2: The Road Warrior Blu-ray Disc User Manual

Model: B00UGQLCY6

1. Introduction

This manual provides essential instructions for the proper use and care of your Mad Max 2: The Road Warrior Blu-ray disc. Please read this guide thoroughly to ensure optimal viewing experience and longevity of your product.

2. Setup

To begin enjoying your Blu-ray disc, follow these simple steps:

1. **Prepare Your Blu-ray Player:** Ensure your Blu-ray player is connected to your television or display device and power source according to its own instruction manual.
2. **Power On:** Turn on your Blu-ray player and television/display device. Select the correct input source on your television for the Blu-ray player.
3. **Insert the Disc:** Gently remove the Mad Max 2: The Road Warrior Blu-ray disc from its case. Hold the disc by its edges to avoid touching the playback surface. Insert the disc into the disc tray or slot of your Blu-ray player with the label side facing up.
4. **Close Tray:** If your player has a disc tray, gently close it. The player should automatically begin reading the disc.

3. Operating

Once the disc is loaded, the main menu should appear. Use your Blu-ray player's remote control to navigate.

- **Play Movie:** Select "Play Movie" or a similar option from the main menu to start playback of the feature film.
- **Scene Selection:** Use the "Scene Selection" or "Chapters" option to jump to specific parts of the movie.
- **Audio/Subtitles:** Access the "Audio" or "Subtitles" menu to change language tracks or enable/disable subtitles. Available options may vary.
- **Special Features:** Explore the "Special Features" menu for bonus content, such as behind-the-scenes documentaries,

trailers, or interviews, if available on this disc.

- **Navigation:** Use the arrow keys on your remote to move between menu options and the "Enter" or "OK" button to make selections.

4. Maintenance

Proper care will extend the life of your Blu-ray disc and ensure consistent playback quality.

- **Handling:** Always hold the disc by its outer edges or by the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If the disc becomes dirty or smudged, gently wipe it with a soft, lint-free cloth. Wipe from the center of the disc outwards in a straight line, not in a circular motion. Do not use abrasive cleaners or solvents.
- **Storage:** Store the disc in its original case when not in use. Keep it away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Do not place the disc on rough surfaces or expose it to objects that could scratch it.

5. Troubleshooting

If you encounter issues during playback, consider the following common solutions:

- **Disc Not Playing:**
  - Ensure the disc is inserted correctly (label side up).
  - Check if the disc is clean and free of scratches or smudges. Clean if necessary.
  - Verify that your player is a Blu-ray player and not just a DVD player. Blu-ray discs require a compatible Blu-ray player.
  - Try playing another Blu-ray disc to determine if the issue is with the disc or the player.
- **Skipping or Freezing:**
  - Clean the disc thoroughly as described in the Maintenance section.
  - Ensure the disc is not warped or damaged.
  - Check for any firmware updates for your Blu-ray player, as outdated firmware can sometimes cause playback issues.
- **No Audio/Video:**
  - Confirm all cables (HDMI, audio) are securely connected between your Blu-ray player and your television/receiver.
  - Check the input source on your television.
  - Verify audio settings on your Blu-ray player and television.

6. Specifications

Media Format	Blu-ray
ASIN	B00UGQLCY6
Package Dimensions	6.77 x 5.31 x 0.39 inches
Item Weight	2.54 ounces

7. Warranty and Support

For information regarding warranty or customer support for your Blu-ray disc, please refer to the packaging or contact Warner Home Video directly. Specific warranty terms may vary based on region and retailer.
For general inquiries about your Blu-ray player, please consult the player's manufacturer manual or support channels.

© 2026 Warner Home Video. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00UGQLCY6

More documents and user manuals: **https://manuals.plus/**