Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ProFurnitureParts FLAT2BRS-LIM

ProFurnitureParts Limoss OEM Recliner 2-Button Round Electric Power Switch Handset with 5-Prong Plug Instruction Manual

1. Product Overview

The ProFurnitureParts Limoss OEM Recliner 2-Button Round Electric Power Switch Handset is designed as a direct replacement for electric recliners utilizing a 5-prong plug system. This handset provides simple and reliable control for reclining and returning to an upright position.

It is an OEM (Original Equipment Manufacturer) product by Limoss, ensuring compatibility and quality for your recliner.

2. Package Contents

- 1 x Limoss OEM Recliner 2-Button Round Electric Power Switch Handset with 5-Prong Plug

3. Specifications

Brand	ProFurnitureParts
Model Name	Limoss Flat 2 Button Power Recliner Round Switch
Item Model Number	FLAT2BRS-LIM
Color	Black
Connector Type	5-Pin Plug
Cable Length	Approximately 4-5 feet (as observed in videos)
Product Dimensions	30 x 2 x 2 inches (packaging/overall, switch diameter approx. 2.6 inches)
Item Weight	3.84 ounces

4. Safety Information

- Always disconnect power to the recliner before attempting any installation or replacement.
- Ensure all connections are secure and free from damage.
- Do not operate the recliner if any part of the wiring or switch is damaged.
- Keep children and pets away from moving parts of the recliner during operation.
- If you are unsure about any step, consult a qualified technician.

5. Setup and Installation

This 2-button round electric power switch is designed for easy installation as a replacement part. Follow these steps:

1. **Disconnect Power:** Unplug your recliner from the wall outlet to ensure safety during installation.
2. **Locate Existing Switch:** Identify the current 2-button round switch on your recliner. It is typically located on the side of the chair.
3. **Remove Old Switch:** Carefully remove the old switch. This may involve unscrewing it or gently prying it out of its housing. Note how the old switch's cable is routed.
4. **Disconnect Old Plug:** Trace the cable from the old switch to where it connects to the recliner's motor or power system. Disconnect the 5-prong plug.
5. **Connect New Switch:** Take the new ProFurnitureParts Limoss 2-button switch. Connect its 5-prong plug to the corresponding port on your recliner's motor or power system. Ensure the connection is firm and secure.
6. **Secure New Switch:** Route the new switch's cable as the old one was, and secure the new round switch into its housing.
7. **Restore Power:** Once the new switch is securely installed and all connections are firm, plug your recliner back into the wall outlet.

Visual Guide: 5-Prong Plug



This image shows the 5-prong plug connector, which connects the handset to the recliner's motor system. Ensure your recliner uses this type of connector for compatibility.

Visual Guide: Limoss Switch



This image displays the top view of the 2-button round switch, showing the two distinct buttons for operation.

Installation Video Example

Your browser does not support the video tag.

This video demonstrates the connection of a 5-pin recliner switch, similar to the ProFurnitureParts Limoss model, to a recliner's power system. It highlights the ease of plugging in the connector.

Recliner Operation with 2-Button Handset

Your browser does not support the video tag.

This video illustrates the functionality of a 2-button round hand control handset, showing how to extend and retract the recliner mechanism. It provides a visual reference for expected operation.

6. Operation

The 2-button round electric power switch is straightforward to operate:

- **Extend Recliner:** Press and hold one of the buttons (typically the top or front button, depending on installation) to extend the recliner footrest and backrest. Release the button when the desired position is reached.
- **Retract Recliner:** Press and hold the other button (typically the bottom or rear button) to retract the recliner footrest and return the backrest to the upright position. Release the button when the desired position is reached.

The buttons provide continuous control, allowing you to stop the recliner at any point during its movement.

7. Maintenance

- **Cleaning:** Wipe the switch surface with a clean, dry cloth. Avoid using liquid cleaners directly on the switch to

prevent electrical damage.

- **Cable Inspection:** Periodically inspect the cable for any signs of wear, cuts, or damage. If damage is found, discontinue use and replace the switch.
- **Connection Check:** Ensure the 5-prong plug remains securely connected to the recliner's motor system.

8. Troubleshooting

Problem	Possible Cause	Solution
Recliner does not move.	No power to the recliner.	Check if the recliner is plugged into a working wall outlet. Ensure the power supply (if separate) is connected and functioning.
Switch buttons are unresponsive.	Loose or disconnected 5-prong plug.	Disconnect power, then check the 5-prong plug connection to the motor. Reconnect firmly.
Recliner moves intermittently.	Damaged cable or faulty connection.	Inspect the cable for visible damage. Ensure all connections are secure. If damage is present, replace the switch.

9. Warranty and Support

Warranty: ProFurnitureParts offers a warranty for 90 days from the date of purchase for this product.

For technical support, troubleshooting assistance, or warranty claims, please contact ProFurnitureParts customer service through your original point of purchase or visit the official ProFurnitureParts website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00UXQSGC0

More documents and user manuals: **https://manuals.plus/**