Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi FH1363

De'Longhi Multifry XL Fryer FH1363 Instruction Manual

Model: FH1363

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your De'Longhi Multifry XL Fryer FH1363. Please read all instructions carefully before using the appliance and retain this manual for future reference. The De'Longhi Multifry XL Fryer FH1363 is designed to prepare a variety of dishes, including fresh and frozen potatoes, pizza, cake, risotto, stew, fish, and meat, using minimal oil. Its efficient system ensures even cooking, resulting in crispy exteriors and moist interiors.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- The appliance operates at 220V and 50Hz. Ensure your power supply matches these specifications.

Product Overview

The De'Longhi Multifry XL Fryer FH1363 features a compact design with advanced cooking capabilities.



Image 1: Front view of the De'Longhi Multifry XL Fryer FH1363. This image displays the appliance's overall design, including the transparent lid, control panel, and handle.

Key Components:

- **Transparent Lid:** Allows monitoring of the cooking process without opening.
- **Control Panel:** Includes power and temperature settings.
- **Mixing Paddle:** Automatically stirs food during cooking. It is removable for delicate foods.
- **Cooking Bowl:** Features non-stick and anti-scratch ceramic coating.
- **Heating Elements:** Double independent heating elements for efficient cooking.
- **Cool Touch Walls:** Designed to remain cool during operation for safe handling.

Setup

1. **Unpack the Appliance:** Carefully remove the fryer and all accessories from the packaging. Retain packaging for storage or future transport.
2. **Initial Cleaning:** Before first use, wash the removable lid, mixing paddle, and cooking bowl with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the fryer on a stable, flat, heat-resistant surface, away from walls and other appliances to ensure proper ventilation. Ensure there is sufficient space around the unit.
4. **Power Connection:** Ensure the power supply voltage (220V) and frequency (50Hz) match the appliance's requirements. Plug the power cord into a grounded electrical outlet.

Operating Instructions

General Operation:

1. **Prepare Ingredients:** Place your desired ingredients into the cooking bowl. For recipes requiring stirring, ensure the mixing paddle is correctly installed. For delicate items or those not requiring stirring, the paddle can be removed.
2. **Close the Lid:** Securely close the transparent lid.
3. **Power On:** Press the power button to turn on the appliance.
4. **Set Temperature:** Use the temperature control to select one of the four available power levels. Refer to your recipe or

cooking guide for recommended settings.

5. **Start Cooking:** The fryer will begin heating and cooking. The automatic mixing process will engage if the paddle is installed.
6. **Monitor Cooking:** Utilize the transparent lid to observe the cooking progress without interrupting the process.
7. **Power Off:** Once cooking is complete, press the power button to turn off the appliance and unplug it from the wall outlet.

Cooking Versatility:

The Multifry XL Fryer is capable of preparing a wide range of dishes.



Image 2: The De'Longhi Multifry XL Fryer FH1363 displayed alongside a variety of prepared meals, including pizza, fries, cake, and other dishes, showcasing its versatility.

- **Potatoes:** Ideal for both fresh and frozen potatoes, achieving a crispy texture.
- **Pizza & Cake:** Can be used for baking, offering an alternative to traditional ovens.
- **Risotto & Stew:** The automatic mixing paddle is particularly useful for dishes requiring constant stirring.
- **Fish & Meat:** Cook various types of fish and meat with minimal oil.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your fryer. Always unplug the appliance and allow it to cool completely before cleaning.

1. **Detachable Parts:** The lid, mixing paddle, and cooking bowl are easily detachable. Remove these parts for cleaning.
2. **Washing:** Wash the detachable parts with warm, soapy water. The non-stick and anti-scratch ceramic coating of the bowl makes cleaning simple. Avoid abrasive cleaners or scouring pads that could damage the coating.

3. **Rinsing and Drying:** Rinse all parts thoroughly with clean water and dry them completely before reassembling or storing.
4. **Exterior Cleaning:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.

Troubleshooting

If you encounter any issues with your De'Longhi Multifry XL Fryer FH1363, please refer to the following general advice.

- **Appliance Not Turning On:**
  - Ensure the power cord is securely plugged into a functional electrical outlet.
  - Check if the outlet is receiving power (e.g., by plugging in another appliance).
- **Food Not Cooking Evenly:**
  - Verify that the correct temperature level has been selected for the food type.
  - Ensure the mixing paddle is installed and functioning correctly for dishes that require stirring.
  - Avoid overfilling the cooking bowl; adhere to recommended capacities.
- **Unusual Noises:**
  - Check if the mixing paddle is properly seated.
  - Ensure no foreign objects are inside the cooking bowl.

For issues not resolved by the above steps, please contact De'Longhi customer support. Do not attempt to repair the appliance yourself.

Specifications



Image 3: Side view of the De'Longhi Multifry XL Fryer FH1363 with key dimensions (length, width, height) indicated in centimeters.

Feature	Specification
Brand	De'Longhi
Model Number	FH1363
Capacity	1.7 Liters
Power / Wattage	1400 watts
Voltage	220 Volts
Product Dimensions (L x W x H)	39.5 x 32.5 x 29 cm
Item Weight	5.29 Kilograms
Material	Plastic
Special Features	Temperature Control, Double Independent Heating Elements, Automatic Mixing Process

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official De'Longhi website.
If you require technical assistance, spare parts, or have any questions regarding your De'Longhi Multifry XL Fryer FH1363, please contact De'Longhi customer support. Contact details can typically be found on the official De'Longhi website or in the product

packaging.

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00VE53LHY

More documents and user manuals: **https://manuals.plus/**