Powermatic 19642

Powermatic Mini Precision Manual Rolling Machine User Manual

Model: 19642 | Brand: Powermatic

Introduction

The Powermatic Mini Precision Manual Rolling Machine is designed for efficient and consistent manual rolling. Its compact size and durable metal construction ensure reliable performance. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to help you get the most out of your machine.

Important Safety Information

Please read all instructions carefully before using the Powermatic Mini. Failure to follow these guidelines may result in damage to the machine or personal injury.

- Keep the machine out of reach of children and pets.
- Use only dry, shredded material suitable for rolling. Do not use wet or excessively coarse material, as this can jam or damage the mechanism.
- Do not force the slider or any moving parts. If resistance is encountered, check for obstructions.
- Clean the machine regularly as instructed in the maintenance section to prevent buildup and ensure smooth operation.
- Do not attempt to disassemble the machine beyond what is described in this manual.

Package Contents

Verify that all items are present in the package:

- 1 x Powermatic Mini Precision Manual Rolling Machine
- 1 x Cleaning Brush
- 1 x Poker Tool
- 1 x User Manual (this document)



Image: Powermatic Mini machine shown with its retail packaging and the included cleaning brush and poker tool.

Setup

Before first use, ensure the machine is clean and free of any debris. No assembly is required for the Powermatic Mini.



Image: Quick Start Manual diagram illustrating the steps for preparing and using the machine.

Operation Instructions

Follow these steps for optimal performance:

1. **Prepare the Machine:** Ensure the slider is all the way to the right, in the "start" position.



Image: The Powermatic Mini with its slider positioned to the right, indicating the start position.

2. **Load Material:** Lift the cover to fully open the tobacco chamber. Evenly sprinkle your chosen material into the chamber. Do not overfill.
3. **Compress Material:** Lightly compress the material in the chamber with your fingers to ensure it is evenly distributed and not too loose or too packed.
4. **Insert Tube:** Insert an empty cigarette tube onto the brass nozzle on the left side of the machine. Ensure it is fully seated.
5. **Close Cover:** Close the cover completely down.
6. **Inject:** Hold the machine firmly with one hand. With the other hand, smoothly move the slider completely to the left. This action injects the material into the tube.
7. **Remove Finished Product:** Once the slider reaches the left, open the cover and carefully remove the filled tube from the brass nozzle.

Repeat the steps for each new tube. For best results, use high-quality, properly shredded material.



Image: The Powermatic Mini machine displayed on a wooden surface, highlighting its compact design and included accessories.

Maintenance and Cleaning

Regular cleaning will extend the life of your Powermatic Mini and ensure consistent performance.

- After each use, or as needed, use the included cleaning brush to remove any loose material from the chamber and around the slider mechanism.
- The poker tool can be used to gently clear any blockages in the brass nozzle.
- Wipe the exterior of the machine with a dry or slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the machine is completely dry before storing.
- Store in a cool, dry place away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Material not injecting fully.	Material is too wet or too coarse. Chamber is overfilled or underfilled. Slider not moved completely.	Use drier, finer shredded material. Adjust the amount of material. Ensure full, smooth stroke of the slider.
Tube tears or rips.	Tube not fully seated on nozzle. Material is too tightly packed. Damaged tube.	Ensure tube is pushed all the way onto the brass nozzle. Lightly compress material, do not overpack. Use new, undamaged tubes.

Problem	Possible Cause	Solution
Slider is stiff or jammed.	Material lodged in mechanism. Machine needs cleaning.	Clear any visible obstructions with the poker tool or brush. Perform thorough cleaning as per maintenance section.

Specifications

Model: 19642

Brand: Powermatic

Material: Metal

Color: Black

Item Weight: 15.5 ounces

Package Dimensions: 6.02 x 5.67 x 2.09 inches

UPC: 759284130889, 784652551232

Assembly Required: No

Batteries Required: No

Warranty and Support

For warranty information, technical support, or to inquire about replacement parts, please contact Powermatic customer service directly. Refer to the product packaging or the official Powermatic website for current contact details.
Official Website: www.powermaticinjector.com

© 2024 Powermatic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question